


# PHV-A7E

## SERVICE MANUAL

*AEP Model*  
*E Model*



### SPECIFICATIONS

#### • System

Video signal PAL  
Image device Precision CCD image sensor

#### • Input and output jacks

S video output 4-pin mini DIN  
Luminance: 1Vp-p, 75 ohms unbalanced, sync negative  
Chrominance: 0.300Vp-p, 75 ohms unbalanced  
Video output Phono jack, 1Vp-p, 75 ohms unbalanced, sync negative  
RFU DC OUT Special mini jack, 5V DC  
Audio output Phono jack, -7.5dBs, (at output impedance 47 kilohms), impedance less than 2.2 kilohms  
MIC IN Minijack, -60dBs, low impedance with 2.5-3V DC output, impedance 6.8 kilohms

#### • General

Power requirements AC 220-240V 50/60Hz  
Power consumption 12 W  
Operating temperature 5°C to 40°C (41°F to 104°F)  
Storage temperature -20°C to 60°C (-4°F to 140°F)  
Range of object field 48.5 × 36.6-8.6 × 6.5 mm  
(1<sup>15</sup>/<sub>16</sub> × 1<sup>1</sup>/<sub>2</sub>-1<sup>1</sup>/<sub>32</sub> × 9<sup>9</sup>/<sub>32</sub> inches)  
Dimensions 126 × 256 × 190 (w/h/d) mm  
(5 × 10<sup>1</sup>/<sub>8</sub> × 7<sup>1</sup>/<sub>2</sub> inches)  
Weight 2.3kg (5 lb 1 oz)  
Supplied accessories Film carrier (for strip film 1, for mounted film 1)  
AV connecting cable (1)  
Dust cover (1)  
Optional accessories Video printer  
Microphone F-VS3  
S video connecting cable  
21-pin connecting cable  
RFU adaptor  
LCD colour monitor  
Film carrier HVT-NA7/SA7

Design and specifications are subject to change without notice.

#### Note

This appliance conforms with EEC Directive 87/308/EEC regarding interference suppression.





PHOTO VIDEO CAMERA  
**SONY**®

## SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the B+ voltage to see it is at the values specified.

### SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK  OR DOTTED LINE WITH MARK  ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.



## TABLE OF CONTENTS

Section	Title	Page	Section	Title	Page
1.	GENERAL		6.	ELECTRICAL PARTS LIST	112
	Overview	4		HARDWARE LIST	126
	Precautions	5	7.	ELECTRICAL ADJUSTMENT	
	Parts Identification	5		7-1. Preparations for Adjustment	127
	To Connect Other Equipment	7		7-1-1. Servicing tools	127
	Basic Operation	8		7-1-2. Preparation	128
	Advanced Operation	10		7-1-3. Precautions	129
2.	DISASSEMBLY			7-1-4. Adjustment remote controller	131
2-1.	Removal of Outer Section-1	11		7-1-5. Check Point Array	136
2-2.	Removal of Outer Section-2	11		7-1-6. AF Microprocessor Data Reading Tool	136
2-3.	Opening of VC-85 Board	12		7-1-7. Data Processing	137
2-4.	Removal of Front Bracket (FA-1 and JS-22 Boards)	12		7-2. Focus Adjustment	138
2-5.	Removal of Fluorescent Lamp Assembly	13		7-3. Electrical Adjustment	138
2-6.	Removal of DC-DC Converter Unit	13		7-3-1. Power Supply Check	138
2-7.	Removal of Power Block	14		7-3-2. DDS Microprocessor System Clock Adjustment (VC-85 Board)	139
2-8.	Removal of t Frame Assembly (PJ-43 Board)	14		7-3-3. DDS Microprocessor Clock Check (VC-85 board)	139
2-9.	Removal of MC-65 Board	15		7-3-4. PLL Adjustment	139
2-10.	Removal of Lens Assembly	15		7-3-5. EVR Initial Settings	140
2-11.	Removal of Lens Assembly	16		7-3-6. PG CONT and VSUB Adjustment	141
2-12.	Removal of GE-10 Board	16		7-3-7. Hall Adjustment (VC-85 Board)	141
2-13.	Removal of Zoom Lens	17		7-3-8. Positive Iris Adjustment (VC-85 Board)	142
3.	DIAGRAMS			7-3-9. GC Confirmation (VC-85 board)	142
3-1.	Circuit Board Location	18		7-3-10. Y Signal Matrix Adjustment (VC-85 Board)	142
3-2.	Overall Block Diagram	19		7-3-11. Chroma Signal Matrix Adjustment (1) (VC-85 Board)	143
3-3.	Camera (1) Block Diagram	22		7-3-12. Chroma Signal Matrix Adjustment (2) (VC-85 Board)	144
3-4.	Camera (2) Block Diagram	25		7-3-13. YH Level Adjustment (VC-85 Board)	145
3-5.	Focus Block Diagram	30		7-3-14. Sync Level Adjustment (PJ-43 Board)	145
3-6.	System Control Block Diagram	33		7-3-15. Setup Adjustment (PJ-43 Board)	146
3-7.	Description of System Control Block	35		7-3-16. White Clip Adjustment (PJ-43 Board)	146
3-7-1.	DDS Micro Processor $\mu$ PD7508BGB (IC101 on VC-85 board)	35		7-3-17. Y Level adjustment (PJ-43 Board)	147
3-7-2.	EVR Micro Processor MC68HC05N4FU (IC802 on VC-85 board)	37		7-3-18. Aperture Adjustment (VC-85 Board)	147
3-7-3.	AF Micro Processor MC68HC05C4FU (IC905 on VC-85 board)	38		7-3-19. Chroma Level Adjustment (VC-85 Board)	148
3-8.	Audio Block Diagram	41		7-3-20. Burst Phase Adjustment (PJ-43 Board) (Method Using Vectorscope)	148
3-9.	Power Block Diagram	43		7-3-21. Burst Phase Adjustment (PJ-43 Board) (Method Using Oscilloscope)	149
4.	PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS			7-3-22. Burst Level Adjustment	149
4-1.	Frame Schematic Diagram	45		7-3-23. Negative Iris Adjustment (VC-85 Board)	150
4-2.	Printed Wiring Boards and Schematic Diagrams	48		7-3-24. Negative Y Level Adjustment (PJ-43 Board)	150
	• CD-52 Board	49		7-3-25. Negative Color Reproduction Adjustment (PJ-43 Board)	151
	• GE-10 Board	54		7-3-26. Negative Color Reproduction Adjustment (Method Using Oscilloscope)	152
	• VC-85 Board	61		7-3-27. Negative Pre-white Balance Adjustment (VC-85 Board)	153
	• VC-85, FR-62 Boards	80		7-3-28. Auto White Balance Adjustment	154
	• MC-65, FA-1, PJ-43, JS-22 Boards	97		7-3-29. Positive Pre-white Balance Adjustment (VC-85 Board)	156
	• Power Block	103		7-3-30. Positive Color Reproduction Adjustment (Method using vectorscope)	157
4-3.	Semiconductors	107		7-3-31. Positive Color Reproduction Adjustment (Method using oscilloscope)	158
5.	EXPLODED VIEWS			7-3-32. Auto Focus Adjustment (VC-85 board)	159
5-1.	Cabinet	109		7-3-33. Auto Focus Confirmation (VC-85 Board)	159
5-2.	Chassis	110		7-4. Arrangement Diagram for Adjustment Parts	160
5-3.	Lens	111			

There is the color reproduction standard frame at the back of the book.

# SECTION 1 GENERAL

This section is extracted from instruction manual.

## Overview


The photo video camera PHV-A7E is a film-to-video converter which enables you to view your photo films on your TV. Having the negative/positive selector, you can easily display both negative and positive films. It also accepts both strip and mounted film. Furthermore, you can use this unit in many other ways such as magnifying a small object on the TV screen.

### Main features of the PHV-A7E

- 1/2 inch precision CCD image sensor (470,000 picture elements) for sharp, clear image detail
- High resolution picture (400 TV lines and above)
- S video output for high quality picture
- Negative/positive selector for using both negative and positive films
- Instant automatic focus function for easy focusing
- Zooming function (x8) for making the picture appear closer or farther away
- White balance function for adjusting the white colour of your picture
- Manual iris control for adjusting the brightness to your taste
- Colour balance control for adding colour effect
- Angle rotating control for changing the angle of the picture
- Microphone input for adding sound effects
- Trimming function for cutting unnecessary parts of the picture

### Supplied accessories

Before you start operation, check to see that everything is contained in the package.



## With This Unit, You Can

<p>Display negative film on the TV screen</p>	<p>Magnify a small object or photograph on the TV screen</p>
<p>Connect to VCR for editing or video printer for printing</p>	<p>Use as an instant titler for editing</p>
<p>Connect to personal computer for scanning the picture</p>	<p>Add sound effects using a microphone</p>

## Precautions

### On safety

- Operate the unit only on 220-240V AC, 50/60Hz
- Should any liquid or solid object fall into the cabinet, unplug the unit and have it checked by qualified personnel before operating it any further.
- Unplug the unit from the wall outlet if it will not be used for an extended period of time. To disconnect the cord, pull it out by grasping the plug. Never pull the cord itself.

### On installation

Do not install the unit in a location near heat sources such as radiators or air ducts, or in a place subject to direct sunlight, excessive dust, mechanical vibration or shock.

### On connection

- Before connecting, be sure to turn off all equipment.
- Insert plugs securely, as loose connections may cause hum and noise.
- To disconnect the cord, pull it out by the plug. Never pull the cord itself.
- To avoid interference, turn off equipment not in use.
- If noise occurs in the picture or sound, move the pieces of equipment farther away from each other.
- For details on connections, refer to the instruction manuals covering the corresponding equipment.

### On operation

When the unit will not be used, turn the power off to conserve energy and to extend the useful life of your unit.

### On cleaning the cabinet

Clean the cabinet and controls with a soft cloth lightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent such as alcohol or benzene.

To clean the plate which covers the light source part, remove the film carrier.


Clean the lens and film with a blower. If dust is on the lens, it will be displayed on the screen.

### On repacking

Do not throw away the carton and the packing material. It makes an ideal container to transport the unit in.


## Parts Identification

### Front





# Parts Identification

Right Side




Rear




## To Connect Other Equipment

Before connection, be sure to turn off the power of all equipment. Refer to the manuals of the corresponding equipment for connection.


### To Connect to a TV/monitor with Audio/video Inputs




### To Connect to a TV/monitor with an S Video Input



### To Connect to a TV/monitor with a 21-pin connector




### To Connect to a TV without an Audio/video Input



### If the TV/monitor is stereo


Connect the audio plug (black) of the supplied AV connecting cable to the audio left (white) jack of the TV/monitor. You can also use the AV connecting cable (not supplied).

### To Connect to a VTR




## To Connect Other Equipment

### To Connect to a Video Printer



### To Connect to an LCD Colour Monitor



Attach the LCD colour monitor (not supplied) via the accessory shoe, then connect the monitor and PHV-A7E with the supplied AV connecting cable.

## Basic Operation


This section explains the procedure for displaying film on the TV screen. This unit accepts film under 35 mm.

### 1 Turn on the power of this unit and the TV.


The picture appears on the screen after about 4 seconds.

#### Note


When you turn on the power, the light source may not light up if the fluorescent tube protection circuit functions. In such case, turn off the power, then turn on again after about 5 seconds.



### 2 Attach the film carrier (for strip film or mounted film) to the carrier guide of this unit.




### 3 Adjust the angle of the picture. You can adjust the angle within 270°.



Rotate the angle rotating dial.


## 4 Set the NEGA/POSI (negative/positive) switch.



## 5 Press ZOOM button (T or W).

### Note


While pressing the ZOOM button (also a few seconds after), automatic focus functions.



To make the subject appear farther away  
Press W (wide).




To make the subject appear closer  
Press T (telephoto).



## 6 Adjust the focus.

Keep the PUSH AUTO button pressed until the picture is in focus.



### To focus manually


The automatic focus may not function depending on the kind of the film you are using. In such case, adjust the focus with the FOCUS +/- button.

If the colour or brightness is not normal  
Turn off the power, then after a few seconds, turn it on again.


To trim the unnecessary part of the picture  
Move the film carrier to adjust the position of the picture, then press the ZOOM button to adjust the size.

## How to Change the Colour Balance

### 1 Press the ON/OFF button.




### 2 Adjust with the COLOUR BALANCE control.



## How to Adjust the Brightness

**1** Press the IRIS PUSH MANUAL button.



**2** Adjust with the CLOSE/OPEN control.



You can adjust for inadequate brightness to a certain extent, even if it was due to under exposure when the picture was taken.

### Notes on the iris adjustment

This unit automatically adjusts the iris using the brightest part of the object that the lens is focused on. In the following cases, the automatic iris may not function. In such cases, adjust it manually.

- The film on the film carrier is not placed properly, and the light has hit the light source directly.
- The picture has changed due to zooming or trimming.
- The original film was extremely over or under exposed.
- The original film has too much contrast.

## How to Adjust the Colour

Adjust with the COLOUR control.



To make the colour deeper, turn to the right. To make the colour paler, turn to the left. If you turn the control to the left end, the colour turns to black and white.

## To Insert Sound Using a Microphone

**1** Connect the microphone to MIC IN (PLUG IN POWER) jack.

**2** Adjust the volume with the MIC LEVEL control.



When this unit is connected to a TV/monitor and audio system, and the microphone is near the speaker, howling (noise) may occur. In such case, lower the volume of the TV and audio system.

## How to Hold the White Balance Level

When you zoom the picture, the white balance level may change. To avoid such change, use this function.

Press the WHT BAL PUSH HOLD button.



The white balance level does not change when you press the ZOOM button to change the size of the picture.


## To Display a Small Object or Photograph

To display small object or photograph, remove the carrier guide from this unit, then place the object or photograph directly. If placed on the carrier guide, the picture may not be in focus.


### Notes

- Without the carrier guide, light hits the light source directly and may interfere with automatic iris function. In such case, adjust iris manually.
- Do not scratch the surface of the plate which covers the light source.

How to remove the carrier guide




How to attach the carrier guide






## SECTION 2 DISASSEMBLY


### 2-1. REMOVAL OF OUTER SECTION-1




### 2-2. REMOVAL OF OUTER SECTION-2




### 2-3. OPENING OF VC-85 BOARD




### 2-4. REMOVAL OF FRONT BRACKET (FA-1 AND JS-22 BOARDS)




## 2-5. REMOVAL OF FLUORESCENT LAMP ASSEMBLY




## 2-6. REMOVAL OF DC-DC CONVERTER UNIT




## 2-7. REMOVAL OF POWER BLOCK



## 2-8. REMOVAL OF T FRAME ASSEMBLY (PJ-43 BOARD)




## 2-9. REMOVAL OF MC-65 BOARD



## 2-10. REMOVAL OF LENS ASSEMBLY


- 1 Refer to 2-3 and open the VC-85 board.
- 2 Refer to 2-7 and remove the power block.



## 2-11. REMOVAL OF LENS ASSEMBLY

**① Three screws (+PTP2×12)**

(Turn the lens assembly and remove the screws at the potimum position with a long screw driver.)



**② Hold up the lens assembly.**

## 2-12. REMOVAL OF GE-10 BOARD


**② Remove the shield case (C) in the arrow direction.**

**① Two screws (+P2×3)**

**④ Screw (+P2×3)**

**⑧ GE-10 board**

**⑤ Two screws (+BTP2×5)**




**③ Five connectors (CN852 to CN856)**

**⑥ Connector (CN602 18P)**


**⑦ Connector (CN603 2P)**

## 2-13. REMOVAL OF ZOOM LENS




## SECTION 3 DIAGRAMS


### 3-1. CIRCUIT BOARD LOCATION









3-2. OVERALL BLOCK DIAGRAM







### 3-3. CAMERA (1) BLOCK DIAGRAM

**GE-10 BOARD (1/2) (See Page 57)**





**VC-85 BOARD (1/3)**  
(See Page 61, 75,  
80, 93)







### 3-5. FOCUS BLOCK DIAGRAM











3-7. DESCRIPTION OF SYSTEM CONTROL BLOCK

The system control block consists of the three micro processors listed below.

- DDS Micro processor  $\mu$ PD7508BGB
- EVR Micro processor MC68HC05N4FU
- AF Micro processor MC68HC05C4FU

3-7-1. DDS Micro Processor  $\mu$ PD7508BGB  
(IC101 on VC-85 board)

1. Description of functions

- 1) Internal data communication control
- 2) Key matrix reading  
(White balance, focus mode, iris mode, color balance mode)

2. Terminal functions and Input/output levels (  $\mu$ PD7508BGB)

Pin No.	Signal Name	I/O	Function and Input/Output Level
1	CMI 0	I	Key matrix input signal. Normally "H" 1V period "L" pulse when there is key input
2	CMI 1	I	
3	CMI 2	I	
4	CMI 3	I	
5	CMO 0	O	Key matrix output signal 1V period "L" pulse
6	CMO 1	O	
7	CMO 2	O	
8	CMO 3	O	
9	—	—	—
10	—	—	—
11	—	—	—
12	—	—	—
13	—	—	—
14	—	—	—
15	RESET	I	Reset input, Normally "L"
16	CL 1	I	System clock oscillation terminal, 330 kHz when operating
17	VDD	—	Power supply input terminal
18	CL 2	O	System clock oscillation terminal.
19	INT 1	I	Interrupting input by camera VD, 1V period "H" pulse
20	GND	—	—
21	DDS SCK	I/O	Serial communication serial clock input/output, V period "L" pulse row
22	DDS SO	O	Serial communication data output, V period "H" pulse row
23	—	—	—
24	DDS SI	I	Serial communication data input, V period "L" pulse row
25	—	—	—
26	POWER	I	5V power supply detection, "H" when power is on
27	—	—	—
28	TEST	I	Test mode input, Normally "H"
29	—	—	—
30	—	—	—
31	EVR CS	O	Chip select signal for EVR micro processor, 1V period "L" pulse
32	—	O	—
33	FOCUS	O	Focus mode output, Manual mode "H"
34	IRIS	O	Iris mode output, Manual mode "H"
35	WHITE BALANCE	O	White balance mode output, Hold mode "H"
36	COLOR BALANCE	—	Color balance mode output, Color balance on "H"
37	Vss	I	GND
38	X1	O	Crystal oscillation circuit input for clock, 32.768 kHz
39	X2	—	Crystal oscillation circuit output for clock, 32.768 kHz
40	—	—	—
41	—	—	—
42	—	—	—
43	—	—	—
44	—	—	—

3-7-2. EVR Micro Processor MC68HC05N4FU (IC802 on VC-85 board)

1. Description of functions.

- 1) EVR control
- 2) Automatic white balance control

2. Terminal functions and input/output levels (MC68HC05N4FU)

Pin No.	Signal Name	I/O	Function and Input/Output Level
1	—	—	—
2	SSW	O	"H" only when communicating with serial switchover D/A converter, V period "H" pulse
3	SCLK	O	Serial clock output, V period "L" pulse row
4	SI	I	Serial data input, V period "H" pulse row
5	SO	O	Serial data output, V period "L" pulse row
6	EVR CS	I	Communication demand from DDS, V period "L" pulse
7	L IN	I	LANC input, L: 0, H: 1, V period "H" pulse row
8	L OUT	O	LANC output, L: 0, H: 1, V period "H" pulse row
9	CAM ADJ	I	NORMAL/ADJUST switchover, Normally "H". "L" during adjustment
10	—	—	—
11	SSW	O	Serial signal switchover, V period "L" pulse
12, 13	LD	O	Data load command for EVR (IC703, IC706), V period "H" pulse
14	—	—	—
15	IRIS I/O	I	IN DOOR/OUT DOOR discrimination input, H: IN DOOR, L: OUT DOOR
16	—	—	—
17	VDD	—	Connected to REG 5V
18	GND	—	GND
19	—	—	—
20	PAL/NTSC	I	Broadcasting method selection, L: NTSC, H: PAL
21	TG STB	—	Timing generator strobe signal
22	GND	—	—
23	GND	—	—
24, 25	GND	—	—
26	GND	—	—
27	GND	—	—
28	CAM 5V	I	Camera power rising is observed. L: CAM OFF, H: CAM ON
29	AW IN	I	AWS A/D timer is stopped. Pattern drive interruption, Normally 2V period pulse
30	AW ADJ	O	AWS preset data is taken in. Normally "L", "H" during auto white balance adjustment
31	—	—	—
32	—	—	—
33	—	—	—
34	S3SW	O	AWB measurement signal selection, 3V period "H" pulse
35	S2SW	O	AWB measurement signal selection, 3V period "H" pulse
36	DISCHG	O	Capacitor reset pulse for generating timer measurement lamp voltage, V period "H" pulse
37	—	—	—
38	S1SW	O	AWB measurement signal selection, 3V period "H" pulse
39	—	—	—
40	OSC2	O	Built-in inverter output for oscillation. Oscillation frequency: 4 MHz.
41	OSC1	I	Built-in inverter input for oscillation.
42	VDD	—	Connected to REG 5V.
43	—	—	—
44	RESET	—	Normally "H", "L" during reset
45	IRQ	—	Connected to EVR CS signal, V period "L" pulse
46	—	—	Connected to VDD
47	—	—	Connected to VDD
48	—	—	—

3-7-3. AF Micro Processor MC68HC05C4FU (IC905 on VC-85 board)

1. Description of functions

- 1) AF control
- 2) Power focus
- 3) Zoom motor drive

2. The auto focus system in this unit


(A-AF:Image processing method)

Subjects the high frequency components of the video signal (actually the luminance signal) to micro processor processings at TTL without utilizing the external sensor, and controls the focus.

3. Outline of operations

Extracts the high frequency components of 100k to 2 MHz and 1M to 2 MHz from the luminance signal Y, and subjects these components to digital integration with every field.

This integration value known as the evaluation value. And it is used as information for auto focusing performed by controlling the focus ring while searching for the evaluation value peak, based on the concept:[When in focus → Clearer image edges → Increase in image high frequency components → Increase in evaluation value].




## 4. Terminal functions and input/output levels (MC68HC05C4FU)


Pin No.	Signal Name	I/O	Function and Input/Output Level
1	SS OUT	O	EVR data reading timing output (PD5 SS input), V period "L" pulse row
2	—	—	—
3	—	—	—
4	AGC COMP	I	EE LOCK AGC comparater
5	IRIS COMP	I	EE LOCK IRIS comparater
6	—	—	—
7	—	—	—
8	—	—	—
9	—	—	—
10	—	—	—
11	ZOOM T	O	Normally "H", "L" when the zoom motor is rotated to the TELE side
12	ZOOM W	O	Normally "H", "L" when the zoom motor is rotated to the WIDE side
13	Focus N	O	Normally "L", "H" when the focus motor is rotated to the FAR side
14	—	—	—
15	Focus F	O	Normally "L". "H" when the focus motor is rotated to the NEAR side
16	F SPD $\phi$	O	Focus motor speed control signal 0 bit (LSB)
17	—	—	—
18	F SPD1	O	Focus motor speed control signal 1 bit
19	F SPD2	O	Focus motor speed control signal 2 bit
20	—	—	—
21	F SPD3	O	Focus motor speed control signal 3 bit (MSB)
22	—	—	—
23	Vss	—	Connected to GND
24	Vss	—	Connected to GND
25	—	—	—
26	FOCUS NEAR	I	"L" at focus ring NEAR side
27	—	—	—
28	WEIGHTING	O	Amplifies the signal from AF switch.
29	—	—	—
30	FOCUS FAR	I	"L" at focus ring FAR side
31	AF SSW	O	Timing output for bus switchovers, V period "H" pulse
32	—	—	—
33	DA STB	O	D/A converter for AF, For data latch, V period "H" pulse row
34	PAL/NTSC	I	PAL/NTSC switchover
35	—	—	—
36	J STB	O	Exterior display tool, For data latch, V period "L" pulse
37	XCS	O	Communication demand active "L" to IC904 CXD-1204, V period "L" pulse.
38	TEST	I	Connected to VDD
39	—	—	—
40	MODE	I	Connected to VDD
41	MISO	I/O	SPI MASTER: in SLAVE: out V period "H" pulse row
42	MOSI	I/O	SPI MASTER: out SLAVE: in V period "L" pulse row
43	SCK	I/O	SPI SERIAL CLOCK V period "L" pulse row
44	—	—	—
45	SS	I	V period "L" pulse row
46	—	—	—
47	—	—	—

Pin No.	Signal Name	I/O	Function and Input/Output Level
48	EVR CS	I	EVR data communication demand $\overline{L}$ from DDS micro processor, V period "L" pulse
49	—	—	—
50	—	—	—
51	Focus $\overline{FG}$	I	Interruption outbreak at focus MOTOR FG $\overline{L}$ , "L" when auto focus is off, "H" pulse of the period corresponding to the rotation speed of focus motor when the auto focus is on
52	CLK OUT	O	Waveform shaping output of pin ⑤ clock (1.79 MHz)
53	—	—	—
54	CLK IN	I	External clock input, The 14.3 MHz clock input to pin ② of IC904 is frequency divided into 1/8 and input.
55	VDD	—	CAM 5V
56	—	—	—
57	—	—	—
58	—	—	—
59	—	—	—
60	SYS RST	I	Normally "H". "L" when reset
61	AREA	I	Interruption outbreak at $\overline{L}$ from CXD-1204 (IC904). V period pulse
62	VPP	—	CAM 5V
63	—	—	—
64	—	—	—


3-8. AUDIO BLOCK DIAGRAM



3-9. POWER BLOCK DIAGRAM






### 3-9. POWER BLOCK DIAGRAM



## SECTION 4

## PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS




## 4-1. FRAME SCHEMATIC DIAGRAM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22

10

-77 (C)



FRAME FRAME

FRAME



4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS.  
(In addition to this , the necessary note is printed in each block.)

- **For printed wiring boards.**

  - : indicated a lead wire mounted on the component side.
  - : Through hole.
  - : Parts mounted on the conductor side.
  - ▒ : Pattern from the side which enables seeing.
  - ▒ : Pattern of the rear side.
  - : Circled numbers refer to waveforms.
- **Measuring conditions voltage value and waveform.**

  - The object is color bar chart (positive type).
  - Voltages are dc between ground and measurement points. Readings are taken with a digital multimeter (DC 10MΩ ).
  - Voltage variations may be noted due to normal production tolerances.

Caution:

Pattern face side: Parts on the pattern face side seen from (Conductor Side) the pattern face are indicated.





Parts face side: Parts on the parts face side seen from the (Component side) parts face are indicated.

- **For schematic diagrams.**
- Caution when replacing chip parts.  
New parts must be attached after removal of chip.  
Be careful not to heat the minuts side of tantalum capacitor, because it is damaged by the heat.
  - All resistors are in ohms, 1/6W unless otherwise noted.  
Chip resistor are 1/16W unless otherwise noted.  
kΩ : 1000Ω , MΩ : 1000kΩ .
  - All capacitors are in μF unless otherwise noted. pF: μ μF.  
50V or less are not indicated except for electrolytics and tantalums.
  - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
  - ⎓ : nonflammable resistor.
  - ⎓ : fusible resistor.
  - : panel designation.
  - : adjustment for repair.
  - : B+ Line.
  - - - : B- Line.
  - ↔ : IN/OUT direction of ( + , - ) B LINE.
  - Circled numbers refer to waveforms.

**Note:**  
The components identi- fied by mark △ or dotted line with mark △ are critical for safty.  
Replace only with part number specified.


When indicating parts by refer-  
ence number, please include the  
board name.

1. Adjust the distance so that the output waveform of Fig. a and the Fig. b can be obtain.




Waveform.  
nt points.  
0MΩ).  
al production  
of Fig. a and

# CD-52 BOARD



## CD-52 (CCD IMAGER) SCHEMATIC DIAGRAM

— Ref. No. CD-52 BOARD: 1000 series —



### • SIGNAL PATH

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA/DATA	
REC			➡➡➡	
PB				

### CAUTIONS FOR REPLACING THE CCD IMAGER

- According to type of CCD imager (IC101 on the CD-52 board), it is necessary to require the compensating ROM (IC001 on the DT-77B board). The repairing CCD imager does not require the compensating ROM.
- So when replacing the CCD imager on which the compensating ROM is installed, remove the compensating ROM before replacement.
- Since the mounted CD-52 and DT-77B boards which are supplied as a repair parts are not installed IC101 and IC001 respectively, replace the respective ICs from the previous board to the new when replacing each board.
- When you replaced the CCD imager, perform the overall camera head adjustment.
- CCD imager has such a structure that it may be spoiled by static electricity, so handle it with a care similar for MOS IC. Further, be sure that the light receiving part has no stick of dust and no entry of bright light.




CD-52 (CCD IMAGER) PRINTED WIRING BOARD

— Ref. No. CD-52 BOARD: 1000 series —


CD-52 BOARD

- D623 C-13
- D624 C-12
- D627 B-13
- D628 C-13
- Q601 B-12
- Q622 E-10
- Q623 D-13
- Q625 C-13
- Q626 E-12

CD-52 BOARD (COMPONENT SIDE)




CD-52 BOARD (CONDUCTOR SIDE)





**CD-52 BOARD (CONDUCTOR SIDE)**



\* A-7062-929-A CD-52 BOARD, COMPLETE

\*\*\*\*\*

(Ref. No 1,000 Series)

< DIODE >

D623	8-719-404-46	DIODE	MA110
D624	8-719-820-05	DIODE	1SS181
D627	8-719-800-76	DIODE	1SS226
D628	8-719-404-46	DIODE	MA110

< TRANSISTOR >

Q601	8-765-420-02	TRANSISTOR	2SK300-3
Q622	8-729-403-42	TRANSISTOR	XN1401
Q623	8-729-421-23	TRANSISTOR	XN1216
Q625	8-729-905-35	TRANSISTOR	2SC4081-R
Q626	8-729-402-84	TRANSISTOR	XN4601



GE-10 (SYNC/TIMING GENERATOR) PRINTED WIRING BOARD

— Ref. No. GE-10 BOARD: 4000 series —

\* A-7062-930-A GE-10 BOARD, COMPLETE  
\*\*\*\*\*  
(Ref. No. 4,000 Series)

A-7068-165-A DT-77B BOARD, COMPLETE (HIC)

< DIODE >

D621	8-719-404-46	DIODE	MA110
D622	8-719-404-46	DIODE	MA110
D625	8-719-949-46	DIODE	1T32
D631	8-719-404-46	DIODE	MA110

< IC >

IC621	8-752-326-08	IC	CXD1159Q
-------	--------------	----	----------


< TRANSISTOR >

Q621	8-729-402-84	TRANSISTOR	XN4601
Q624	8-729-402-84	TRANSISTOR	XN4601
Q627	8-729-402-84	TRANSISTOR	XN4601
Q628	8-729-905-35	TRANSISTOR	2SC4081-R
Q630	8-729-905-35	TRANSISTOR	2SC4081-R
Q633	8-729-402-84	TRANSISTOR	XN4601


GE-10 BOARD

D621	D-12
D622	D-12
D625	C-7
IC621	C-8
Q621	D-3
Q624	B-3
Q627	B-3
Q628	A-8
Q630	D-8
Q633	C-3

GE-10 BOARD (COMPONENT SIDE)




GE-10 BOARD (COND






D (COMPONENT SIDE)



GE-10 BOARD (CONDUCTOR SIDE)







1	2	3	4	5	6	7	8	9	10	11
---	---	---	---	---	---	---	---	---	----	----

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O










FP-378 (FLEXIBLE) → TO VC-85 (2/4) BOARD CN705 CN706  
(See Page 95)

GE-10 BOARD




• SIGNAL PATH

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA/DATA	
REC	→	→→	→→→	
PB				


VC-85 (CAMERA PROCESS, SYSTEM CONTROL) SCHEMATIC DIAGRAM


VC-85 BOARD (1/4)




— Ref. No. VC-85 BOARD: 7000 series —

VC-85 (1/4) BOARD










# VC-85 (CAMERA PROCESS, SYSTEM CONTROL), FR-62 (FLUORESCENT DISPLAY) PRINTED WIRING BOARDS

— Ref. No. FR-62 BOARD: 3000 series, VC-85 BOARD: 7000 series —


VC-85 BOARD

D101	F-3	Q703	F-14
D102	F-2	Q704	K-18
D103	F-3	Q705	F-14
D104	G-3	Q706	G-14
D106	E-29	Q707	J-20
D107	F-4	Q708	B-16
D108	E-29	Q709	I-20
D201	K-28	Q710	J-22
D202	K-28	Q711	J-22
D203	F-28	Q712	K-19
D575	F-22	Q713	H-21
D576	F-22	Q714	K-18
D801	A-17	Q715	H-18
D802	A-15	Q716	C-21
D852	A-8	Q717	I-11
D901	H-25	Q718	I-21
D902	H-24	Q719	J-19
		Q720	J-19
		Q721	J-19
		Q722	J-18
		Q723	H-23
		Q724	I-23
		Q725	I-23
		Q727	F-12
		Q728	H-11
		Q734	H-22
		Q801	B-15
		Q802	A-17
		Q803	B-19
		Q804	B-13
		Q805	B-14
		Q806	B-15
		Q807	B-14
		Q851	A-7
		Q852	A-7
		Q853	B-8
		Q854	A-25
		Q855	A-8
		Q856	A-24
		Q858	B-7
		Q859	B-25
		Q860	B-25
		Q901	H-24
		Q902	F-25
		Q903	H-26
		Q904	H-24
		Q906	E-5
		Q907	D-27
		Q909	E-24
		Q910	F-24
		Q911	E-24
		Q914	G-24
		Q915	F-6
		Q916	F-27
		Q918	C-27
		Q919	C-26
		Q920	G-24
Q101	F-4		
Q102	F-3		
Q103	F-3		
Q105	E-28		
Q202	J-2		
Q203	J-31		
Q204	J-31		
Q205	K-13		
Q206	K-28		
Q207	K-28		
Q208	J-28		
Q209	J-28		
Q210	K-26		
Q211	K-6		
Q212	K-27		
Q213	K-27		
Q214	K-7		
Q215	K-27		
Q216	K-26		
Q574	D-21		
Q575	E-23		
Q576	E-23		
Q577	E-22		
Q578	F-22		
Q579	B-10		
Q580	C-10		
Q581	E-23		
Q582	H-22		
Q702	I-13		


VC-85 BOARD (COMPONENT SIDE)




VC-85 BOARD (CONDUCTOR SIDE)









VC-85 BOARD (CONDUCTOR SIDE)







FR-62 BOARD (CONDUCTOR SIDE)



\* A-7062-931-A VC-85 BOARD, COMPLETE  
\*\*\*\*\*  
(Ref. No. 7,000 Series)

A-7068-193-A MX-7PH BOARD, COMPLETE (HIC)

< DIODE >

D101	8-719-404-35 DIODE	MA141WK
D102	8-719-404-35 DIODE	MA141WK
D103	8-719-928-13 DIODE	SLM13DW
D104	8-719-928-13 DIODE	SLM13DW
D105	8-719-404-35 DIODE	MA141WK
D107	8-719-404-46 DIODE	MA110
D108	8-719-404-35 DIODE	MA141WK
D201	8-719-404-46 DIODE	MA110
D202	8-719-404-46 DIODE	MA110
D203	8-719-400-18 DIODE	MA152WK

D575	8-719-800-76 DIODE	1SS226
D576	8-719-404-46 DIODE	MA110
D801	8-719-820-05 DIODE	1SS181
D802	8-719-404-46 DIODE	MA110
D852	8-719-404-46 DIODE	MA110

D901	8-719-404-46 DIODE	MA110
D902	8-719-820-05 DIODE	1SS181

< IC >

IC101	8-759-152-80 IC	uPD750880B-522
IC102	8-759-937-56 IC	S-8054ALB-LM-S
IC103	8-759-926-28 IC	SN74HC174ANS
IC201	8-752-009-51 IC	CX20095A
IC202	8-759-504-47 IC	TL026CPS

IC203	8-759-983-69 IC	LM358PS
IC204	8-759-911-65 IC	MC74HC4053F
IC205	8-759-937-56 IC	S-8054ALB-LM-S
IC207	8-759-502-36 IC	S-81350HG
IC575	8-759-983-69 IC	LM358PS

IC576	8-759-234-77 IC	TC4566F
IC577	8-759-234-77 IC	TC4566F
IC578	8-759-234-77 IC	TC4566F
IC702	8-752-034-21 IC	CXA1339R
IC703	8-759-946-00 IC	MB88341PFV

IC704	8-759-300-71 IC	TC4053BF
IC705	8-752-033-34 IC	CXA1072R
IC706	8-759-946-00 IC	MB88341PFV
IC707	8-759-300-71 IC	TC4053BF
IC708	8-759-300-71 IC	TC4053BF

IC709	8-759-300-71 IC	TC4053BF
IC710	8-759-100-93 IC	uPC393Q2
IC711	8-759-300-71 IC	TC4053BF
IC712	8-759-100-93 IC	uPC393Q2
IC713	8-759-200-67 IC	TC4001BF

IC714	8-759-300-71 IC	TC4053BF
IC715	8-759-100-93 IC	uPC393Q2
IC716	8-759-300-71 IC	TC4053BF
IC717	8-759-300-71 IC	TC4053BF
IC720	8-759-234-77 IC	TC4566F

IC801	8-759-937-56 IC	S-8054ALB-LM-S
IC802	8-759-037-60 IC	MC68HC05N4-SC406667
IC803	8-759-983-74 IC	LM324NS
IC804	8-759-008-67 IC	MC14056BF
IC851	8-759-500-11 IC	MM1036XF

IC852	8-759-983-69 IC	LM358PS
IC853	8-759-030-35 IC	MPC1725M
IC854	8-759-983-74 IC	LM324NS
IC901	8-752-334-49 IC	CXD1172AM
IC902	8-759-946-00 IC	MB88341PFV

IC903	8-759-940-45 IC	S-8054HN-CB
IC904	8-752-326-19 IC	CXD1204R
IC905	8-759-031-86 IC	MC68HC05C4-SC411531
IC906	8-759-300-71 IC	TC4053BF
IC907	8-759-983-74 IC	LM324NS

IC908	8-759-009-06 IC	MC14052BF
-------	-----------------	-----------

< TRANSISTOR >

Q101	8-729-905-18 TRANSISTOR	DTC144EU
Q102	8-729-907-00 TRANSISTOR	DTC114EU
Q103	8-729-907-00 TRANSISTOR	DTC114EU
Q105	8-729-905-18 TRANSISTOR	DTC144EU

Q201	8-729-905-35 TRANSISTOR	2SC4081-R
Q202	8-729-905-35 TRANSISTOR	2SC4081-R
Q203	8-729-905-35 TRANSISTOR	2SC4081-R
Q204	8-729-905-35 TRANSISTOR	2SC4081-R
Q205	8-729-905-35 TRANSISTOR	2SC4081-R
Q206	8-729-905-35 TRANSISTOR	2SC4081-R

Q207	8-729-230-49 TRANSISTOR	2SC2712-YG
Q208	8-729-905-35 TRANSISTOR	2SC4081-R
Q209	8-729-106-60 TRANSISTOR	2SB1115A
Q210	8-729-905-35 TRANSISTOR	2SC4081-R
Q211	8-729-905-23 TRANSISTOR	2SA1576-R

Q212	8-729-402-84 TRANSISTOR	XN4601
Q213	8-729-905-35 TRANSISTOR	2SC4081-R
Q214	8-729-905-23 TRANSISTOR	2SA1576-R
Q215	8-729-905-35 TRANSISTOR	2SC4081-R
Q216	8-729-905-35 TRANSISTOR	2SC4081-R

Q574	8-729-905-35 TRANSISTOR	2SC4081-R
Q575	8-729-905-35 TRANSISTOR	2SC4081-R
Q576	8-729-905-35 TRANSISTOR	2SC4081-R
Q577	8-765-420-02 TRANSISTOR	2SK300-3
Q578	8-729-905-18 TRANSISTOR	DTC144EU

Q579	8-729-905-35 TRANSISTOR	2SC4081-R
Q580	8-729-402-84 TRANSISTOR	XN4601
Q581	8-729-905-18 TRANSISTOR	DTC144EU
Q582	8-729-905-35 TRANSISTOR	2SC4081-R
Q702	8-729-905-23 TRANSISTOR	2SA1576-R

Q703	8-729-905-35 TRANSISTOR	2SC4081-R
Q704	8-729-905-35 TRANSISTOR	2SC4081-R
Q705	8-729-905-35 TRANSISTOR	2SC4081-R
Q706	8-729-402-78 TRANSISTOR	XN4601
Q707	8-729-905-35 TRANSISTOR	2SC4081-R

Q708	8-729-403-10 TRANSISTOR	XN6215
Q709	8-729-905-35 TRANSISTOR	2SC4081-R
Q710	8-729-905-35 TRANSISTOR	2SC4081-R
Q711	8-729-905-35 TRANSISTOR	2SC4081-R
Q712	8-729-402-84 TRANSISTOR	XN4601

Q713	8-729-402-81 TRANSISTOR	XN4501
Q714	8-729-402-84 TRANSISTOR	XN4601
Q715	8-729-905-35 TRANSISTOR	2SC4081-R
Q716	8-729-905-18 TRANSISTOR	DTC144EU
Q717	8-729-905-23 TRANSISTOR	2SA1576-R

Q718	8-729-905-35 TRANSISTOR	2SC4081-R
Q719	8-729-905-35 TRANSISTOR	2SC4081-R
Q720	8-729-905-23 TRANSISTOR	2SA1576-R
Q721	8-729-905-35 TRANSISTOR	2SC4081-R
Q722	8-729-905-23 TRANSISTOR	2SA1576-R

Q723	8-729-905-35 TRANSISTOR	2SC4081-R
Q724	8-729-905-35 TRANSISTOR	2SC4081-R
Q727	8-729-905-23 TRANSISTOR	2SA1576-R
Q728	8-729-905-18 TRANSISTOR	DTC144EU

Q801	8-729-403-10 TRANSISTOR	XN6215
Q802	8-729-403-07 TRANSISTOR	XN1213
Q803	8-729-905-35 TRANSISTOR	2SC4081-R
Q804	8-729-805-42 TRANSISTOR	2SC3859
Q805	8-729-805-42 TRANSISTOR	2SC3859

Q806	8-729-805-42 TRANSISTOR	2SC3859
Q807	8-729-402-78 TRANSISTOR	XN4601
Q851	8-729-403-07 TRANSISTOR	XN1213
Q852	8-729-905-23 TRANSISTOR	2SA1576-R
Q853	8-729-402-84 TRANSISTOR	XN4601

Q854	8-729-106-60 TRANSISTOR	2SB1115A
Q855	8-729-905-35 TRANSISTOR	2SC4081-R
Q856	8-729-905-15 TRANSISTOR	DTC144EU
Q858	8-729-402-84 TRANSISTOR	XN4601
Q859	8-729-905-18 TRANSISTOR	DTC144EU

Q860	8-729-905-18 TRANSISTOR	DTC144EU
Q901	8-729-402-84 TRANSISTOR	XN4601
Q902	8-729-403-10 TRANSISTOR	XN6215
Q903	8-729-905-23 TRANSISTOR	2SA1576-R
Q904	8-729-905-18 TRANSISTOR	DTC144EU

Q906	8-729-905-35 TRANSISTOR	2SC4081-R
Q907	8-729-905-35 TRANSISTOR	2SC4081-R
Q909	8-729-905-35 TRANSISTOR	2SC4081-R
Q910	8-729-905-35 TRANSISTOR	2SC4081-R
Q911	8-729-402-19 TRANSISTOR	XN6501

Q914	8-729-905-18 TRANSISTOR	DTC144EU
Q915	8-729-905-18 TRANSISTOR	DTC144EU
Q916	8-729-905-18 TRANSISTOR	DTC144EU
Q918	8-729-905-18 TRANSISTOR	DTC144EU
Q919	8-729-905-18 TRANSISTOR	DTC144EU

Q920	8-729-402-84 TRANSISTOR	XN4601
------	-------------------------	--------



\* A-7062-931-A VC-85 BOARD, COMPLETE  
\*\*\*\*\*  
(Ref. No. 7, 090 Series)

A-7068-193-A WX-7PH BOARD, COMPLETE (HIC)

< DIODE >

D101	8-719-404-35	DIODE	MA141WK
D102	8-719-404-35	DIODE	MA141WK
D103	8-719-928-13	DIODE	SLM13DW
D104	8-719-928-13	DIODE	SLM13DW
D106	8-719-404-35	DIODE	MA141WK
D107	8-719-404-46	DIODE	MA110
D108	8-719-404-35	DIODE	MA141WK
D201	8-719-404-46	DIODE	MA110
D202	8-719-404-46	DIODE	MA110
D203	8-719-400-18	DIODE	MA152WK

< IC >

IC101	8-759-152-80	IC	uPD75088GB-522
IC102	8-759-937-56	IC	S-8054ALB-LM-S
IC103	8-759-926-28	IC	SN74HC174ANS
IC201	8-752-009-51	IC	CX20095A
IC202	8-759-504-47	IC	TL062CPS
IC203	8-759-983-69	IC	LM358PS
IC204	8-759-011-65	IC	MC174HC053F
IC205	8-759-937-56	IC	S-8054ALB-LM-S
IC207	8-759-502-36	IC	S-81350HG
IC575	8-759-983-69	IC	LM358PS
IC576	8-759-234-77	IC	TC4566F
IC577	8-759-234-77	IC	TC4566F
IC578	8-759-234-77	IC	TC4566F
IC702	8-752-034-21	IC	CXA1339R
IC703	8-759-946-00	IC	MB88341PFV
IC704	8-759-300-71	IC	TC4053BF
IC705	8-752-033-34	IC	CXA1072R
IC706	8-759-946-00	IC	MB88341PFV
IC707	8-759-300-71	IC	TC4053BF
IC708	8-759-300-71	IC	TC4053BF
IC709	8-759-300-71	IC	TC4053BF
IC710	8-759-100-93	IC	uPC393G2
IC711	8-759-300-71	IC	TC4053BF
IC712	8-759-100-93	IC	uPC393G2
IC713	8-759-200-67	IC	TC4001BF
IC714	8-759-300-71	IC	TC4053BF
IC715	8-759-100-93	IC	uPC393G2
IC716	8-759-300-71	IC	TC4053BF
IC717	8-759-300-71	IC	TC4053BF
IC720	8-759-234-77	IC	TC4566F
IC801	8-759-937-56	IC	S-8054ALB-LM-S
IC802	8-759-037-60	IC	MC68HC05N4-SC406667
IC803	8-759-983-74	IC	LM324NS
IC804	8-759-008-87	IC	MC140658F
IC851	8-759-500-11	IC	MM1038XF
IC852	8-759-983-69	IC	LM358PS
IC853	8-759-030-35	IC	MPC1725M
IC854	8-759-983-74	IC	LM324NS
IC901	8-752-334-49	IC	CXD1172AM
IC902	8-759-946-00	IC	MB88341PFV
IC903	8-759-940-45	IC	S-8054HN-CB
IC904	8-752-326-18	IC	CXD1204R
IC905	8-759-031-86	IC	MC68HC05C4-SC411531
IC906	8-759-300-71	IC	TC4053BF
IC907	8-759-983-74	IC	LM324NS
IC908	8-759-009-06	IC	MC14052BF

< TRANSISTOR >

Q101	8-729-905-18	TRANSISTOR	DTC144EU
Q102	8-729-907-00	TRANSISTOR	DTC114EU
Q103	8-729-907-00	TRANSISTOR	DTC114EU
Q105	8-729-905-18	TRANSISTOR	DTC144EU

Q201	8-729-905-35	TRANSISTOR	2SC4081-R
Q202	8-729-905-35	TRANSISTOR	2SC4081-R
Q203	8-729-905-35	TRANSISTOR	2SC4081-R
Q204	8-729-905-35	TRANSISTOR	2SC4081-R
Q205	8-729-905-35	TRANSISTOR	2SC4081-R
Q206	8-729-905-35	TRANSISTOR	2SC4081-R
Q207	8-729-230-49	TRANSISTOR	2SC2712-YG
Q208	8-729-905-35	TRANSISTOR	2SC4081-R
Q209	8-729-106-60	TRANSISTOR	2SB1115A
Q210	8-729-905-35	TRANSISTOR	2SC4081-R
Q211	8-729-905-23	TRANSISTOR	2SA1576-R
Q212	8-729-402-84	TRANSISTOR	XN4601
Q213	8-729-905-35	TRANSISTOR	2SC4081-R
Q214	8-729-985-23	TRANSISTOR	2SA1576-R
Q215	8-729-905-35	TRANSISTOR	2SC4081-R
Q216	8-729-905-35	TRANSISTOR	2SC4081-R
Q574	8-729-905-35	TRANSISTOR	2SC4081-R
Q575	8-729-905-35	TRANSISTOR	2SC4081-R
Q576	8-729-905-35	TRANSISTOR	2SC4081-R
Q577	8-765-420-02	TRANSISTOR	2SK300-3
Q578	8-729-905-18	TRANSISTOR	DTC144EU
Q579	8-729-905-35	TRANSISTOR	2SC4081-R
Q580	8-729-402-84	TRANSISTOR	XN4601
Q581	8-729-905-18	TRANSISTOR	DTC144EU
Q582	8-729-905-35	TRANSISTOR	2SC4081-R
Q702	8-729-905-23	TRANSISTOR	2SA1576-R
Q703	8-729-905-35	TRANSISTOR	2SC4081-R
Q704	8-729-905-35	TRANSISTOR	2SC4081-R
Q705	8-729-905-35	TRANSISTOR	2SC4081-R
Q706	8-729-402-78	TRANSISTOR	XN4601
Q707	8-729-905-35	TRANSISTOR	2SC4081-R
Q708	8-729-403-10	TRANSISTOR	XN6215
Q709	8-729-905-35	TRANSISTOR	2SC4081-R
Q710	8-729-905-35	TRANSISTOR	2SC4081-R
Q711	8-729-905-35	TRANSISTOR	2SC4081-R
Q712	8-729-402-84	TRANSISTOR	XN4601
Q713	8-729-402-81	TRANSISTOR	XN4501
Q714	8-729-402-84	TRANSISTOR	XN4601
Q715	8-729-905-35	TRANSISTOR	2SC4081-R
Q716	8-729-905-18	TRANSISTOR	DTC144EU
Q717	8-729-905-23	TRANSISTOR	2SA1576-R
Q718	8-729-905-35	TRANSISTOR	2SC4081-R
Q719	8-729-905-35	TRANSISTOR	2SC4081-R
Q720	8-729-905-23	TRANSISTOR	2SA1576-R
Q721	8-729-905-35	TRANSISTOR	2SC4081-R
Q722	8-729-905-35	TRANSISTOR	2SC4081-R
Q723	8-729-905-35	TRANSISTOR	2SC4081-R
Q724	8-729-905-35	TRANSISTOR	2SC4081-R
Q727	8-729-905-23	TRANSISTOR	2SA1576-R
Q728	8-729-905-18	TRANSISTOR	DTC144EU
Q801	8-729-403-10	TRANSISTOR	XN6215
Q802	8-729-403-07	TRANSISTOR	XN1213
Q803	8-729-905-35	TRANSISTOR	2SC4081-R
Q804	8-729-805-42	TRANSISTOR	2SC3859
Q805	8-729-805-42	TRANSISTOR	2SC3859
Q806	8-729-805-42	TRANSISTOR	2SC3859
Q807	8-729-402-78	TRANSISTOR	XN6401
Q851	8-729-403-07	TRANSISTOR	XN1213
Q852	8-729-905-23	TRANSISTOR	2SA1576-R
Q853	8-729-402-84	TRANSISTOR	XN4601
Q854	8-729-106-60	TRANSISTOR	2SB1115A
Q855	8-729-905-35	TRANSISTOR	2SC4081-R
Q856	8-729-905-15	TRANSISTOR	DTC144EU
Q858	8-729-402-84	TRANSISTOR	XN4601
Q859	8-729-905-18	TRANSISTOR	DTC144EU
Q860	8-729-905-18	TRANSISTOR	DTC144EU
Q901	8-729-402-84	TRANSISTOR	XN4601
Q902	8-729-403-10	TRANSISTOR	XN6215
Q903	8-729-905-23	TRANSISTOR	2SA1576-R
Q904	8-729-905-18	TRANSISTOR	DTC144EU
Q906	8-729-905-35	TRANSISTOR	2SC4081-R
Q907	8-729-905-35	TRANSISTOR	2SC4081-R
Q909	8-729-905-35	TRANSISTOR	2SC4081-R
Q910	8-729-905-35	TRANSISTOR	2SC4081-R
Q911	8-729-402-19	TRANSISTOR	XN6501
Q914	8-729-905-18	TRANSISTOR	DTC144EU
Q915	8-729-905-18	TRANSISTOR	DTC144EU
Q916	8-729-905-18	TRANSISTOR	DTC144EU
Q918	8-729-905-18	TRANSISTOR	DTC144EU
Q919	8-729-905-18	TRANSISTOR	DTC144EU
Q920	8-729-402-84	TRANSISTOR	XN4601


VC-85 (CAMERA PROCESS, SYSTEM CONTROL), FR-62 (FLUORESCENT DISPLAY) PRINTED WIRING BOARDS

— Ref. No. FR-62 BOARD: 3000 series, VC-85 BOARD: 7000 series —


VC-85 BOARD

D101	E-3	Q703	F-14
D102	F-2	Q704	K-18
D103	E-3	Q705	F-14
D104	G-3	Q706	G-14
D106	E-29	Q707	J-20
D107	F-4	Q708	B-16
D108	E-29	Q709	I-20
D201	K-28	Q710	J-22
D202	K-28	Q711	J-22
D203	I-28	Q712	K-19
D575	F-22	Q713	H-21
D576	F-22	Q714	K-18
D801	A-17	Q715	H-18
D802	A-15	Q716	C-21
D852	A-8	Q717	I-11
D901	H-25	Q718	I-21
D902	H-24	Q719	J-19
		Q720	J-19
		Q721	J-19
		Q722	J-18
		Q723	H-23
		Q724	I-23
		Q725	I-23
		Q727	F-12
		Q728	H-11
		Q734	H-22
		Q801	B-15
		Q802	A-17
		Q803	B-19
		Q804	B-13
		Q805	B-14
		Q806	B-15
		Q807	B-14
		Q851	A-7
		Q852	A-7
		Q853	B-8
		Q854	A-25
		Q855	A-8
		Q856	A-24
		Q858	B-7
		Q859	B-25
		Q860	B-25
		Q901	H-24
		Q902	F-25
		Q903	H-26
		Q904	H-24
		Q906	E-5
		Q907	D-27
		Q909	E-24
		Q910	F-24
		Q911	E-24
		Q914	G-24
		Q915	F-6
		Q916	F-27
		Q918	C-27
		Q919	C-26
		Q920	G-24
IC102	G-28		
IC103	E-4		
IC105	G-4		
IC201	K-30		
IC202	K-24		
IC203	J-25		
IC204	J-26		
IC205	J-28		
IC207	I-29		
IC575	F-22		
IC576	E-22		
IC577	G-23		
IC578	G-23		
IC701	G-13		
IC702	H-19		
IC703	H-18		
IC704	F-19		
IC705	I-21		
IC706	G-21		
IC707	G-17		
IC708	H-17		
IC709	I-18		
IC710	C-16		
IC711	C-15		
IC712	C-13		
IC713	C-12		
IC714	D-14		
IC715	D-13		
IC716	D-12		
IC717	F-20		
IC801	A-16		
IC802	A-18		
IC803	A-20		
IC804	A-13		
IC851	A-6		
IC852	A-8		
IC853	B-24		
IC854	B-26		
IC901	G-27		
IC902	H-26		
IC903	H-7		
IC904	F-27		
IC905	G-6		
IC906	H-8		
IC907	I-6		
IC908	G-8		
Q101	F-4		
Q102	F-3		
Q103	F-3		
Q105	E-28		
Q201	J-2		
Q202	J-2		
Q203	J-31		
Q204	J-31		
Q205	K-13		
Q206	J-28		
Q207	K-28		
Q208	I-28		
Q209	J-28		
Q210	K-26		
Q211	K-6		
Q212	K-27		
Q213	K-27		
Q214	K-7		
Q215	K-27		
Q216	K-26		
Q574	D-21		
Q575	E-23		
Q576	E-23		
Q577	F-22		
Q578	F-22		
Q579	B-10		
Q580	C-10		
Q581	H-23		
Q582	H-22		
Q702	I-13		


VC-85 BOARD (COMPONENT SIDE)









VC-81 BOARD (CONDUCTOR 100)







## VC-85 (CAMERA PROCESS, SYSTEM CONTROL) SCHEMATIC DIAGRAM

— Ref. No. VC-85 BOARD: 7000 series —

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O

1

2

3

4

5

6

7

8

9


10

11

## VC-85 (2/4) BOARD

TO  
GE-10 BOARD  
W603  
(See Page 59)TO  
GE-10 BOARD  
W602  
(See Page 60)TO  
GE-10 BOARD  
W602  
(See Page 60)TO  
DC-DC CONVERTER  
CN2  
(See Page 81)AF CK (4F5C) EB  
WNB EC  
AGC CONT F EB  
Y7 CONT EF  
IRIS OUT EF  
AGC REF EG  
AGC CONT R CN  
PG CONT CU  
V SUB CONT EH  
G  
BRIVE (+) BA  
CONT (+) BB  
CONT (-) BC  
BIAS (+) AA  
HALL (-) AB  
HALL (+) BF  
ZOOM T BG  
ZOOM W BH  
FOCUS N BI  
FOCUS F BJ  
FOCUS ANGB BA  
FOCUS N C BL  
FOCUS F C BHTO VC-85 (4/4)  
BOARD  
(See Page 94, 95)Q574  
BUFFERQ574  
25C4081R573  
470R574  
1KR575  
1KR576  
1KR577  
1KR578  
1KR579  
1KR580  
1KR581  
1KR582  
1KR583  
1KR584  
1KR585  
1KR586  
1KR587  
1KR588  
1KR589  
1KR590  
1KR591  
1KR592  
1KR593  
1KR594  
1KR595  
1KR596  
1KR597  
1KR598  
1KR599  
1KR600  
1KR601  
1KR602  
1KR603  
1KR604  
1KR605  
1KR606  
1KR607  
1KR608  
1KR609  
1KR610  
1KR611  
1KR612  
1KR613  
1KR614  
1KR615  
1KR616  
1KR617  
1KR618  
1KR619  
1KR620  
1KR621  
1KR622  
1KR623  
1KR624  
1KR625  
1KR626  
1KR627  
1KR628  
1KR629  
1KR630  
1KR631  
1KR632  
1KR633  
1KR634  
1KR635  
1KR636  
1KR637  
1KR638  
1KR639  
1KR640  
1KR641  
1KR642  
1KR643  
1KR644  
1KR645  
1KR646  
1KR647  
1KR648  
1KR649  
1KR650  
1KR651  
1KR652  
1KR653  
1KR654  
1KR655  
1KR656  
1KR657  
1KR658  
1KR659  
1KR660  
1KR661  
1KR662  
1KR663  
1KR664  
1KR665  
1KR666  
1KR667  
1KR668  
1KR669  
1KR670  
1KR671  
1KR672  
1KR673  
1KR674  
1KR675  
1KR676  
1KR677  
1KR678  
1KR679  
1KR680  
1KR681  
1KR682  
1KR683  
1KR684  
1KR685  
1KR686  
1KR687  
1KR688  
1KR689  
1KR690  
1KR691  
1KR692  
1KR693  
1KR694  
1KR695  
1KR696  
1KR697  
1KR698  
1KR699  
1KR700  
1KR701  
1KR702  
1KR703  
1KR704  
1KR705  
1KR706  
1KR707  
1KR708  
1KR709  
1KR710  
1KR711  
1KR712  
1KR713  
1KR714  
1KR715  
1KR716  
1KR717  
1KR718  
1KR719  
1KR720  
1KR721  
1KR722  
1KR723  
1KR724  
1KR725  
1KR726  
1KR727  
1KR728  
1KR729  
1KR730  
1KR731  
1KR732  
1KR733  
1KR734  
1KR735  
1KR736  
1KR737  
1KR738  
1KR739  
1KR740  
1KR741  
1KR742  
1KR743  
1KR744  
1KR745  
1KR746  
1KR747  
1KR748  
1KR749  
1KR750  
1KR751  
1KR752  
1KR753  
1KR754  
1KR755  
1KR756  
1KR757  
1KR758  
1KR759  
1KR760  
1KR761  
1KR762  
1KR763  
1KR764  
1KR765  
1KR766  
1KR767  
1KR768  
1KR769  
1KR770  
1KR771  
1KR772  
1KR773  
1KR774  
1KR775  
1KR776  
1KR777  
1KR778  
1KR779  
1KR780  
1KR781  
1KR782  
1KR783  
1KR784  
1KR785  
1KR786  
1KR787  
1KR788  
1KR789  
1KR790  
1KR791  
1KR792  
1KR793  
1KR794  
1KR795  
1KR796  
1KR797  
1KR798  
1KR799  
1KR800  
1KR801  
1KR802  
1KR803  
1KR804  
1KR805  
1KR806  
1KR807  
1KR808  
1KR809  
1KR810  
1KR811  
1KR812  
1KR813  
1KR814  
1KR815  
1KR816  
1KR817  
1KR818  
1KR819  
1KR820  
1KR821  
1KR822  
1KR823  
1KR824  
1KR825  
1KR826  
1KR827  
1KR828  
1KR829  
1KR830  
1KR831  
1KR832  
1KR833  
1KR834  
1KR835  
1KR836  
1KR837  
1KR838  
1KR839  
1KR840  
1KR841  
1KR842  
1KR843  
1KR844  
1KR845  
1KR846  
1KR847  
1KR848  
1KR849  
1KR850  
1KR851  
1KR852  
1KR853  
1KR854  
1KR855  
1KR856  
1KR857  
1KR858  
1KR859  
1KR860  
1KR861  
1KR862  
1KR863  
1KR864  
1KR865  
1KR866  
1K





	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA/DATA	
REC	➡	➡➡		
PB				

— Ref. No. FR-62 BOARD: 3000 series, VC-85 BOARD: 7000 series —

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

**VC-85 (3/4) BOARD****IC202**CHROMA GAIN  
CONTROL  
AMP**IC203**

AMP

**IC204**


SELECTOR

TO  
VC-85 (1/4)  
BOARD  
(See Page 64)



REF 1V AB  
REF 2V AA  
REG 5V AB  
CB ON/OFF AE  
N/P AF  
VB AG  
DBS SI AH  
DBS SO AI  
DBS SCK AJ  
EVR CS AK  
IRIS MANU AL  
FOCUS N AM  
FOCUS F AN  
ZOOM T AO  
ZOOM W AP  
IRIS VR AQ  
GND G  
C OUT AR  
GND G  
Y OUT AS  
BLK AT  
6V AU  
CAM ON AV

CHASSIS GND A

09







• SIGNAL PATH

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA/DATA	
REC	→	→	→	
PB				




## VC-85 (CAMERA PROCESS, SYSTEM CONTROL), FR-62 (FLUORESCENT DISPLAY) PRINTED WIRING BOARDS

— Ref. No. FR-62 BOARD: 3000 series, VC-85 BOARD: 7000 series —


## VC-85 BOARD

D101	E-3	Q703	F-14
D102	F-2	Q704	K-18
D103	E-3	Q705	F-14
D104	G-3	Q706	G-14
D106	E-29	Q707	J-20
D107	F-4	Q708	B-16
D108	E-29	Q709	I-20
D201	K-28	Q710	J-22
D202	K-28	Q711	J-22
D203	I-28	Q712	K-19
D575	F-22	Q713	H-21
D576	F-22	Q714	K-18
D801	A-17	Q715	H-18
D802	A-15	Q716	C-21
D852	A-8	Q717	I-11
D901	H-25	Q718	I-21
D902	H-24	Q719	J-19
IC102	G-28	Q720	J-19
IC103	E-4	Q721	J-19
IC105	G-4	Q722	J-18
IC201	K-30	Q723	H-23
IC202	K-24	Q724	I-23
IC203	J-25	Q725	I-23
IC204	J-26	Q726	F-12
IC205	J-26	Q727	H-11
IC207	I-29	Q728	H-22
IC575	F-22	Q801	B-15
IC576	E-22	Q802	A-17
IC577	G-23	Q803	B-19
IC578	G-23	Q804	B-13
IC701	H-19	Q805	B-14
IC702	H-19	Q806	B-15
IC703	H-18	Q807	B-14
IC704	F-19	Q808	A-7
IC705	I-21	Q809	B-8
IC706	G-21	Q810	A-25
IC707	G-17	Q811	A-8
IC708	H-17	Q812	A-24
IC709	I-18	Q813	B-7
IC710	C-16	Q814	B-25
IC711	C-15	Q815	B-25
IC712	C-13	Q816	H-24
IC713	C-12	Q817	F-25
IC714	D-14	Q818	H-26
IC715	D-13	Q819	H-24
IC716	D-12	Q820	E-5
IC717	F-20	Q821	D-27
IC801	A-16	Q822	E-24
IC802	A-18	Q823	F-24
IC803	A-20	Q824	E-24
IC804	A-13	Q825	G-24
IC851	A-6	Q826	F-6
IC852	A-8	Q827	F-27
IC853	B-24	Q828	C-27
IC854	B-26	Q829	C-26
IC901	G-27	Q830	G-24
IC902	H-26		
IC903	H-7		
IC904	F-27		
IC905	G-6		
IC906	H-8		
IC907	I-6		
IC908	G-8		
Q101	F-4		
Q102	F-3		
Q103	F-3		
Q105	E-28		
Q201	J-2		
Q202	J-2		
Q203	J-31		
Q204	J-31		
Q205	K-13		
Q206	J-28		
Q207	K-28		
Q208	I-28		
Q209	J-28		
Q210	K-26		
Q211	K-6		
Q212	K-27		
Q213	K-27		
Q214	K-7		
Q215	K-27		
Q216	K-26		
Q574	D-21		
Q575	E-23		
Q576	E-23		
Q577	E-22		
Q578	F-22		
Q579	B-10		
Q580	C-10		
Q581	H-23		
Q582	H-22		
Q702	I-13		


## VC-85 BOARD (COMPONENT SIDE)









FR-62 BOARD (CONDUCTOR SIDE)







FR-62 BOARD (CONDUCTOR SIDE)



\* A-7062-931-A VC-85 BOARD, COMPLETE  
\*\*\*\*\*  
(Ref. No 7, 000 Series)

A-7068-193-A MX-7PH BOARD, COMPLETE (NIC)

< DIODE >

D101	8-719-404-35	DIODE	MA141WK
D102	8-719-404-35	DIODE	MA141WK
D103	8-719-928-13	DIODE	SLM13DW
D104	8-719-928-13	DIODE	SLM13DW
D106	8-719-404-35	DIODE	MA141WK
D107	8-719-404-46	DIODE	MA110
D108	8-719-404-35	DIODE	MA141WK
D201	8-719-404-46	DIODE	MA110
D202	8-719-404-46	DIODE	MA110
D203	8-719-400-18	DIODE	MA152WK
D575	8-719-800-76	DIODE	1SS226
D576	8-719-404-46	DIODE	MA110
D801	8-719-820-05	DIODE	1SS181
D802	8-719-404-46	DIODE	MA110
D852	8-719-404-46	DIODE	MA110
D901	8-719-404-46	DIODE	MA110
D902	8-719-820-05	DIODE	1SS181

< IC >

IC101	8-759-152-80	IC	uPD7508BGB-522
IC102	8-759-937-56	IC	S-8054ALB-LM-S
IC103	8-759-976-28	IC	SN74HC174ANS
IC201	8-752-009-51	IC	CX20095A
IC202	8-759-504-47	IC	TL026CPS
IC203	8-759-983-69	IC	LM358PS
IC204	8-759-011-65	IC	MC74HC4053F
IC205	8-759-937-56	IC	S-8054ALB-LM-S
IC207	8-759-502-36	IC	S-8135DHG
IC575	8-759-983-69	IC	LM358PS
IC576	8-759-234-77	IC	TC4566F
IC577	8-759-234-77	IC	TC4566F
IC578	8-759-234-77	IC	TC4566F
IC702	8-752-034-21	IC	CXA1339R
IC703	8-759-946-00	IC	MB88341PFV
IC704	8-759-300-71	IC	TC4053BF
IC705	8-752-033-34	IC	CXA1072R
IC706	8-759-946-00	IC	MB88341PFV
IC707	8-759-300-71	IC	TC4053BF
IC708	8-759-300-71	IC	TC4053BF
IC709	8-759-300-71	IC	TC4053BF
IC710	8-759-100-93	IC	uPC39302
IC711	8-759-300-71	IC	TC4053BF
IC712	8-759-100-93	IC	uPC39302
IC713	8-759-200-67	IC	TC4001BF
IC714	8-759-300-71	IC	TC4053BF
IC715	8-759-100-93	IC	uPC39302
IC716	8-759-300-71	IC	TC4053BF
IC717	8-759-300-71	IC	TC4053BF
IC720	8-759-234-77	IC	TC4566F
IC801	8-759-937-56	IC	S-8054ALB-LM-S
IC802	8-759-037-60	IC	MC68HC05N4-SC406667
IC803	8-759-983-74	IC	LM324NS
IC804	8-759-008-67	IC	MC14066BF
IC851	8-759-500-11	IC	MM1036XF
IC852	8-759-983-69	IC	LM358PS
IC853	8-759-030-35	IC	MPC1725M
IC854	8-759-983-74	IC	LM324NS
IC901	8-752-334-49	IC	CXD1172AM
IC902	8-759-946-00	IC	MB88341PFV
IC903	8-759-940-45	IC	S-8054HN-CB
IC904	8-752-326-18	IC	CXD1204R
IC905	8-759-031-86	IC	MC68HC05C4-SC411531
IC906	8-759-300-71	IC	TC4053BF
IC907	8-759-983-74	IC	LM324NS
IC908	8-759-009-06	IC	MC14052BF

< TRANSISTOR >

Q101	8-729-905-18	TRANSISTOR	DTC144EU
Q102	8-729-907-00	TRANSISTOR	DTC114EU
Q103	8-729-907-00	TRANSISTOR	DTC114EU
Q105	8-729-905-18	TRANSISTOR	DTC144EU

Q201	8-729-905-35	TRANSISTOR	2SC4081-R
Q202	8-729-905-35	TRANSISTOR	2SC4081-R
Q203	8-729-905-35	TRANSISTOR	2SC4081-R
Q204	8-729-905-35	TRANSISTOR	2SC4081-R
Q205	8-729-905-35	TRANSISTOR	2SC4081-R
Q206	8-729-905-35	TRANSISTOR	2SC4081-R
Q207	8-729-230-49	TRANSISTOR	2SC2712-VG
Q208	8-729-905-35	TRANSISTOR	2SC4081-R
Q209	8-729-106-60	TRANSISTOR	2SB1115A
Q210	8-729-905-35	TRANSISTOR	2SC4081-R
Q211	8-729-905-23	TRANSISTOR	2SA1576-R
Q212	8-729-402-84	TRANSISTOR	XN4601
Q213	8-729-905-35	TRANSISTOR	2SC4081-R
Q214	8-729-905-23	TRANSISTOR	2SA1576-R
Q215	8-729-905-35	TRANSISTOR	2SC4081-R
Q216	8-729-905-35	TRANSISTOR	2SC4081-R
Q574	8-729-905-35	TRANSISTOR	2SC4081-R
Q575	8-729-905-35	TRANSISTOR	2SC4081-R
Q576	8-729-905-35	TRANSISTOR	2SC4081-R
Q577	8-765-420-02	TRANSISTOR	2SK300-3
Q578	8-729-905-18	TRANSISTOR	DTC144EU
Q579	8-729-905-35	TRANSISTOR	2SC4081-R
Q580	8-729-402-84	TRANSISTOR	XN4601
Q581	8-729-905-18	TRANSISTOR	DTC144EU
Q582	8-729-905-35	TRANSISTOR	2SC4081-R
Q702	8-729-905-23	TRANSISTOR	2SA1576-R
Q703	8-729-905-35	TRANSISTOR	2SC4081-R
Q704	8-729-905-35	TRANSISTOR	2SC4081-R
Q705	8-729-905-35	TRANSISTOR	2SC4081-R
Q706	8-729-402-78	TRANSISTOR	XN4601
Q707	8-729-905-35	TRANSISTOR	2SC4081-R
Q708	8-729-403-10	TRANSISTOR	XN6215
Q709	8-729-905-35	TRANSISTOR	2SC4081-R
Q710	8-729-905-35	TRANSISTOR	2SC4081-R
Q711	8-729-905-35	TRANSISTOR	2SC4081-R
Q712	8-729-402-84	TRANSISTOR	XN4601
Q713	8-729-402-81	TRANSISTOR	XN4601
Q714	8-729-402-84	TRANSISTOR	XN4601
Q715	8-729-905-35	TRANSISTOR	2SC4081-R
Q716	8-729-905-18	TRANSISTOR	DTC144EU
Q717	8-729-905-23	TRANSISTOR	2SA1576-R
Q718	8-729-905-35	TRANSISTOR	2SC4081-R
Q719	8-729-905-35	TRANSISTOR	2SC4081-R
Q720	8-729-905-23	TRANSISTOR	2SA1576-R
Q721	8-729-905-35	TRANSISTOR	2SC4081-R
Q722	8-729-905-23	TRANSISTOR	2SA1576-R
Q723	8-729-905-35	TRANSISTOR	2SC4081-R
Q724	8-729-905-35	TRANSISTOR	2SC4081-R
Q727	8-729-905-23	TRANSISTOR	2SA1576-R
Q728	8-729-905-18	TRANSISTOR	DTC144EU
Q801	8-729-403-10	TRANSISTOR	XN6215
Q802	8-729-403-07	TRANSISTOR	XN1213
Q803	8-729-905-35	TRANSISTOR	2SC4081-R
Q804	8-729-805-42	TRANSISTOR	2SC3859
Q805	8-729-805-42	TRANSISTOR	2SC3859
Q806	8-729-805-42	TRANSISTOR	2SC3859
Q807	8-729-402-78	TRANSISTOR	XN4601
Q851	8-729-403-07	TRANSISTOR	XN1213
Q852	8-729-905-23	TRANSISTOR	2SA1576-R
Q853	8-729-402-84	TRANSISTOR	XN4601
Q854	8-729-106-60	TRANSISTOR	2SB1115A
Q855	8-729-905-35	TRANSISTOR	2SC4081-R
Q856	8-729-905-15	TRANSISTOR	DTC144EU
Q858	8-729-402-84	TRANSISTOR	XN4601
Q859	8-729-905-18	TRANSISTOR	DTC144EU
Q860	8-729-905-18	TRANSISTOR	DTC144EU
Q901	8-729-402-84	TRANSISTOR	XN4601
Q902	8-729-403-10	TRANSISTOR	XN6215
Q903	8-729-905-23	TRANSISTOR	2SA1576-R
Q904	8-729-905-18	TRANSISTOR	DTC144EU
Q906	8-729-905-35	TRANSISTOR	2SC4081-R
Q907	8-729-905-35	TRANSISTOR	2SC4081-R
Q909	8-729-905-35	TRANSISTOR	2SC4081-R
Q910	8-729-905-35	TRANSISTOR	2SC4081-R
Q911	8-729-402-19	TRANSISTOR	XN6501
Q914	8-729-905-18	TRANSISTOR	DTC144EU
Q915	8-729-905-18	TRANSISTOR	DTC144EU
Q916	8-729-905-18	TRANSISTOR	DTC144EU
Q918	8-729-905-18	TRANSISTOR	DTC144EU
Q919	8-729-905-18	TRANSISTOR	DTC144EU
Q920	8-729-402-84	TRANSISTOR	XN4601



\*\*\*\*\*

(Ref. No. 7.000 Series)

A-7068-193-A MX-7PH BOARD, COMPLETE (HIC)

D101	8-719-404-35	DIODE	MA141WK
D102	8-719-404-35	DIODE	MA141WK
D103	8-719-928-13	DIODE	SLM13DW
D104	8-719-928-13	DIODE	SLM13DW
D106	8-719-404-35	DIODE	MA141WK
D107	8-719-404-46	DIODE	MA110
D108	8-719-404-35	DIODE	MA141WK
D201	8-719-404-46	DIODE	MA110
D202	8-719-404-46	DIODE	MA110
D203	8-719-400-18	DIODE	MA152WK

< 10 >

IC101	8-759-152-80	IC	uPD75088GB-522
IC102	8-759-937-56	IC	S-8054ALB-LM-S
IC103	8-759-926-28	IC	SN74HC174ANS
IC201	8-752-009-51	IC	CX20095A
IC202	8-759-504-47	IC	TL06CPS
IC203	8-759-983-69	IC	LM358PS
IC204	8-759-011-65	IC	MC74HC4053F
IC205	8-759-937-56	IC	S-8054ALB-LM-S
IC207	8-759-502-36	IC	S-81350HD
IC575	8-750-833-69	IC	LM358PS

IC576	8-759-234-77	IC	TC4S66F
IC577	8-759-234-77	IC	TC4S66F
IC578	8-759-234-77	IC	TC4S66F
IC702	8-752-034-21	IC	CXA1339R
IC703	8-759-946-00	IC	MB88341PFV

IC704	8-759-300-71	1C	TC4053BF
IC705	8-752-033-34	1C	CXA1072R
IC706	8-759-846-00	1C	MB88341PFV
IC707	8-759-300-71	1C	TC4053BF
IC708	8-759-300-71	1C	TC4053BF

IC709	8-759-300-71	IC	TC4053BF
IC710	8-759-100-93	IC	uPC393G2
IC711	8-759-300-71	IC	TC4053BF
IC712	8-759-100-93	IC	uPC393G2
IC713	8-759-200-67	IC	TC4001BF

IC714	8-759-300-71	IC	TC4053BF
IC715	8-759-100-93	IC	uPC393G2
IC716	8-759-300-71	IC	TC4053BF
IC717	8-759-300-71	IC	TC4053BF
IC720	8-759-234-77	IC	TC4S66F

IC801	8-759-937-56	IC	S-8054ALB-LM-S
IC802	8-759-037-60	IC	MC68HC05N4-SC406661
IC803	8-759-983-74	IC	LM324NS
IC804	8-759-008-67	IC	MC14066BF
IC851	8-759-500-11	IC	MM1036XF

IC852	8-759-983-69	IC	LM358PS
IC853	8-759-030-35	IC	MPC1725M
IC854	8-759-983-74	IC	LM324NS
IC901	8-752-334-49	IC	CXD1172AM
IC902	8-759-946-00	IC	MB88341PFV

IC903	8-759-940-45	IC	S-8054HN-CB
IC904	8-752-326-18	IC	CXD1204R
IC905	8-759-031-86	IC	MC68HC05C4-SC41153
IC906	8-759-300-71	IC	TC4053BF
IC907	8-759-983-74	IC	LM324NS

IC908 8-759-009-06 IC MC14052BF

< TRANSISTOR >

## &lt; TRANSISTOR &gt;

Q101	8-729-905-18	TRANSISTOR	DTC144EU
Q102	8-729-907-00	TRANSISTOR	DTC114EU
Q103	8-729-907-00	TRANSISTOR	DTC114EU
Q105	8-729-905-18	TRANSISTOR	DTC144EU

Q201	8-729-905-35	TRANSISTOR	2SC4081-R
Q202	8-729-905-35	TRANSISTOR	2SC4081-R
Q203	8-729-905-35	TRANSISTOR	2SC4081-R
Q204	8-729-905-35	TRANSISTOR	2SC4081-R
Q205	8-729-905-35	TRANSISTOR	2SC4081-R
Q206	8-729-905-35	TRANSISTOR	2SC4081-R

Q207	8-729-230-49	TRANSISTOR	2SC2712-YC
Q208	8-729-905-35	TRANSISTOR	2SC4081-R
Q209	8-729-106-60	TRANSISTOR	2SB1115A
Q210	8-729-905-35	TRANSISTOR	2SC4081-R
Q211	8-729-905-23	TRANSISTOR	2SA1576-R

Q212	8-729-402-84	TRANSISTOR	XN4601
Q213	8-729-905-35	TRANSISTOR	2SC4081-R
Q214	8-729-905-23	TRANSISTOR	2SA1576-R
Q215	8-729-905-35	TRANSISTOR	2SC4081-R
Q216	8-729-905-35	TRANSISTOR	2SC4081-R

Q574	8-729-905-35	TRANSISTOR	2SC4081-R
Q575	8-729-905-35	TRANSISTOR	2SC4081-R
Q576	8-729-905-35	TRANSISTOR	2SC4081-R
Q577	8-765-420-02	TRANSISTOR	2SK300-3
Q578	8-729-905-18	TRANSISTOR	DTC144EU

Q579	8-729-905-35	TRANSISTOR	2SC4081-R
Q580	8-729-402-84	TRANSISTOR	XN4601
Q581	8-729-905-18	TRANSISTOR	DTC144EU
Q582	8-729-905-35	TRANSISTOR	2SC4081-R
Q702	8-729-905-23	TRANSISTOR	2SA1576-R

Q703	8-729-905-35	TRANSISTOR	2SC4081-R
Q704	8-729-905-35	TRANSISTOR	2SC4081-R
Q705	8-729-905-35	TRANSISTOR	2SC4081-R
Q706	8-729-402-78	TRANSISTOR	XM6401
Q707	8-729-905-35	TRANSISTOR	2SC4081-R

Q708	8-729-403-10	TRANSISTOR	XN6215
Q709	8-729-905-35	TRANSISTOR	2SC4081-R
Q710	8-729-905-35	TRANSISTOR	2SC4081-R
Q711	8-729-905-35	TRANSISTOR	2SC4081-R
Q712	8-729-402-84	TRANSISTOR	XN4601

Q713	8-729-402-81	TRANSISTOR	XN4501
Q714	8-729-402-84	TRANSISTOR	XN4601
Q715	8-729-905-35	TRANSISTOR	2SC4081-R
Q716	8-729-905-18	TRANSISTOR	DTC144EU
Q717	8-729-905-73	TRANSISTOR	2SA1576-R

Q718	8-729-905-35	TRANSISTOR	2SC4081-R
Q719	8-729-905-35	TRANSISTOR	2SC4081-R
Q720	8-729-905-23	TRANSISTOR	2SA1576-R
Q721	8-729-905-35	TRANSISTOR	2SC4081-R
Q722	8-729-905-23	TRANSISTOR	2SA1576-R

Q723	8-729-905-35	TRANSISTOR	2SC4081-R
Q724	8-729-905-35	TRANSISTOR	2SC4081-R
Q727	8-729-905-23	TRANSISTOR	2SA1576-R
Q728	8-729-905-18	TRANSISTOR	DTC144EU

Q801	8-729-403-10	TRANSISTOR	XN6215
Q802	8-729-403-07	TRANSISTOR	XN1213
Q803	8-729-905-35	TRANSISTOR	2SC4081-R
Q804	8-729-805-42	TRANSISTOR	2SC3859
Q805	8-729-805-42	TRANSISTOR	2SC3859

Q806	8-729-805-42	TRANSISTOR	2SC3859
Q807	8-729-402-78	TRANSISTOR	XN6401
Q851	8-729-403-07	TRANSISTOR	XN1213
Q852	8-729-905-23	TRANSISTOR	2SA1576-R
Q853	8-729-402-84	TRANSISTOR	XN4601

Q854	8-729-106-60	TRANSISTOR	2SB1115A
Q855	8-729-905-35	TRANSISTOR	2SC4081-R
Q856	8-729-905-15	TRANSISTOR	DTC144WU
Q858	8-729-402-84	TRANSISTOR	XA6001
Q859	8-729-905-18	TRANSISTOR	DTC144EU

Q860	8-729-905-18	TRANSISTOR	DTC144EU
Q901	8-729-402-84	TRANSISTOR	XN4601
Q902	8-729-403-10	TRANSISTOR	XN6215
Q903	8-729-905-23	TRANSISTOR	2SA1576-R
Q904	8-729-905-18	TRANSISTOR	DTC144EU

Q906	8-729-905-35	TRANSISTOR	2SC4081-R
Q907	8-729-905-35	TRANSISTOR	2SC4081-R
Q909	8-729-905-35	TRANSISTOR	2SC4081-R
Q910	8-729-905-35	TRANSISTOR	2SC4081-R
Q911	8-729-402-19	TRANSISTOR	XM6501

Q914	8-729-905-18	TRANSISTOR	DTC144EU
Q915	8-729-905-18	TRANSISTOR	DTC144EU
Q916	8-729-905-18	TRANSISTOR	DTC144EU
Q918	8-729-905-18	TRANSISTOR	DTC144EU
Q919	8-729-905-18	TRANSISTOR	DTC144EU

Q920 8-729-402-84 TRANSISTOR XN4601

— Ref. No. FR-62 BOARD: 3000 series, VC-85 BOARD: 7000 series —


## VC-85 BOARD

D101	E-3
D102	F-2
D103	E-3
D104	G-3
D106	E-29
D107	F-4
D108	E-29
D201	K-28
D202	K-28
D203	I-28
D575	F-22
D576	F-22
D801	A-17
D802	A-15
D852	A-8
D901	H-25
D902	H-24


C102	G-28
C103	E-4
C105	G-4
C201	K-30
C202	K-24
C203	J-25
C204	J-26
C205	J-28
C207	I-29
C575	F-22
C576	E-22
C577	G-23
C578	G-23
C701	G-13
C702	H-19
C703	H-18
C704	F-19
C705	I-21
C706	G-21
C707	G-17
C708	H-17
C709	I-18
C710	C-16
C711	C-15
C712	C-13
C713	C-12
C714	D-14
C715	D-13
C716	D-12
C717	F-20
C801	A-16
C802	A-18
C803	A-20
C804	A-13
C851	A-6
C852	A-8
C853	B-24
C854	B-26
C901	G-27
C902	H-26
C903	H-7
C904	F-27
C905	G-6
C906	H-8
C907	I-6
C908	G-8

Q101	F-4
Q102	T-3
Q103	T-3
Q105	F-28
Q201	F-2
Q202	J-21
Q203	J-21
Q204	J-31
Q205	K-13
Q206	J-28
Q207	K-28
Q208	I-28
Q209	J-28
Q210	K-26
Q211	K-6
Q212	K-27
Q213	K-27
Q214	K-7
Q215	K-27
Q216	K-26
Q574	D-21
Q575	F-23
Q576	F-23
Q577	F-22
Q578	F-22
Q579	B-10
Q580	O-10
Q581	H-23
Q582	H-22
Q702	I-13



## VC-85 BOARD (COMPONENT SIDE)












VC-85 (CAMERA PROCESS, SYSTEM CONTROL) SCHEMATIC DIAGRAM

— Ref. No. VC-85 BOARD: 7000 series —

(See Page 76, 77)

TO VC-85 (2/4) BOARD

VC-85 (4/4) BOARD






(See Page 76, 77)

TO VC - 85 (2/4) BOARD

(See Page 61)

(See Page 76, 77)


TO VC-85 (2/4) BOARD





(See Page 76, 77)

TO VC-85 (2/4) BOARD



MC-65 (MIC AMPLIFIER), FA-1 (FUNCTION SWITCH), PJ-43 (OUTPUT CONNECTOR), JS-22 (COLOR CORRECT CONTROL) PRINTED WIRING BOARDS

— Ref. No. FA-1 BOARD: 2000 series, JS-22 BOARD: 5000 series, PJ-43 BOARD: 6000 series, MC-65 BOARD: 8000 series —

\* A-7062-932-A MC-65 BOARD, COMPLETE  
\*\*\*\*\*  
(Ref. No 8,000 Series)

< DIODE >

D005	8-719-420-15 DIODE	MA8082-M
D006	8-719-420-15 DIODE	MA8082-M
D261	8-719-404-46 DIODE	MA110
D262	8-719-404-46 DIODE	MA110

< IC >

IC206	8-759-981-58 IC RC2043M-D
-------	---------------------------


< TRANSISTOR >

Q261	8-729-905-35 TRANSISTOR	2SC4081-R
Q262	8-729-905-12 TRANSISTOR	DTA144EU
Q263	8-729-920-XX TRANSISTOR	DTA114EU
Q264	8-729-905-18 TRANSISTOR	DTC144EU


MC-65 BOARD

D005	F-2
D006	H-4
D261	B-4
D262	B-5
IC206	C-4
Q261	B-5
Q262	B-5
Q263	B-4
Q264	B-4


MC-65 BOARD (COMPONENT SIDE)




MC-65 BOARD (CONDUCTOR SIDE)



PJ-43 BOARD (CONDUCTOR SIDE)



FA-1 BOARD (COMPONENT SIDE)




\* A-7062-935-A PJ-43 BOARD, COMPLETE  
\*\*\*\*\*  
(Ref. No 6,000 Series)


< DIODE >

D001	8-719-800-76	DIODE	1SS226
D002	8-719-800-76	DIODE	1SS226
D003	8-719-800-76	DIODE	1SS226
D004	8-719-106-43	DIODE	RD9. 1M-B1
D007	8-719-106-43	DIODE	RD9. 1M-B1
D008	8-719-106-43	DIODE	RD9. 1M-B1
D009	8-719-106-43	DIODE	RD9. 1M-B1
D010	8-719-106-43	DIODE	RD9. 1M-B1
D011	8-719-106-43	DIODE	RD9. 1M-B1
D012	8-719-106-43	DIODE	RD9. 1M-B1
D013	8-719-106-43	DIODE	RD9. 1M-B1
D014	8-719-106-43	DIODE	RD9. 1M-B1


CONDUCTOR SIDE)




PJ-43 BOARD (CONDUCTOR SIDE)



NENT SIDE)



FA-1 BOARD (CONDUCTOR SIDE)






PJ-43 BOARD, COMPLETE  
 \*\*\*\*\*  
 (Ref.No 6,000 Series)


< DIODE >

-800-76 DIODE 1SS226  
 -800-76 DIODE 1SS226  
 -800-76 DIODE 1SS226  
 -106-43 DIODE RD9.1M-B1  
 -106-43 DIODE RD9.1M-B1  
 -106-43 DIODE RD9.1M-B1  
 -106-43 DIODE RD9.1M-B1  
 -106-43 DIODE RD9.1M-B1  
 -106-43 DIODE RD9.1M-B1  
 -106-43 DIODE RD9.1M-B1  
 -106-43 DIODE RD9.1M-B1  
 -106-43 DIODE RD9.1M-B1


ARD (CONDUCTOR SIDE)



JS-22 BOARD (COMPONENT SIDE)



FA-1 BOARD (CONDUCTOR SIDE)



\* A-7062-933-A FA-1 BOARD, COMPLETE  
 \*\*\*\*\*  
 (Ref.No 2,000 Series)

< DIODE >

D105 8-719-928-13 DIODE SLM13DW  
 D151 8-719-404-46 DIODE MA110  
 D152 8-719-404-46 DIODE MA110  
 D153 8-719-404-46 DIODE MA110  
 D171 8-719-404-46 DIODE MA110

< IC >

IC151 8-759-234-77 IC TC4S66F

< TRANSISTOR >

Q104 8-729-907-00 TRANSISTOR DTC114EU  
 Q151 8-729-905-18 TRANSISTOR DTC144EU  
 Q171 8-729-106-60 TRANSISTOR 2SB1115A  
 Q172 8-729-905-18 TRANSISTOR DTC144EU

**A** —  
**B** —  
**C** —  
**D** —  
**E** —  
**F** —  
**G** —  
**H** —  
**I** —  
**J** —



- SIGNAL PATH**


	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA/DATA	
REC	➡	➡➡	➡➡➡	
PB				




## POWER BLOCK (POWER) PRINTED WIRING BOARD

— Ref. No. POWER BLOCK BOARD: 9000 series —

【POWER BLOCK】(A)(CONDUCTOR SIDE)



【POWER BLOCK】(B)(CONDUCTOR SIDE)



1-413-623-21 POWER BLOCK BOARD

\*\*\*\*\*

(Ref. No 9,000 Series)

< DIODE >

D001	8-719-510-06	DIODE	SIW860
D002	9-998-444-01	DIODE	1SS178
D101	8-719-948-59	DIODE	ERB93-02
D102	9-998-446-01	DIODE	RD15ESAB
D201	8-719-510-37	DIODE	D5LC20U
D202	9-998-444-01	DIODE	1SS178
D203	9-998-444-01	DIODE	1SS178
D204	9-998-444-01	DIODE	1SS178
D205	9-998-448-01	DIODE	RD6.8ESAB
D206	9-900-656-01	DIODE	RD15FB2

< IC >


IC001	8-749-920-45	IC	MA1050
IC101	9-998-450-01	IC	NJM431L
IC201	8-759-135-80	IC	uPC358C

< TRANSISTOR >

Q201	9-998-454-01	TRANSISTOR	2SA1307
Q202	9-998-455-01	TRANSISTOR	2SC1815
Q203	9-998-455-01	TRANSISTOR	2SC1815


POWER BLOCK (POWER) SCHEMATIC DIAGRAM

— Ref. No. POWER BLOCK BOARD: 9000 series —




4-3. SEMICONDUCTORS


CXA1072R  
CXA1339R  
CXD1204R  
MC68HC05N4-SC406667




CXD1159Q




CXD1172AM  
HD14053BFP  
SN74HC174ANS  
TC4053BF




CX20095A  
HD14066BFP  
MC14066BF  
TC4001BF




HD14052BFP  
MC14052BF  
MC14053BF  
MC74HC4053F  
MPC1725M  
TC4053BF




LM324NS  
LM358PS  
RC2043M-D  
μPC393G2




MB88341PFV




MM1036XF  
TL026CPS




SC14S66F  
TC4S66F




S-8054ALB-LM-S  
S-8054HN-CB




S-81350HG




μPD7508BGB-522




DTA114EU  
2SA1576-R  
2SC2712-YG  
2SC3859  
2SC4081-R




DTA144EU  
DTC114EU  
DTC144EU  
DTC144WU




XN1213  
XN1216




XN1401




XN4501




XN4601




XN6215  
XN6501




XN6401




2SB1115A




2SK300-3




MA110




MA141WK  
MA152WK




MA8082-M




RD9.1M-B1




1SS226



1SS181



1T32





## SECTION 5 EXPLODED VIEWS


### NOTE:

- -XX, -X mean standardized parts, so they may have some difference from the original one.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list is given in the last of this parts list.

The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

### 5-1. CABINET






Ref. No.	Part No.	Description	Remark
1	3-719-381-11	SCREW (M2X5)	
2	X-3940-410-1	CABINET ASSY, TOP	
3	X-3940-474-1	KNOB ASSY, DIAL	
4	3-941-663-11	CABINET (MID)	
5	X-3940-418-1	GUIDE ASSY, FILM	
6	X-3941-084-1	PANEL ASSY, FRONT	
7	3-941-844-11	BUTTON, FOCUS SW	
8	3-941-844-01	BUTTON, SW	
9	X-3940-767-1	CABINET ASSY, REAR	



Ref. No.	Part No.	Description	Remark
10	X-3940-419-1	CABINET ASSY, BOTTOM	
11	3-941-861-01	FOOT, RUBBER	
12	* 3-945-014-01	LABEL, MODEL NUMBER (AEP)	
12	* 3-945-497-01	LABEL, MODEL NUMBER (E)	
13	3-942-084-01	KNOB, CAP	
14	3-703-713-21	STICKER, SONY SYMBOL (10)	
15	3-724-511-01	SHOE, ACCESSORY	
16	3-839-335-01	CUSHION	





## 5-2. CHASSIS




The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

Ref. No.	Part No.	Description	Remark
51	X-3940-413-1	COVER ASSY, FLUORESCENT LAMP	
52	X-3940-360-1	CASE ASSY, LIGHT	
53	1-518-679-11	FLUORESCENT TUBE	
54	* A-7071-500-A	FR-62 BOARD, COMPLETE	
55	* X-3940-409-1	GUARD ASSY, LAMP	
56	 1-466-504-21	INVERTER, DC-AC	
57	3-943-578-01	PLATE, LIGHT INTERCEPTION	
58	3-831-441-11	CUSHION	
59	* A-7062-933-A	FA-1 BOARD, COMPLETE	
60	3-941-860-01	KNOB, JOY STICK	
61	3-941-858-01	BLIND, JOY STICK	
62	* A-7062-934-A	JS-22 BOARD, COMPLETE	
63	1-466-230-21	CONVERTER UNIT, D/D	
64	 1-555-795-00	CORD, POWER, EULO PLUG	
65	* A-7062-935-A	PJ-43 BOARD, COMPLETE	

Ref. No.	Part No.	Description	Remark
66	 1-413-623-21	POWER BLOCK	
67	3-941-676-01	KNOB, MICROPHONE	
68	* A-7062-932-A	MC-65 BOARD, COMPLETE	
69	* X-3940-541-1	SHIELD (UPPER) ASSY, VOL PCB	
70	3-941-851-11	PANEL (MICROPHONE JACK)	
71	A-7068-193-A	MX-7PH BOARD, COMPLETE (HIC)	
72	* A-7062-931-A	VC-85 BOARD, COMPLETE	
73	3-942-525-01	BLIND (1), KNOB	
74	3-941-670-01	KNOB, ROTARY	
75	X-3941-083-1	PANEL ASSY, SIDE	
76	3-831-441-XX	CUSHION (5)	
77	X-3941-082-1	FRAME ASSY, T	
78	1-641-286-11	FP-480 FLEXIBLE BOARD (AEP)	
S901	 1-572-810-11	SWITCH, SEESAW (AC POWER)	

### 5-3. LENS



Ref. No.	Part No.	Description	Remark
101	* A-7062-930-A	GE-10 BOARD, COMPLETE	
102	* X-3739-811-1	PLATE ASSY, SHIELD, CD	
103	A-7068-165-A	DT-77B BOARD, COMPLETE (HIC)	
104	3-747-151-01	SCREW (2X16)	
105	1-638-487-11	FP-412 FLEXIBLE BOARD	
106	1-638-486-11	FP-378 FLEXIBLE BOARD	
107	* A-7062-929-A	CD-52 BOARD, COMPLETE	
108	* 3-725-175-01	STOPPER, CCD	
109	* 3-725-177-01	RUBBER, SEAL	
110	1-547-381-12	FILTER BLOCK, OPTICAL	
111	3-738-519-11	SCREW (M2X3), +B	
112	3-942-011-01	HOLDER (2), FP	
113	3-941-850-01	ROLLER (SLIDE)	

Ref. No.	Part No.	Description	Remark
114	3-941-664-01	SLIDE (HOLDER)	
115	3-941-841-01	SPRING (2), COMPRESSION	
116	1-547-480-11	LENS, ZOOM	
117	3-727-903-01	SCREW (2X5), TAPPING, + B	
118	X-3940-515-1	LENS (BL) (A) ASSY	
119	X-3940-514-1	LENS (BL) (B) ASSY	
120	X-3940-516-1	GEAR ASSY	
121	3-943-257-01	LENS (BL) (B)	
122	3-831-441-XX	CUSHION (5)	
123	3-725-176-11	HOLDER, CCD	
124	* 3-701-822-00	HOLDER, WIRE	
IC601	8-752-604-70	IC ICX039AN-1 (CCD IMAGER)	

### SECTION 6 ELECTRICAL PARTS LIST

#### NOTE:

The components identified by mark  $\Delta$  or dotted line with mark  $\Delta$  are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS  
All resistors are in ohms  
METAL: Metal-film resistor  
METAL OXIDE: Metal Oxide-film resistor  
F: nonflammable

- Items marked "\*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS  
In each case, u:  $\mu$ , for example:  
uA...:  $\mu$ A..., uPA...:  $\mu$ PA...,  
uPB...:  $\mu$ PB..., uPC...:  $\mu$ PC...,  
uPD...:  $\mu$ PD...
- CAPACITORS  
uF:  $\mu$ F
- COILS  
uH:  $\mu$ H

Ref. No.	Part No.	Description	Remark
	* A-7062-929-A	CD-52 BOARD, COMPLETE ***** (Ref. No 1,000 Series)	
< CAPACITOR >			
C601	1-126-200-11	ELECT CHIP 10uF 20% 35V	
C602	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C604	1-135-091-00	TANTALUM CHIP 1uF 20% 16V	
C605	1-126-607-11	ELECT CHIP 47uF 20% 4V	
C607	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V	
C622	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V	
C626	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C643	1-126-193-11	ELECT 1uF 20% 50V	
C644	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C647	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C648	1-164-005-11	CERAMIC CHIP 0.47uF 25V	
C649	1-126-602-11	ELECT CHIP 3.3uF 20% 50V	
< CONNECTOR >			
CN602	* 1-569-077-11	CONNECTOR, BOARD TO BOARD (F) 18P	
< DIODE >			
D623	8-719-404-46	DIODE MA110	
D624	8-719-820-05	DIODE 1SS181	
D627	8-719-800-76	DIODE 1SS226	
D628	8-719-404-46	DIODE MA110	
< COIL >			
L601	1-412-032-11	INDUCTOR, CHIP 100uH	
< TRANSISTOR >			
Q601	8-765-420-02	TRANSISTOR 2SK300-3	
Q622	8-729-403-42	TRANSISTOR XN1401	

Ref. No.	Part No.	Description	Remark
Q623	8-729-421-23	TRANSISTOR XN1216	
Q625	8-729-905-35	TRANSISTOR 2SC4081-R	
Q626	8-729-402-84	TRANSISTOR XN4601	
< RESISTOR >			
R601	1-216-848-11	METAL CHIP 180K 5% 1/16W	
R602	1-216-838-11	METAL CHIP 27K 5% 1/16W	
R603	1-216-816-11	METAL CHIP 390 5% 1/16W	
R604	1-216-809-11	METAL CHIP 100 5% 1/16W	
R605	1-216-828-11	METAL CHIP 3.9K 5% 1/16W	
R622	1-216-857-11	METAL CHIP 1M 5% 1/16W	
R625	1-216-845-11	METAL CHIP 100K 5% 1/16W	
R628	1-216-843-11	METAL CHIP 68K 5% 1/16W	
R629	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R630	1-216-835-11	METAL CHIP 15K 5% 1/16W	
R631	1-216-844-11	METAL CHIP 82K 5% 1/16W	
R632	1-216-844-11	METAL CHIP 82K 5% 1/16W	
R633	1-216-850-11	METAL CHIP 270K 5% 1/16W	
R636	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R638	1-216-836-11	METAL CHIP 18K 5% 1/16W	
R639	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R640	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R669	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R671	1-216-845-11	METAL CHIP 100K 5% 1/16W	
R680	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R693	1-216-821-11	METAL CHIP 1K 5% 1/16W	

\*\*\*\*\*

**FA-1****FR-62****GE-10****DT-77B**

Ref. No.	Part No.	Description	Remark
----------	----------	-------------	--------

\* A-7062-933-A FA-1 BOARD, COMPLETE

\*\*\*\*\*

(Ref. No 2,000 Series)

## &lt; CAPACITOR &gt;

C151	1-135-159-21	TANTALUM CHIP	10uF	10%	20V
C171	1-135-159-21	TANTALUM CHIP	10uF	10%	20V

## &lt; CONNECTOR &gt;

CN101	1-568-969-11	PIN, CONNECTOR (PC BOARD)	11P
CN171	1-566-757-11	PIN, CONNECTOR (PC BOARD)	2P

## &lt; DIODE &gt;

D105	8-719-928-13	DIODE	SLM13DW
D151	8-719-404-46	DIODE	MA110
D152	8-719-404-46	DIODE	MA110
D153	8-719-404-46	DIODE	MA110
D171	8-719-404-46	DIODE	MA110

## &lt; IC &gt;

IC151	8-759-234-77	IC	TC4S66F
-------	--------------	----	---------

## &lt; TRANSISTOR &gt;

Q104	8-729-907-00	TRANSISTOR	DTC114EU
Q151	8-729-905-18	TRANSISTOR	DTC144EU
Q171	8-729-106-60	TRANSISTOR	2SB1115A
Q172	8-729-905-18	TRANSISTOR	DTC144EU

## &lt; RESISTOR &gt;

R119	1-216-635-11	METAL CHIP	220	0.5%	1/10W
R151	1-216-841-11	METAL CHIP	47K	5%	1/16W
R152	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R153	1-216-854-11	METAL CHIP	560K	5%	1/16W
R171	1-216-821-11	METAL CHIP	1K	5%	1/16W
R172	1-216-821-11	METAL CHIP	1K	5%	1/16W

## &lt; SWITCH &gt;

S101	1-571-787-11	SWITCH, TACTILE (PUSH AUTO)
S109	1-571-787-11	SWITCH, TACTILE (FOCUS)
S110	1-571-787-11	SWITCH, TACTILE (FOCUS)
S111	1-571-787-11	SWITCH, TACTILE (ZOOM)
S112	1-571-787-11	SWITCH, TACTILE (ZOOM)

S115	1-571-787-11	SWITCH, TACTILE (ON/OFF)
------	--------------	--------------------------

\*\*\*\*\*

Ref. No.	Part No.	Description	Remark
----------	----------	-------------	--------

\* A-7071-500-A FR-62 BOARD, COMPLETE

\*\*\*\*\*

(Ref. No 3,000 Series)

## &lt; CONNECTOR &gt;

CN062	1-506-468-11	CONNECTOR 3P, MALE	
CN172	1-565-874-11	PIN, CONNECTOR (PC BOARD)	2P

\*\*\*\*\*

\* A-7062-930-A GE-10 BOARD, COMPLETE

\*\*\*\*\*

(Ref. No 4,000 Series)

A-7068-165-A DT-77B BOARD, COMPLETE (HIC)

3-831-441-XX CUSHION (5)

## &lt; CAPACITOR &gt;

C621	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C624	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C625	1-135-166-21	TANTALUM CHIP	47uF	10%	10V
C627	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C628	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V

C629	1-163-809-11	CERAMIC CHIP	0.047uF	10%	25V
C630	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C631	1-162-638-11	CERAMIC CHIP	1uF		16V
C632	1-135-166-21	TANTALUM CHIP	47uF	10%	10V
C634	1-162-945-11	CERAMIC CHIP	22PF	5%	50V

C635	1-162-638-11	CERAMIC CHIP	1uF		16V
C636	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C637	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
C638	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C640	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V

C646	1-162-945-11	CERAMIC CHIP	22PF	5%	50V
C650	1-162-945-11	CERAMIC CHIP	22PF	5%	50V
C687	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V
C689	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V
C862	1-164-360-11	CERAMIC CHIP	0.1uF		16V

C868	1-164-360-11	CERAMIC CHIP	0.1uF		16V
C869	1-164-360-11	CERAMIC CHIP	0.1uF		16V

## &lt; CONNECTOR &gt;

CN603	1-566-757-11	PIN, CONNECTOR (PC BOARD)	2P
CN604	1-568-335-11	CONNECTOR, BOARD TO BOARD	18P
CN852	1-565-880-11	PIN, CONNECTOR (PC BOARD)	8P
CN853	1-565-874-11	PIN, CONNECTOR (PC BOARD)	2P
CN854	1-565-874-11	PIN, CONNECTOR (PC BOARD)	2P

CN855	* 1-565-876-11	PIN, CONNECTOR (PC BOARD)	4P
CN856	1-565-876-11	PIN, CONNECTOR (PC BOARD)	4P



**GE-10****DT-77B**

Ref. No.	Part No.	Description	Remark
< TRIMMER >			
CT621	1-141-368-11	CAP. CHIP TRIMMER	
< DIODE >			
D621	8-719-404-46	DIODE MA110	
D622	8-719-404-46	DIODE MA110	
D625	8-719-949-46	DIODE 1T32	
D631	8-719-404-46	DIODE MA110	
< IC >			
IC621	8-752-326-08	IC CXD11590	
< COIL >			
L621	1-412-029-11	INDUCTOR CHIP 10uH	
L622	1-412-029-11	INDUCTOR CHIP 10uH	
L651	1-410-369-11	INDUCTOR CHIP 1uH	
L652	1-410-369-11	INDUCTOR CHIP 1uH	
L653	1-410-369-11	INDUCTOR CHIP 1uH	
L682	1-410-369-11	INDUCTOR CHIP 1uH	
L683	1-410-369-11	INDUCTOR CHIP 1uH	
L684	1-410-369-11	INDUCTOR CHIP 1uH	
< TRANSISTOR >			
Q621	8-729-402-84	TRANSISTOR XN4601	
Q624	8-729-402-84	TRANSISTOR XN4601	
Q627	8-729-402-84	TRANSISTOR XN4601	
Q628	8-729-905-35	TRANSISTOR 2SC4081-R	
Q630	8-729-905-35	TRANSISTOR 2SC4081-R	
Q633	8-729-402-84	TRANSISTOR XN4601	
< RESISTOR >			
R606	1-216-864-11	METAL CHIP 0 5% 1/16W	
R611	1-216-864-11	METAL CHIP 0 5% 1/16W	
R617	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R618	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R620	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R621	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R623	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R624	1-216-839-11	METAL CHIP 33K 5% 1/16W	
R626	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R627	1-216-820-11	METAL CHIP 820 5% 1/16W	
R634	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R635	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R637	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R641	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R642	1-216-842-11	METAL CHIP 56K 5% 1/16W	
R643	1-216-843-11	METAL CHIP 68K 5% 1/16W	

Ref. No.	Part No.	Description	Remark
R644	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R645	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R646	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R647	1-216-813-11	METAL CHIP 220 5% 1/16W	
R648	1-216-848-11	METAL CHIP 180K 5% 1/16W	
R649	1-216-815-11	METAL CHIP 330 5% 1/16W	
R651	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R652	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R654	1-216-864-11	METAL CHIP 0 5% 1/16W	
R655	1-216-864-11	METAL CHIP 0 5% 1/16W	
R656	1-216-809-11	METAL CHIP 100 5% 1/16W	
R657	1-216-843-11	METAL CHIP 68K 5% 1/16W	
R658	1-216-862-11	METAL GLAZE 2.7M 5% 1/16W	
R659	1-216-809-11	METAL CHIP 100 5% 1/16W	
R660	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R662	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R663	1-216-845-11	METAL CHIP 100K 5% 1/16W	
R664	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R665	1-216-813-11	METAL CHIP 220 5% 1/16W	
R666	1-216-813-11	METAL CHIP 220 5% 1/16W	
R672	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R673	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R674	1-216-864-11	METAL CHIP 0 5% 1/16W	
R675	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R676	1-216-842-11	METAL CHIP 56K 5% 1/16W	
R677	1-216-835-11	METAL CHIP 15K 5% 1/16W	
R678	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R679	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R681	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R682	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R683	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R685	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R686	1-216-864-11	METAL CHIP 0 5% 1/16W	
R687	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R688	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R689	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R690	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R691	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R692	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R694	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R695	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R696	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R697	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R698	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R699	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R700	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R701	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R879	1-216-816-11	METAL CHIP 390 5% 1/16W	
R880	1-216-816-11	METAL CHIP 390 5% 1/16W	

## GE-10

## DT-77B

## JS-22

## MC-65

## PJ-43

Ref. No.	Part No.	Description	Remark
		< VIBRATOR >	
X621	1-577-119-11	OSCILLATOR, CRYSTAL	
X622	1-567-733-11	VIBRATOR, CRYSTAL (17.7MHz)	
*****			
	* A-7062-934-A	JS-22 BOARD, COMPLETE	
		*****	
		(Ref.No 5,000 Series)	
		< CONNECTOR >	
CN102	1-568-964-11	PIN, CONNECTOR (PC BOARD) 6P	
		< VARIABLE RESISTOR >	
RV103	1-237-423-21	RES, VAR, CARBON 1K/1K (COLOUR CORRECT)	
*****			
	* A-7062-932-A	MC-65 BOARD, COMPLETE	
		*****	
		(Ref.No 8,000 Series)	
	* 3-941-954-01	SHIELD (LOWER), VOL PC BOARD	
	3-942-526-01	BLIND (2), KNOB	
		< CAPACITOR >	
C001	1-126-246-11	ELECT CHIP 220uF 20% 4V	
C002	1-126-193-11	ELECT 1uF 20% 50V	
C003	1-126-601-11	ELECT 2.2uF 20% 50V	
C004	1-162-953-11	CERAMIC CHIP 100PF 5% 50V	
C010	1-164-361-11	CERAMIC CHIP 0.047uF 16V	
C261	1-126-206-11	ELECT CHIP 100uF 20% 6.3V	
C262	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C268	1-126-206-11	ELECT CHIP 100uF 20% 6.3V	
C271	1-124-779-00	ELECT CHIP 10uF 20% 16v	
C272	1-162-953-11	CERAMIC CHIP 100PF 5% 50V	
C273	1-126-193-11	ELECT 1uF 20% 50V	
C274	1-126-204-11	ELECT CHIP 47uF 20% 16V	
C275	1-126-400-11	ELECT 22uF 20% 35V	
C276	1-126-395-11	ELECT 22uF 20% 16V	
		< CONNECTOR >	
CN004	1-568-961-11	PIN, CONNECTOR (PC BOARD) 3P	
		< DIODE >	
D005	8-719-420-15	DIODE MA8082-M	
D006	8-719-420-15	DIODE MA8082-M	
D261	8-719-404-46	DIODE MA110	
D262	8-719-404-46	DIODE MA110	

Ref. No.	Part No.	Description	Remark
		< IC >	
IC206	8-759-981-58	IC RC2043M-D	
		< JACK >	
J003	1-507-834-31	JACK (MIC IN)	
		< COIL >	
L261	1-412-032-11	INDUCTOR CHIP 100uH	
L262	1-410-369-11	INDUCTOR CHIP 1uH	
L263	1-410-369-11	INDUCTOR CHIP 1uH	
		< TRANSISTOR >	
Q261	8-729-905-35	TRANSISTOR 2SC4081-R	
Q262	8-729-905-12	TRANSISTOR DTA144EU	
Q263	8-729-920-XX	TRANSISTOR DTA114EU	
Q264	8-729-905-18	TRANSISTOR DTC144EU	
		< RESISTOR >	
R001	1-216-831-11	METAL CHIP 6.8K 5% 1/16W	
R002	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R003	1-216-820-11	METAL CHIP 820 5% 1/16W	
R266	1-216-835-11	METAL CHIP 15K 5% 1/16W	
R268	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R269	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R270	1-216-805-11	METAL CHIP 47 5% 1/16W	
R271	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R272	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R273	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R275	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R276	1-216-833-11	METAL CHIP 10K 5% 1/16W	
		< VARIABLE RESISTOR >	
RV001	1-238-047-11	RES, VAR, CARBON 10K (MIC LEVEL)	
*****			
	* A-7062-935-A	PJ-43 BOARD, COMPLETE	
		*****	
		(Ref.No 6,000 Series)	
		< CAPACITOR >	
C005	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C006	1-164-361-11	CERAMIC CHIP 0.047uF 16V	
C007	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C008	1-162-995-11	CERAMIC CHIP 0.022uF 50V	
C009	1-162-995-11	CERAMIC CHIP 0.022uF 50V	

**PJ-43****VC-85****MX-7PH**

Ref. No.	Part No.	Description	Remark
< CONNECTOR >			
CN001	1-568-968-11	PIN, CONNECTOR (PC BOARD) 10P	
CN003	1-568-961-11	PIN, CONNECTOR (PC BOARD) 3P	
< DIODE >			
D001	8-719-800-76	DIODE 1SS226	
D002	8-719-800-76	DIODE 1SS226	
D003	8-719-800-76	DIODE 1SS226	
D004	8-719-106-43	DIODE RD9. 1M-B1	
D007	8-719-106-43	DIODE RD9. 1M-B1	
D008	8-719-106-43	DIODE RD9. 1M-B1	
D009	8-719-106-43	DIODE RD9. 1M-B1	
D010	8-719-106-43	DIODE RD9. 1M-B1	
D011	8-719-106-43	DIODE RD9. 1M-B1	
D012	8-719-106-43	DIODE RD9. 1M-B1	
D013	8-719-106-43	DIODE RD9. 1M-B1	
D014	8-719-106-43	DIODE RD9. 1M-B1	
< JACK >			
J001	1-566-847-41	CONNECTOR, (S) TERMINAL 4P(S VIDEO OUT)	
J002	1-537-005-21	JACK BOARD (VIDEO/AUDIO/RFUDC OUT)	
< COIL >			
L001	1-410-369-11	INDUCTOR CHIP 1uH	
< RESISTOR >			
R274	1-216-821-11	METAL CHIP 1K 5% 1/16W	
*****			
* A-7062-931-A VC-85 BOARD, COMPLETE			
*****			
(Ref. No 7.000 Series)			
A-7068-193-A MX-7PH BOARD, COMPLETE (HIC)			
-----			
3-831-441-XX CUSHION (5)			
< CAPACITOR >			
C100	1-162-917-11	CERAMIC CHIP 15PF 5% 50V	
C102	1-124-779-00	ELECT CHIP 10uF 20% 16v	
C103	1-162-921-11	CERAMIC CHIP 33PF 5% 50V	
C104	1-162-638-11	CERAMIC CHIP 1uF 16V	
C105	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C106	1-126-601-11	ELECT 2.2uF 20% 50V	
C161	1-135-181-21	TANTALUM CHIP 4.7uF 20% 6.3V	
C201	1-135-158-21	TANTALUM CHIP 15uF 20% 4V	
C202	1-163-034-00	CERAMIC CHIP 0.033uF 50V	
C203	1-135-181-21	TANTALUM CHIP 4.7uF 20% 6.3V	

Ref. No.	Part No.	Description	Remark
C204	1-162-921-11	CERAMIC CHIP 33PF 5% 50V	
C205	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C206	1-126-205-11	ELECT CHIP 47uF 20% 6.3V	
C207	1-135-201-11	TANTALUM CHIP 10uF 20% 4V	
C208	1-126-205-11	ELECT CHIP 47uF 20% 6.3V	
C209	1-135-158-21	TANTALUM CHIP 15uF 20% 4V	
C210	1-126-246-11	ELECT CHIP 220uF 20% 4V	
C211	1-135-157-21	TANTALUM CHIP 10uF 20% 6.3V	
C212	1-126-246-11	ELECT CHIP 220uF 20% 4V	
C213	1-135-157-21	TANTALUM CHIP 10uF 20% 6.3V	
C214	1-163-809-11	CERAMIC CHIP 0.047uF 10% 25V	
C215	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V	
C216	1-126-205-11	ELECT CHIP 47uF 20% 6.3V	
C217	1-163-809-11	CERAMIC CHIP 0.047uF 10% 25V	
C218	1-126-205-11	ELECT CHIP 47uF 20% 6.3V	
C219	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V	
C220	1-135-157-21	TANTALUM CHIP 10uF 20% 6.3V	
C221	1-163-809-11	CERAMIC CHIP 0.047uF 10% 25V	
C222	1-135-157-21	TANTALUM CHIP 10uF 20% 6.3V	
C223	1-135-157-21	TANTALUM CHIP 10uF 20% 6.3V	
C224	1-135-157-21	TANTALUM CHIP 10uF 20% 6.3V	
C225	1-135-181-21	TANTALUM CHIP 4.7uF 20% 6.3V	
C227	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C228	1-135-181-21	TANTALUM CHIP 4.7uF 20% 6.3V	
C241	1-126-206-11	ELECT CHIP 100uF 20% 6.3V	
C242	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C243	1-126-206-11	ELECT CHIP 100uF 20% 6.3V	
C244	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C245	1-124-779-00	ELECT CHIP 10uF 20% 16v	
C246	1-124-779-00	ELECT CHIP 10uF 20% 16v	
C247	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C248	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C249	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C250	1-126-206-11	ELECT CHIP 100uF 20% 6.3V	
C266	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C505	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C506	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C507	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C508	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C509	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C510	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C511	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C512	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C513	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C515	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C521	1-135-149-21	TANTALUM CHIP 2.2uF 20% 10V	
C522	1-135-149-21	TANTALUM CHIP 2.2uF 20% 10V	
C523	1-126-205-11	ELECT CHIP 47uF 20% 6.3V	
C524	1-126-205-11	ELECT CHIP 47uF 20% 6.3V	



Ref. No.	Part No.	Description		Remark
C575	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C576	1-163-038-00	CERAMIC CHIP	0.1uF	25V
C577	1-164-173-11	CERAMIC CHIP	0.0039uF	10% 50V
C578	1-124-779-00	ELECT CHIP	10uF	20% 16v
C579	1-162-638-11	CERAMIC CHIP	1uF	16V
C580	1-162-638-11	CERAMIC CHIP	1uF	16V
C641	1-162-942-11	CERAMIC CHIP	12PF	5% 50V
C703	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C704	1-162-945-11	CERAMIC CHIP	22PF	5% 50V
C705	1-162-946-11	CERAMIC CHIP	27PF	5% 50V
C706	1-135-091-00	TANTALUM CHIP	1uF	20% 16V
C707	1-162-638-11	CERAMIC CHIP	1uF	16V
C708	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C709	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C710	1-126-206-11	ELECT CHIP	100uF	20% 6.3V
C711	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C712	1-164-005-11	CERAMIC CHIP	0.47uF	25V
C713	1-164-005-11	CERAMIC CHIP	0.47uF	25V
C714	1-164-005-11	CERAMIC CHIP	0.47uF	25V
C716	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C717	1-135-091-00	TANTALUM CHIP	1uF	20% 16V
C718	1-135-091-00	TANTALUM CHIP	1uF	20% 16V
C719	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C720	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C721	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C722	1-163-038-00	CERAMIC CHIP	0.1uF	25V
C723	1-163-038-00	CERAMIC CHIP	0.1uF	25V
C724	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C725	1-162-949-11	CERAMIC CHIP	47PF	5% 50V
C726	1-162-943-11	CERAMIC CHIP	15PF	5% 50V
C727	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C728	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C731	1-126-204-11	ELECT CHIP	47uF	20% 16V
C734	1-162-951-11	CERAMIC CHIP	68PF	5% 50V
C735	1-162-953-11	CERAMIC CHIP	100PF	5% 50V
C736	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C737	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C738	1-162-941-11	CERAMIC CHIP	10PF	0.5PF 50V
C739	1-164-005-11	CERAMIC CHIP	0.47uF	25V
C740	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C741	1-162-944-11	CERAMIC CHIP	18PF	5% 50V
C742	1-135-091-00	TANTALUM CHIP	1uF	20% 16V
C743	1-126-206-11	ELECT CHIP	100uF	20% 6.3V
C744	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C746	1-164-005-11	CERAMIC CHIP	0.47uF	25V
C747	1-162-941-11	CERAMIC CHIP	10PF	0.5PF 50V
C748	1-162-951-11	CERAMIC CHIP	68PF	5% 50V
C749	1-162-953-11	CERAMIC CHIP	100PF	5% 50V
C750	1-162-944-11	CERAMIC CHIP	18PF	5% 50V

Ref. No.	Part No.	Description		Remark
C751	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C752	1-162-964-11	CERAMIC CHIP	0.001uF	10% 50V
C753	1-135-091-00	TANTALUM CHIP	1uF	20% 16V
C754	1-162-638-11	CERAMIC CHIP	1uF	16V
C755	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C757	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C759	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C760	1-162-974-11	CERAMIC CHIP	0.01uF	50V
C764	1-162-943-11	CERAMIC CHIP	15PF	5% 50V
C765	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C781	1-162-966-11	CERAMIC CHIP	0.0022uF	10% 50V
C782	1-162-966-11	CERAMIC CHIP	0.0022uF	10% 50V
C783	1-162-966-11	CERAMIC CHIP	0.0022uF	10% 50V
C801	1-135-091-00	TANTALUM CHIP	1uF	20% 16V
C802	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C803	1-162-638-11	CERAMIC CHIP	1uF	16V
C804	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C806	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C807	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C808	1-135-072-21	TANTALUM CHIP	0.22uF	10% 35V
C809	1-124-779-00	ELECT CHIP	10uF	20% 16v
C810	1-126-602-11	ELECT CHIP	3.3uF	20% 50V
C811	1-126-602-11	ELECT CHIP	3.3uF	20% 50V
C812	1-126-602-11	ELECT CHIP	3.3uF	20% 50V
C813	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C851	1-162-638-11	CERAMIC CHIP	1uF	16V
C852	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C853	1-162-995-11	CERAMIC CHIP	0.022uF	50V
C854	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C855	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C856	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
C858	1-162-966-11	CERAMIC CHIP	0.0022uF	10% 50V
C859	1-162-995-11	CERAMIC CHIP	0.022uF	50V
C860	1-162-974-11	CERAMIC CHIP	0.01uF	50V
C861	1-124-779-00	ELECT CHIP	10uF	20% 16v
C863	1-163-075-00	CERAMIC CHIP	0.047uF	50V
C864	1-162-974-11	CERAMIC CHIP	0.01uF	50V
C865	1-162-974-11	CERAMIC CHIP	0.01uF	50V
C867	1-162-964-11	CERAMIC CHIP	0.001uF	10% 50V
C903	1-162-638-11	CERAMIC CHIP	1uF	16V
C906	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C907	1-135-180-21	TANTALUM CHIP	3.3uF	20% 6.3V
C909	1-162-974-11	CERAMIC CHIP	0.01uF	50V
C910	1-162-964-11	CERAMIC CHIP	0.001uF	10% 50V
C911	1-126-205-11	ELECT CHIP	47uF	20% 6.3V
C912	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C914	1-135-157-21	TANTALUM CHIP	10uF	20% 6.3V
C915	1-162-941-11	CERAMIC CHIP	10PF	0.5PF 50V

## VC-85

## MX-7PH

Ref. No.	Part No.	Description	Remark
C916	1-162-964-11	CERAMIC CHIP 0.001uF	10% 50V
C917	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C918	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C919	1-135-157-21	TANTALUM CHIP 10uF	20% 6.3V
C920	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C921	1-162-957-11	CERAMIC CHIP 220PF	5% 50V
C922	1-162-957-11	CERAMIC CHIP 220PF	5% 50V
C923	1-162-957-11	CERAMIC CHIP 220PF	5% 50V
C924	1-162-928-11	CERAMIC CHIP 120PF	5% 50V
C925	1-162-926-11	CERAMIC CHIP 82PF	5% 50V
C930	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C931	1-135-091-00	TANTALUM CHIP 1uF	20% 16V
C932	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C933	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C934	1-162-966-11	CERAMIC CHIP 0.0022uF	10% 50V
C935	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C936	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C937	1-135-145-11	TANTALUM CHIP 0.47uF	10% 35V
C938	1-162-964-11	CERAMIC CHIP 0.001uF	10% 50V
C939	1-162-964-11	CERAMIC CHIP 0.001uF	10% 50V
C940	1-135-155-21	TANTALUM CHIP 4.7uH	10% 16V
C941	1-135-145-11	TANTALUM CHIP 0.47uF	10% 35V
C942	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C951	1-162-964-11	CERAMIC CHIP 0.001uF	10% 50V
C952	1-162-964-11	CERAMIC CHIP 0.001uF	10% 50V
C953	1-162-964-11	CERAMIC CHIP 0.001uF	10% 50V
C954	1-162-964-11	CERAMIC CHIP 0.001uF	10% 50V
C955	1-164-360-11	CERAMIC CHIP 0.1uF	16V
< CONNECTOR >			
CN201	* 1-565-883-11	PIN, CONNECTOR (PC BOARD) 11P	
CN203	1-506-482-11	CONNECTOR 3P, MALE	
CN204	* 1-565-875-11	PIN, CONNECTOR (PC BOARD) 3P	
CN208	* 1-565-882-11	PIN, CONNECTOR (PC BOARD) 10P	
CN209	1-566-760-11	PIN, CONNECTOR (PC BOARD) 5P	
CN701	1-565-877-11	PIN, CONNECTOR (PC BOARD) 5P	
CN702	* 1-565-876-11	PIN, CONNECTOR (PC BOARD) 4P	
CN703	1-565-878-11	PIN, CONNECTOR (PC BOARD) 6P	
CN705	1-580-106-21	CONNECTOR, FPC 28P	
CN706	1-569-478-21	CONNECTOR, FPC 20P	
CN707	1-566-527-11	CONNECTOR, FPC (ZIF) 11P	
CN902	* 1-565-543-11	PIN, CONNECTOR (PC BOARD) 4P	
< DIODE >			
D101	8-719-404-35	DIODE MA141WK	
D102	8-719-404-35	DIODE MA141WK	
D103	8-719-928-13	DIODE SLM13DW	
D104	8-719-928-13	DIODE SLM13DW	
D106	8-719-404-35	DIODE MA141WK	

Ref. No.	Part No.	Description	Remark
D107	8-719-404-46	DIODE MA110	
D108	8-719-404-35	DIODE MA141WK	
D201	8-719-404-46	DIODE MA110	
D202	8-719-404-46	DIODE MA110	
D203	8-719-400-18	DIODE MA152WK	
D575	8-719-800-76	DIODE 1SS226	
D576	8-719-404-46	DIODE MA110	
D801	8-719-820-05	DIODE 1SS181	
D802	8-719-404-46	DIODE MA110	
D852	8-719-404-46	DIODE MA110	
D901	8-719-404-46	DIODE MA110	
D902	8-719-820-05	DIODE 1SS181	
< FILTER >			
FL701	1-236-368-11	FILTER, LOW PASS	
FL702	1-415-634-21	DL (LC)	
FL703	1-236-187-11	FILTER, LOW PASS	
FL704	1-236-190-11	FILTER, LOW PASS	
FL705	1-236-192-11	FILTER, LOW PASS	
FL707	1-415-638-11	DL, LC	
FL708	1-415-635-21	DL (LC)	
FL901	1-236-209-11	FILTER, LOW PASS	
< IC >			
IC101	8-759-152-80	IC uPD7508BGB-522	
IC102	8-759-937-56	IC S-8054ALB-LM-S	
IC103	8-759-926-28	IC SN74HC174ANS	
IC201	8-752-009-51	IC CX20095A	
IC202	8-759-504-47	IC TL026CPS	
IC203	8-759-983-69	IC LM358PS	
IC204	8-759-011-65	IC MC74HC4053F	
IC205	8-759-937-56	IC S-8054ALB-LM-S	
IC207	8-759-502-36	IC S-81350HG	
IC575	8-759-983-69	IC LM358PS	
IC576	8-759-234-77	IC TC4S66F	
IC577	8-759-234-77	IC TC4S66F	
IC578	8-759-234-77	IC TC4S66F	
IC702	8-752-034-21	IC CXA1339R	
IC703	8-759-946-00	IC MB88341PFV	
IC704	8-759-300-71	IC TC4053BF	
IC705	8-752-033-34	IC CXA1072R	
IC706	8-759-946-00	IC MB88341PFV	
IC707	8-759-300-71	IC TC4053BF	
IC708	8-759-300-71	IC TC4053BF	
IC709	8-759-300-71	IC TC4053BF	
IC710	8-759-100-93	IC uPC393G2	
IC711	8-759-300-71	IC TC4053BF	
IC712	8-759-100-93	IC uPC393G2	
IC713	8-759-200-67	IC TC4001BF	

**VC-85****MX-7PH**

Ref. No.	Part No.	Description	Remark
IC714	8-759-300-71	IC TC4053BF	
IC715	8-759-100-93	IC uPC393G2	
IC716	8-759-300-71	IC TC4053BF	
IC717	8-759-300-71	IC TC4053BF	
IC720	8-759-234-77	IC TC4S66F	
IC801	8-759-937-56	IC S-8054ALB-LM-S	
IC802	8-759-037-60	IC MC68HC05N4-SC406667	
IC803	8-759-983-74	IC LM324NS	
IC804	8-759-008-67	IC MC14066BF	
IC851	8-759-500-11	IC MM1036XF	
IC852	8-759-983-69	IC LM358PS	
IC853	8-759-030-35	IC MPC1725M	
IC854	8-759-983-74	IC LM324NS	
IC901	8-752-334-49	IC CXD1172AM	
IC902	8-759-946-00	IC MB88341PFV	
IC903	8-759-940-45	IC S-8054HN-CB	
IC904	8-752-326-18	IC CXD1204R	
IC905	8-759-031-86	IC MC68HC05C4-SC411531	
IC906	8-759-300-71	IC TC4053BF	
IC907	8-759-983-74	IC LM324NS	
IC908	8-759-009-06	IC MC14052BF	
< JACK >			
J202	1-565-276-21	JACK, ULTRA SMALL 1P	
< COIL >			
L101	1-410-393-11	INDUCTOR CHIP 100uH	
L201	1-410-388-21	INDUCTOR CHIP 39uH	
L211	1-412-026-11	INDUCTOR CHIP 1uH	
L212	1-412-026-11	INDUCTOR CHIP 1uH	
L241	1-412-032-11	INDUCTOR CHIP 100uH	
L242	1-412-032-11	INDUCTOR CHIP 100uH	
L623	1-410-381-11	INDUCTOR CHIP 10uH	
L701	1-412-031-11	INDUCTOR CHIP 47uH	
L702	1-412-031-11	INDUCTOR CHIP 47uH	
L703	1-410-392-11	INDUCTOR CHIP 82uH	
L704	1-410-369-11	INDUCTOR CHIP 1uH	
L705	1-410-369-11	INDUCTOR CHIP 1uH	
L706	1-410-369-11	INDUCTOR CHIP 1uH	
L707	1-412-031-11	INDUCTOR CHIP 47uH	
L901	1-410-369-11	INDUCTOR CHIP 1uH	
L902	1-410-655-31	INDUCTOR CHIP 120uH	
< TRANSISTOR >			
Q101	8-729-905-18	TRANSISTOR DTC144EU	
Q102	8-729-907-00	TRANSISTOR DTC114EU	
Q103	8-729-907-00	TRANSISTOR DTC114EU	
Q105	8-729-905-18	TRANSISTOR DTC144EU	

Ref. No.	Part No.	Description	Remark
Q201	8-729-905-35	TRANSISTOR 2SC4081-R	
Q202	8-729-905-35	TRANSISTOR 2SC4081-R	
Q203	8-729-905-35	TRANSISTOR 2SC4081-R	
Q204	8-729-905-35	TRANSISTOR 2SC4081-R	
Q205	8-729-905-35	TRANSISTOR 2SC4081-R	
Q206	8-729-905-35	TRANSISTOR 2SC4081-R	
Q207	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q208	8-729-905-35	TRANSISTOR 2SC4081-R	
Q209	8-729-106-60	TRANSISTOR 2SB1115A	
Q210	8-729-905-35	TRANSISTOR 2SC4081-R	
Q211	8-729-905-23	TRANSISTOR 2SA1576-R	
Q212	8-729-402-84	TRANSISTOR XN4601	
Q213	8-729-905-35	TRANSISTOR 2SC4081-R	
Q214	8-729-905-23	TRANSISTOR 2SA1576-R	
Q215	8-729-905-35	TRANSISTOR 2SC4081-R	
Q216	8-729-905-35	TRANSISTOR 2SC4081-R	
Q574	8-729-905-35	TRANSISTOR 2SC4081-R	
Q575	8-729-905-35	TRANSISTOR 2SC4081-R	
Q576	8-729-905-35	TRANSISTOR 2SC4081-R	
Q577	8-765-420-02	TRANSISTOR 2SK300-3	
Q578	8-729-905-18	TRANSISTOR DTC144EU	
Q579	8-729-905-35	TRANSISTOR 2SC4081-R	
Q580	8-729-402-84	TRANSISTOR XN4601	
Q581	8-729-905-18	TRANSISTOR DTC144EU	
Q582	8-729-905-35	TRANSISTOR 2SC4081-R	
Q702	8-729-905-23	TRANSISTOR 2SA1576-R	
Q703	8-729-905-35	TRANSISTOR 2SC4081-R	
Q704	8-729-905-35	TRANSISTOR 2SC4081-R	
Q705	8-729-905-35	TRANSISTOR 2SC4081-R	
Q706	8-729-402-78	TRANSISTOR XN6401	
Q707	8-729-905-35	TRANSISTOR 2SC4081-R	
Q708	8-729-403-10	TRANSISTOR XN6215	
Q709	8-729-905-35	TRANSISTOR 2SC4081-R	
Q710	8-729-905-35	TRANSISTOR 2SC4081-R	
Q711	8-729-905-35	TRANSISTOR 2SC4081-R	
Q712	8-729-402-84	TRANSISTOR XN4601	
Q713	8-729-402-81	TRANSISTOR XN4501	
Q714	8-729-402-84	TRANSISTOR XN4601	
Q715	8-729-905-35	TRANSISTOR 2SC4081-R	
Q716	8-729-905-18	TRANSISTOR DTC144EU	
Q717	8-729-905-23	TRANSISTOR 2SA1576-R	
Q718	8-729-905-35	TRANSISTOR 2SC4081-R	
Q719	8-729-905-35	TRANSISTOR 2SC4081-R	
Q720	8-729-905-23	TRANSISTOR 2SA1576-R	
Q721	8-729-905-35	TRANSISTOR 2SC4081-R	
Q722	8-729-905-23	TRANSISTOR 2SA1576-R	
Q723	8-729-905-35	TRANSISTOR 2SC4081-R	
Q724	8-729-905-35	TRANSISTOR 2SC4081-R	
Q725	8-729-907-00	TRANSISTOR DTC114EU	



## VC-85

## MX-7PH

Ref. No.	Part No.	Description	Remark
Q727	8-729-905-23	TRANSISTOR 2SA1576-R	
Q728	8-729-905-18	TRANSISTOR DTC144EU	
Q801	8-729-403-10	TRANSISTOR XN6215	
Q802	8-729-403-07	TRANSISTOR XN1213	
Q803	8-729-905-35	TRANSISTOR 2SC4081-R	
Q804	8-729-805-42	TRANSISTOR 2SC3859	
Q805	8-729-805-42	TRANSISTOR 2SC3859	
Q806	8-729-805-42	TRANSISTOR 2SC3859	
Q807	8-729-402-78	TRANSISTOR XN6401	
Q851	8-729-403-07	TRANSISTOR XN1213	
Q852	8-729-905-23	TRANSISTOR 2SA1576-R	
Q853	8-729-402-84	TRANSISTOR XN4601	
Q854	8-729-106-60	TRANSISTOR 2SB1115A	
Q855	8-729-905-35	TRANSISTOR 2SC4081-R	
Q856	8-729-905-15	TRANSISTOR DTC144WU	
Q858	8-729-402-84	TRANSISTOR XN4601	
Q859	8-729-905-18	TRANSISTOR DTC144EU	
Q860	8-729-905-18	TRANSISTOR DTC144EU	
Q901	8-729-402-84	TRANSISTOR XN4601	
Q902	8-729-403-10	TRANSISTOR XN6215	
Q903	8-729-905-23	TRANSISTOR 2SA1576-R	
Q904	8-729-905-18	TRANSISTOR DTC144EU	
Q906	8-729-905-35	TRANSISTOR 2SC4081-R	
Q907	8-729-905-35	TRANSISTOR 2SC4081-R	
Q909	8-729-905-35	TRANSISTOR 2SC4081-R	
Q910	8-729-905-35	TRANSISTOR 2SC4081-R	
Q911	8-729-402-19	TRANSISTOR XN6501	
Q914	8-729-905-18	TRANSISTOR DTC144EU	
Q915	8-729-905-18	TRANSISTOR DTC144EU	
Q916	8-729-905-18	TRANSISTOR DTC144EU	
Q918	8-729-905-18	TRANSISTOR DTC144EU	
Q919	8-729-905-18	TRANSISTOR DTC144EU	
Q920	8-729-402-84	TRANSISTOR XN4601	
< RESISTOR >			
R101	1-216-845-11	METAL CHIP 100K 5%	1/16W
R102	1-216-845-11	METAL CHIP 100K 5%	1/16W
R103	1-216-845-11	METAL CHIP 100K 5%	1/16W
R104	1-216-845-11	METAL CHIP 100K 5%	1/16W
R105	1-216-845-11	METAL CHIP 100K 5%	1/16W
R106	1-216-849-11	METAL CHIP 220K 5%	1/16W
R107	1-216-845-11	METAL CHIP 100K 5%	1/16W
R108	1-216-845-11	METAL CHIP 100K 5%	1/16W
R109	1-216-845-11	METAL CHIP 100K 5%	1/16W
R111	1-216-809-11	METAL CHIP 100 5%	1/16W
R112	1-216-841-11	METAL CHIP 47K 5%	1/16W
R113	1-216-833-11	METAL CHIP 10K 5%	1/16W
R114	1-216-851-11	METAL CHIP 330K 5%	1/16W

Ref. No.	Part No.	Description	Remark
R115	1-216-864-11	METAL CHIP 0 5%	1/16W
R116	1-216-864-11	METAL CHIP 0 5%	1/16W
R117	1-216-635-11	METAL CHIP 220 0.5%	1/10W
R118	1-216-635-11	METAL CHIP 220 0.5%	1/10W
R121	1-216-833-11	METAL CHIP 10K 5%	1/16W
R131	1-216-846-11	METAL CHIP 120K 5%	1/16W
R161	1-216-846-11	METAL CHIP 120K 5%	1/16W
R201	1-216-813-11	METAL CHIP 220 5%	1/16W
R202	1-216-833-11	METAL CHIP 10K 5%	1/16W
R203	1-216-833-11	METAL CHIP 10K 5%	1/16W
R204	1-216-821-11	METAL CHIP 1K 5%	1/16W
R205	1-216-817-11	METAL CHIP 470 5%	1/16W
R206	1-216-818-11	METAL CHIP 560 5%	1/16W
R207	1-216-817-11	METAL CHIP 470 5%	1/16W
R208	1-216-813-11	METAL CHIP 220 5%	1/16W
R209	1-216-816-11	METAL CHIP 390 5%	1/16W
R210	1-216-821-11	METAL CHIP 1K 5%	1/16W
R211	1-216-821-11	METAL CHIP 1K 5%	1/16W
R212	1-216-833-11	METAL CHIP 10K 5%	1/16W
R213	1-216-831-11	METAL CHIP 6.8K 5%	1/16W
R214	1-216-833-11	METAL CHIP 10K 5%	1/16W
R215	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
R216	1-216-827-11	METAL CHIP 3.3K 5%	1/16W
R217	1-216-827-11	METAL CHIP 3.3K 5%	1/16W
R218	1-216-807-11	METAL CHIP 68 5%	1/16W
R219	1-216-807-11	METAL CHIP 68 5%	1/16W
R220	1-216-837-11	METAL CHIP 22K 5%	1/16W
R221	1-216-834-11	METAL CHIP 12K 5%	1/16W
R222	1-216-822-11	METAL CHIP 1.2K 5%	1/16W
R223	1-216-817-11	METAL CHIP 470 5%	1/16W
R224	1-216-822-11	METAL CHIP 1.2K 5%	1/16W
R225	1-216-815-11	METAL CHIP 330 5%	1/16W
R226	1-216-807-11	METAL CHIP 68 5%	1/16W
R227	1-216-820-11	METAL CHIP 820 5%	1/16W
R228	1-216-836-11	METAL CHIP 18K 5%	1/16W
R229	1-216-829-11	METAL CHIP 4.7K 5%	1/16W
R230	1-216-791-11	METAL CHIP 3.3 5%	1/16W
R231	1-216-821-11	METAL CHIP 1K 5%	1/16W
R232	1-216-821-11	METAL CHIP 1K 5%	1/16W
R233	1-216-821-11	METAL CHIP 1K 5%	1/16W
R234	1-216-821-11	METAL CHIP 1K 5%	1/16W
R235	1-216-845-11	METAL CHIP 100K 5%	1/16W
R236	1-216-857-11	METAL CHIP 1M 5%	1/16W
R237	1-216-824-11	METAL CHIP 1.8K 5%	1/16W
R238	1-216-833-11	METAL CHIP 10K 5%	1/16W
R239	1-216-817-11	METAL CHIP 470 5%	1/16W
R240	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
R241	1-216-821-11	METAL CHIP 1K 5%	1/16W

**VC-85****MX-7PH**

Ref. No.	Part No.	Description	Remark		
R242	1-216-824-11	METAL CHIP	1.8K	5%	1/16W
R243	1-216-812-11	METAL CHIP	180	5%	1/16W
R245	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R246	1-216-819-11	METAL CHIP	680	5%	1/16W
R247	1-216-817-11	METAL CHIP	470	5%	1/16W
R248	1-216-812-11	METAL CHIP	180	5%	1/16W
R249	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R250	1-216-839-11	METAL CHIP	33K	5%	1/16W
R251	1-216-837-11	METAL CHIP	22K	5%	1/16W
R252	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R253	1-216-821-11	METAL CHIP	1K	5%	1/16W
R254	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R255	1-216-833-11	METAL CHIP	10K	5%	1/16W
R256	1-216-821-11	METAL CHIP	1K	5%	1/16W
R257	1-216-817-11	METAL CHIP	470	5%	1/16W
R258	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R261	1-216-837-11	METAL CHIP	22K	5%	1/16W
R262	1-216-839-11	METAL CHIP	33K	5%	1/16W
R263	1-216-817-11	METAL CHIP	470	5%	1/16W
R264	1-216-817-11	METAL CHIP	470	5%	1/16W
R265	1-216-817-11	METAL CHIP	470	5%	1/16W
R281	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R282	1-216-819-11	METAL CHIP	680	5%	1/16W
R283	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R284	1-216-864-11	METAL CHIP	0	5%	1/16W
R285	1-216-815-11	METAL CHIP	330	5%	1/16W
R286	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R287	1-216-865-11	METAL CHIP	3K	5%	1/16W
R507	1-216-834-11	METAL CHIP	12K	5%	1/16W
R508	1-216-834-11	METAL CHIP	12K	5%	1/16W
R509	1-216-661-11	METAL CHIP	2.7K	0.5%	1/10W
R510	1-216-647-11	METAL CHIP	680	0.5%	1/10W
R511	1-216-659-11	METAL CHIP	2.2K	0.5%	1/10W
R512	1-216-854-11	METAL CHIP	560K	5%	1/16W
R513	1-216-833-11	METAL CHIP	10K	5%	1/16W
R514	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R515	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R516	1-216-833-11	METAL CHIP	10K	5%	1/16W
R517	1-216-854-11	METAL CHIP	560K	5%	1/16W
R518	1-216-665-11	METAL CHIP	3.9K	0.5%	1/10W
R519	1-216-647-11	METAL CHIP	680	0.5%	1/10W
R520	1-216-647-11	METAL CHIP	680	0.5%	1/10W
R521	1-216-659-11	METAL CHIP	2.2K	0.5%	1/10W
R522	1-216-649-11	METAL CHIP	820	0.5%	1/10W
R523	1-216-655-11	METAL CHIP	1.5K	0.5%	1/10W
R524	1-216-854-11	METAL CHIP	560K	5%	1/16W
R525	1-216-833-11	METAL CHIP	10K	5%	1/16W
R526	1-216-833-11	METAL CHIP	10K	5%	1/16W
R527	1-216-854-11	METAL CHIP	560K	5%	1/16W

Ref. No.	Part No.	Description	Remark		
R528	1-216-665-11	METAL CHIP	3.9K	0.5%	1/10W
R529	1-216-645-11	METAL CHIP	560	0.5%	1/10W
R530	1-216-649-11	METAL CHIP	820	0.5%	1/10W
R531	1-216-665-11	METAL CHIP	3.9K	0.5%	1/10W
R532	1-216-645-11	METAL CHIP	560	0.5%	1/10W
R533	1-216-649-11	METAL CHIP	820	0.5%	1/10W
R534	1-216-854-11	METAL CHIP	560K	5%	1/16W
R535	1-216-833-11	METAL CHIP	10K	5%	1/16W
R536	1-216-833-11	METAL CHIP	10K	5%	1/16W
R537	1-216-854-11	METAL CHIP	560K	5%	1/16W
R538	1-216-661-11	METAL CHIP	2.7K	0.5%	1/10W
R539	1-216-635-11	METAL CHIP	220	0.5%	1/10W
R540	1-216-655-11	METAL CHIP	1.5K	0.5%	1/10W
R541	1-216-837-11	METAL CHIP	22K	5%	1/16W
R543	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R544	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R545	1-216-837-11	METAL CHIP	22K	5%	1/16W
R546	1-216-839-11	METAL CHIP	33K	5%	1/16W
R547	1-216-821-11	METAL CHIP	1K	5%	1/16W
R548	1-216-821-11	METAL CHIP	1K	5%	1/16W
R549	1-216-864-11	METAL CHIP	0	5%	1/16W
R551	1-216-833-11	METAL CHIP	10K	5%	1/16W
R552	1-216-833-11	METAL CHIP	10K	5%	1/16W
R553	1-216-833-11	METAL CHIP	10K	5%	1/16W
R561	1-216-845-11	METAL CHIP	100K	5%	1/16W
R571	1-216-841-11	METAL CHIP	47K	5%	1/16W
R573	1-216-817-11	METAL CHIP	470	5%	1/16W
R574	1-216-821-11	METAL CHIP	1K	5%	1/16W
R575	1-216-813-11	METAL CHIP	220	5%	1/16W
R576	1-216-828-11	METAL CHIP	3.9K	5%	1/16W
R577	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
R578	1-216-815-11	METAL CHIP	330	5%	1/16W
R579	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R580	1-216-821-11	METAL CHIP	1K	5%	1/16W
R581	1-216-857-11	METAL CHIP	1M	5%	1/16W
R582	1-216-842-11	METAL CHIP	56K	5%	1/16W
R583	1-216-857-11	METAL CHIP	1M	5%	1/16W
R584	1-216-857-11	METAL CHIP	1M	5%	1/16W
R585	1-216-845-11	METAL CHIP	100K	5%	1/16W
R586	1-216-833-11	METAL CHIP	10K	5%	1/16W
R587	1-216-833-11	METAL CHIP	10K	5%	1/16W
R588	1-216-845-11	METAL CHIP	100K	5%	1/16W
R589	1-216-834-11	METAL CHIP	12K	5%	1/16W
R590	1-216-842-11	METAL CHIP	56K	5%	1/16W
R591	1-216-835-11	METAL CHIP	15K	5%	1/16W
R592	1-216-856-11	METAL CHIP	820K	5%	1/16W
R593	1-216-857-11	METAL CHIP	1M	5%	1/16W
R594	1-216-845-11	METAL CHIP	100K	5%	1/16W
R595	1-216-825-11	METAL CHIP	2.2K	5%	1/16W

**VC-85****MX-7PH**

Ref. No.	Part No.	Description	Remark		
R596	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
R597	1-216-826-11	METAL CHIP	2. 7K	5%	1/16W
R598	1-216-845-11	METAL CHIP	100K	5%	1/16W
R599	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
R607	1-216-832-11	METAL CHIP	8. 2K	5%	1/16W
R608	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
R609	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
R612	1-216-821-11	METAL CHIP	1K	5%	1/16W
R613	1-216-845-11	METAL CHIP	100K	5%	1/16W
R614	1-216-833-11	METAL CHIP	10K	5%	1/16W
R615	1-216-823-11	METAL CHIP	1. 5K	5%	1/16W
R616	1-216-833-11	METAL CHIP	10K	5%	1/16W
R668	1-216-821-11	METAL CHIP	1K	5%	1/16W
R705	1-216-836-11	METAL CHIP	18K	5%	1/16W
R706	1-216-835-11	METAL CHIP	15K	5%	1/16W
R707	1-216-821-11	METAL CHIP	1K	5%	1/16W
R708	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W
R710	1-216-834-11	METAL CHIP	12K	5%	1/16W
R711	1-216-835-11	METAL CHIP	15K	5%	1/16W
R714	1-216-864-11	METAL CHIP	0	5%	1/16W
R715	1-216-821-11	METAL CHIP	1K	5%	1/16W
R716	1-216-821-11	METAL CHIP	1K	5%	1/16W
R717	1-216-827-11	METAL CHIP	3. 3K	5%	1/16W
R718	1-216-821-11	METAL CHIP	1K	5%	1/16W
R719	1-216-832-11	METAL CHIP	8. 2K	5%	1/16W
R720	1-216-822-11	METAL CHIP	1. 2K	5%	1/16W
R721	1-216-833-11	METAL CHIP	10K	5%	1/16W
R722	1-216-821-11	METAL CHIP	1K	5%	1/16W
R723	1-216-837-11	METAL CHIP	22K	5%	1/16W
R724	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
R725	1-216-823-11	METAL CHIP	1. 5K	5%	1/16W
R726	1-216-864-11	METAL CHIP	0	5%	1/16W
R728	1-216-833-11	METAL CHIP	10K	5%	1/16W
R729	1-216-835-11	METAL CHIP	15K	5%	1/16W
R730	1-216-839-11	METAL CHIP	33K	5%	1/16W
R731	1-216-821-11	METAL CHIP	1K	5%	1/16W
R732	1-216-821-11	METAL CHIP	1K	5%	1/16W
R733	1-216-821-11	METAL CHIP	1K	5%	1/16W
R734	1-216-831-11	METAL CHIP	6. 8K	5%	1/16W
R735	1-216-833-11	METAL CHIP	10K	5%	1/16W
R736	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
R737	1-216-821-11	METAL CHIP	1K	5%	1/16W
R738	1-216-821-11	METAL CHIP	1K	5%	1/16W
R739	1-216-820-11	METAL CHIP	820	5%	1/16W
R740	1-216-821-11	METAL CHIP	1K	5%	1/16W
R741	1-216-821-11	METAL CHIP	1K	5%	1/16W
R742	1-216-837-11	METAL CHIP	22K	5%	1/16W
R743	1-216-839-11	METAL CHIP	33K	5%	1/16W
R745	1-216-830-11	METAL CHIP	5. 6K	5%	1/16W

Ref. No.	Part No.	Description	Remark		
R746	1-216-831-11	METAL CHIP	6. 8K	5%	1/16W
R747	1-216-821-11	METAL CHIP	1K	5%	1/16W
R748	1-216-134-00	METAL CHIP	2. 2	5%	1/8W
R749	1-216-821-11	METAL CHIP	1K	5%	1/16W
R750	1-216-821-11	METAL CHIP	1K	5%	1/16W
R751	1-216-833-11	METAL CHIP	10K	5%	1/16W
R752	1-216-833-11	METAL CHIP	10K	5%	1/16W
R753	1-216-864-11	METAL CHIP	0	5%	1/16W
R754	1-216-836-11	METAL CHIP	18K	5%	1/16W
R755	1-216-838-11	METAL CHIP	27K	5%	1/16W
R756	1-216-821-11	METAL CHIP	1K	5%	1/16W
R757	1-216-833-11	METAL CHIP	10K	5%	1/16W
R758	1-216-821-11	METAL CHIP	1K	5%	1/16W
R759	1-216-836-11	METAL CHIP	18K	5%	1/16W
R761	1-216-821-11	METAL CHIP	1K	5%	1/16W
R762	1-216-841-11	METAL CHIP	47K	5%	1/16W
R763	1-216-841-11	METAL CHIP	47K	5%	1/16W
R764	1-216-833-11	METAL CHIP	10K	5%	1/16W
R765	1-216-833-11	METAL CHIP	10K	5%	1/16W
R766	1-216-812-11	METAL CHIP	180	5%	1/16W
R767	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W
R768	1-216-834-11	METAL CHIP	12K	5%	1/16W
R770	1-216-835-11	METAL CHIP	15K	5%	1/16W
R771	1-216-864-11	METAL CHIP	0	5%	1/16W
R772	1-216-834-11	METAL CHIP	12K	5%	1/16W
R773	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
R775	1-216-836-11	METAL CHIP	18K	5%	1/16W
R776	1-216-816-11	METAL CHIP	390	5%	1/16W
R778	1-216-823-11	METAL CHIP	1. 5K	5%	1/16W
R779	1-216-839-11	METAL CHIP	33K	5%	1/16W
R780	1-216-837-11	METAL CHIP	22K	5%	1/16W
R781	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
R782	1-216-818-11	METAL CHIP	560	5%	1/16W
R783	1-216-817-11	METAL CHIP	470	5%	1/16W
R784	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
R785	1-216-817-11	METAL CHIP	470	5%	1/16W
R786	1-216-826-11	METAL CHIP	2. 7K	5%	1/16W
R787	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
R788	1-216-845-11	METAL CHIP	100K	5%	1/16W
R789	1-216-836-11	METAL CHIP	18K	5%	1/16W
R790	1-216-835-11	METAL CHIP	15K	5%	1/16W
R791	1-216-817-11	METAL CHIP	470	5%	1/16W
R792	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
R793	1-216-817-11	METAL CHIP	470	5%	1/16W
R794	1-216-826-11	METAL CHIP	2. 7K	5%	1/16W
R796	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
R797	1-216-864-11	METAL CHIP	0	5%	1/16W
R798	1-216-833-11	METAL CHIP	10K	5%	1/16W

**VC-85****MX-7PH**

Ref. No.	Part No.	Description	Remark		
R799	1-216-833-11	METAL CHIP	10K	5%	1/16W
R801	1-216-833-11	METAL CHIP	10K	5%	1/16W
R802	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R803	1-216-833-11	METAL CHIP	10K	5%	1/16W
R804	1-216-833-11	METAL CHIP	10K	5%	1/16W
R805	1-216-833-11	METAL CHIP	10K	5%	1/16W
R806	1-216-833-11	METAL CHIP	10K	5%	1/16W
R808	1-216-841-11	METAL CHIP	47K	5%	1/16W
R809	1-216-857-11	METAL CHIP	1M	5%	1/16W
R810	1-216-833-11	METAL CHIP	10K	5%	1/16W
R811	1-216-821-11	METAL CHIP	1K	5%	1/16W
R812	1-216-840-11	METAL CHIP	39K	5%	1/16W
R813	1-216-833-11	METAL CHIP	10K	5%	1/16W
R815	1-216-845-11	METAL CHIP	100K	5%	1/16W
R816	1-216-833-11	METAL CHIP	10K	5%	1/16W
R817	1-216-845-11	METAL CHIP	100K	5%	1/16W
R818	1-216-845-11	METAL CHIP	100K	5%	1/16W
R819	1-216-845-11	METAL CHIP	100K	5%	1/16W
R820	1-216-833-11	METAL CHIP	10K	5%	1/16W
R821	1-216-833-11	METAL CHIP	10K	5%	1/16W
R822	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R823	1-216-837-11	METAL CHIP	22K	5%	1/16W
R824	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R825	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
R826	1-216-833-11	METAL CHIP	10K	5%	1/16W
R827	1-216-845-11	METAL CHIP	100K	5%	1/16W
R828	1-216-833-11	METAL CHIP	10K	5%	1/16W
R831	1-216-864-11	METAL CHIP	0	5%	1/16W
R833	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R834	1-216-864-11	METAL CHIP	0	5%	1/16W
R835	1-216-837-11	METAL CHIP	22K	5%	1/16W
R836	1-216-837-11	METAL CHIP	22K	5%	1/16W
R837	1-216-833-11	METAL CHIP	10K	5%	1/16W
R844	1-216-817-11	METAL CHIP	470	5%	1/16W
R845	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R851	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R852	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R853	1-216-833-11	METAL CHIP	10K	5%	1/16W
R854	1-216-840-11	METAL CHIP	39K	5%	1/16W
R855	1-216-864-11	METAL CHIP	0	5%	1/16W
R856	1-216-831-11	METAL CHIP	6.8K	5%	1/16W
R857	1-216-835-11	METAL CHIP	15K	5%	1/16W
R859	1-216-134-00	METAL CHIP	2.2	5%	1/8W
R861	1-216-833-11	METAL CHIP	10K	5%	1/16W
R862	1-216-821-11	METAL CHIP	1K	5%	1/16W
R863	1-216-821-11	METAL CHIP	1K	5%	1/16W
R864	1-216-843-11	METAL CHIP	68K	5%	1/16W
R865	1-216-837-11	METAL CHIP	22K	5%	1/16W
R866	1-216-857-11	METAL CHIP	1M	5%	1/16W

Ref. No.	Part No.	Description	Remark		
R867	1-216-847-11	METAL CHIP	150K	5%	1/16W
R868	1-216-835-11	METAL CHIP	15K	5%	1/16W
R869	1-216-144-00	METAL CHIP	5.6	5%	1/8W
R872	1-216-857-11	METAL CHIP	1M	5%	1/16W
R873	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R874	1-216-837-11	METAL CHIP	22K	5%	1/16W
R876	1-216-837-11	METAL CHIP	22K	5%	1/16W
R877	1-216-841-11	METAL CHIP	47K	5%	1/16W
R878	1-216-839-11	METAL CHIP	33K	5%	1/16W
R881	1-216-837-11	METAL CHIP	22K	5%	1/16W
R882	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R883	1-216-840-11	METAL CHIP	39K	5%	1/16W
R884	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R885	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R886	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R887	1-216-833-11	METAL CHIP	10K	5%	1/16W
R888	1-216-833-11	METAL CHIP	10K	5%	1/16W
R889	1-216-838-11	METAL CHIP	27K	5%	1/16W
R890	1-216-840-11	METAL CHIP	39K	5%	1/16W
R891	1-216-815-11	METAL CHIP	330	5%	1/16W
R901	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R902	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R904	1-216-134-00	METAL CHIP	2.2	5%	1/8W
R905	1-216-144-00	METAL CHIP	5.6	5%	1/8W
R906	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R907	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R909	1-216-833-11	METAL CHIP	10K	5%	1/16W
R910	1-216-833-11	METAL CHIP	10K	5%	1/16W
R911	1-216-864-11	METAL CHIP	0	5%	1/16W
R913	1-216-833-11	METAL CHIP	10K	5%	1/16W
R914	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R915	1-216-864-11	METAL CHIP	0	5%	1/16W
R916	1-216-843-11	METAL CHIP	68K	5%	1/16W
R919	1-216-833-11	METAL CHIP	10K	5%	1/16W
R920	1-216-857-11	METAL CHIP	1M	5%	1/16W
R921	1-216-849-11	METAL CHIP	220K	5%	1/16W
R922	1-216-847-11	METAL CHIP	150K	5%	1/16W
R923	1-216-854-11	METAL CHIP	560K	5%	1/16W
R924	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R926	1-216-857-11	METAL CHIP	1M	5%	1/16W
R931	1-216-835-11	METAL CHIP	15K	5%	1/16W
R932	1-216-832-11	METAL CHIP	8.2K	5%	1/16W
R933	1-216-845-11	METAL CHIP	100K	5%	1/16W
R934	1-216-845-11	METAL CHIP	100K	5%	1/16W
R935	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R936	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R937	1-216-837-11	METAL CHIP	22K	5%	1/16W
R940	1-216-837-11	METAL CHIP	22K	5%	1/16W
R941	1-216-833-11	METAL CHIP	10K	5%	1/16W



## VC-85

## MX-7PH

## POWER BLOCK

Ref. No.	Part No.	Description	Remark		
R942	1-216-844-11	METAL CHIP	82K	5%	1/16W
R943	1-216-819-11	METAL CHIP	680	5%	1/16W
R944	1-216-864-11	METAL CHIP	0	5%	1/16W
R945	1-216-818-11	METAL CHIP	560	5%	1/16W
R946	1-216-828-11	METAL CHIP	3.9K	5%	1/16W
R947	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R949	1-216-821-11	METAL CHIP	1K	5%	1/16W
R950	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R952	1-216-845-11	METAL CHIP	100K	5%	1/16W
R953	1-216-837-11	METAL CHIP	22K	5%	1/16W
R954	1-216-820-11	METAL CHIP	820	5%	1/16W
R955	1-216-831-11	METAL CHIP	6.8K	5%	1/16W
R956	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R957	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R958	1-216-818-11	METAL CHIP	560	5%	1/16W
R959	1-216-833-11	METAL CHIP	10K	5%	1/16W
R960	1-216-821-11	METAL CHIP	1K	5%	1/16W
R961	1-216-824-11	METAL CHIP	1.8K	5%	1/16W
R962	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R963	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R964	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R965	1-216-821-11	METAL CHIP	1K	5%	1/16W
R966	1-216-685-11	METAL CHIP	27K	0.5%	1/10W
R967	1-216-675-11	METAL CHIP	10K	0.5%	1/10W
R968	1-216-675-11	METAL CHIP	10K	0.5%	1/10W
R969	1-216-833-11	METAL CHIP	10K	5%	1/16W
R970	1-216-833-11	METAL CHIP	10K	5%	1/16W
R971	1-216-839-11	METAL CHIP	33K	5%	1/16W
R972	1-216-813-11	METAL CHIP	220	5%	1/16W
R973	1-216-813-11	METAL CHIP	220	5%	1/16W
R974	1-216-813-11	METAL CHIP	220	5%	1/16W
R981	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R982	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R987	1-216-833-11	METAL CHIP	10K	5%	1/16W
R988	1-216-837-11	METAL CHIP	22K	5%	1/16W
R989	1-216-837-11	METAL CHIP	22K	5%	1/16W
R993	1-216-833-11	METAL CHIP	10K	5%	1/16W
R994	1-216-833-11	METAL CHIP	10K	5%	1/16W
R995	1-216-833-11	METAL CHIP	10K	5%	1/16W
R996	1-216-837-11	METAL CHIP	22K	5%	1/16W
R997	1-218-295-11	METAL GLAZE	43K	5%	1/16W
R998	1-216-837-11	METAL CHIP	22K	5%	1/16W
R999	1-216-837-11	METAL CHIP	22K	5%	1/16W
< VARIABLE RESISTOR >					
RV101	1-238-093-11	RES. ADJ CERMET 100K			
RV102	1-237-776-11	RES. VAR. CARBON 10K (COLOUR)			
RV104	1-230-661-11	RES. VAR. CARBON 10K (CLOSE/OPEN)			
RV509	1-238-092-11	RES. ADJ CERMET 47K			

Ref. No.	Part No.	Description	Remark
RV510	1-238-092-11	RES. ADJ CERMET 47K	
RV511	1-238-092-11	RES. ADJ CERMET 47K	
RV512	1-238-092-11	RES. ADJ CERMET 47K	
RV851	1-238-093-11	RES. ADJ CERMET 100K	

## &lt; SWITCH &gt;

S102	1-571-787-11	SWITCH, TACTILE (IRIS MANUAL)	
S103	1-571-787-11	SWITCH, TACTILE (WHT BAL HOLD)	
S114	1-570-865-11	SWITCH, SLIDE (NEGA/POSI)	

## &lt; VIBRATOR &gt;

X101	1-527-997-21	VIBRATOR, CRYSTAL (32.768KHz)	
X801	1-577-118-11	VIBRATOR, LITHIUM NIOBATE (4MHz)	

\*\*\*\*\*

## △ 1-413-623-21 POWER BLOCK BOARD

\*\*\*\*\*

(Ref. No 9, 000 Series)

## &lt; CAPACITOR &gt;

C001	△ 9-900-653-01	FILM	0.22uF	250V
C002	△ 9-998-435-01	CERAMIC	2200PF	125V
C003	△ 9-998-435-01	CERAMIC	2200PF	125V
C004	1-161-953-12	CERAMIC	4700PF	125V
C005	△ 9-998-433-01	FILM	0.1uF	250V
C006	9-900-655-01	ELECT	47uF	450V
C007	9-900-654-01	FILM	0.01uF	630V
C009	9-998-431-01	FILM	0.0047uF	100V
C010	△ 1-161-953-12	CERAMIC	4700PF	125V
C011	△ 1-161-953-12	CERAMIC	4700PF	125V
C101	9-998-438-01	ELECT	680uF	16V
C102	9-998-439-01	ELECT	0.47uF	50V
C103	9-998-436-01	CERAMIC	100PF	50V
C104	9-998-440-01	ELECT	330uF	16V
C105	- - -		0.047uF	
C201	9-998-441-01	ELECT	1800uF	10V
C202	9-998-442-01	ELECT	4.7uF	35V
C203	9-998-436-01	CERAMIC	100PF	50V
C204	1-106-206-12	FILM	0.01uF	100V
C205	9-998-443-01	ELECT	1000uF	10V

## &lt; CONNECTOR &gt;

CN001	△ 9-998-481-01	PIN, CONNECTOR (PC BOARD) 2P (250V, 7A)	
CN002	9-998-482-01	PIN, CONNECTOR (PC BOARD) 4P (125V, 1A)	
CN003	9-998-483-01	PIN, CONNECTOR (PC BOARD) 3P (125V, 1A)	
CN01	9-998-484-01	PIN, CONNECTOR (PC BOARD)	
CN02	9-998-484-01	PIN, CONNECTOR (PC BOARD)	

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

# POWER BLOCK

Ref. No.	Part No.	Description	Remark
< DIODE >			
D001	△ 8-719-510-06	DIODE SIW860	
D002	9-998-444-01	DIODE 1SS178	
D101	8-719-948-59	DIODE ERB93-02	
D102	9-998-446-01	DIODE RD15ESAB	
D201	8-719-510-37	DIODE D5LC20U	
D202	9-998-444-01	DIODE 1SS178	
D203	9-998-444-01	DIODE 1SS178	
D204	9-998-444-01	DIODE 1SS178	
D205	9-998-448-01	DIODE RD6.8ESAB	
D206	9-900-656-01	DIODE RD15FB2	
< FUSE >			
F001	△ 9-900-661-01	FUSE 250V 1.6A	
< IC >			
IC001	△ 8-749-920-45	IC MA1050	
IC101	9-998-450-01	IC NJM431L	
IC201	8-759-135-80	IC uPC358C	
< COIL >			
L001	△ 9-900-659-01	FILTER, LINE 5mH 0.5A (SU10V-03100)	
L003	9-900-665-01	(B-01-RTF)	
L101	9-998-457-01	CORE, DRUM	
< PHOTO COUPLER >			
PC001	△ 9-900-658-01	PHOTO COUPLER PC111	
< TRANSISTOR >			
Q201	△ 9-998-454-01	TRANSISTOR 2SA1307	
Q202	9-998-455-01	TRANSISTOR 2SC1815	
Q203	9-998-455-01	TRANSISTOR 2SC1815	
< RESISTOR >			
R001	△ 9-900-662-01	CEMENT 4.7	2W
R002	9-900-663-01	METAL OXIDE 150K	2W
R004	9-998-478-01	CARBON 390	1/6W
R005	9-998-478-01	CARBON 390	1/6W
R006	9-998-464-01	CARBON 100	1/6W
R101	9-998-465-01	CARBON 330	1/6W
R102	9-998-465-01	CARBON 330	1/6W
R103	9-998-466-01	CARBON 10K	1/6W
R104	9-998-466-01	CARBON 10K	1/6W
R105	9-998-467-01	CARBON 2.2K	1/6W
R106	9-998-463-01	CARBON 47	1/6W
R107	9-998-468-01	CARBON 1K	1/6W
R201	9-998-468-01	CARBON 1K	1/6W
R202	9-998-471-01	CARBON 22	1/2W
R203	9-998-468-01	CARBON 1K	1/6W

Ref. No.	Part No.	Description	Remark
R204	9-998-472-01	CARBON 4.7K	1/6W
R205	9-998-473-01	METAL 15K	1/6W
R206	9-998-468-01	CARBON 1K	1/6W
R207	9-998-472-01	CARBON 4.7K	1/6W
R208	9-998-474-01	CARBON 100K	1/6W
R209	9-998-475-01	CARBON 220	1/6W
R210	9-998-476-01	CEMENT 0.1	2W
R211	9-998-477-01	CARBON 6.8K	1/6W
R212	9-998-475-01	CARBON 220	1/6W
R213	9-998-478-01	CARBON 390	1/6W
R214	9-998-468-01	CARBON 1K	1/6W
R215	9-998-471-01	CARBON 22	1/2W
R216	- - -	10K	

## < THYRISTOR >

SR101 △ 9-998-452-01 THYRISTOR SF3GZ47 (400V, 3A)

## < TRANSFORMER >

T001 △ 9-900-660-01 TRANSFORMER, CONVERTER (N-T00-516)

## < VARIABLE RESISTOR >

VR101 9-998-480-01 RES, ADJ 1K

VR201 9-998-462-01 RES, ADJ 1K

\*\*\*\*\*

## MISCELLANEOUS

\*\*\*\*\*

53 1-518-679-11 FLUORESCENT TUBE  
 56 △ 1-466-504-21 INVERTER, DC-AC  
 63 1-466-230-21 CONVERTER UNIT, D/D  
 64 △ 1-555-795-00 CORD, POWER, EULO PLUG  
 78 1-641-286-11 FP-480 FLEXIBLE BOARD (AEP)

110 1-547-381-12 FILTER BLOCK, OPTICAL  
 116 1-547-480-11 LENS, ZOOM  
 IC601 8-752-604-70 IC ICX039AN-1 (CCD IMAGER)  
 S901-2 △ 1-572-810-11 SWITCH, SEESAW (AC POWER)

\*\*\*\*\*

## ACCESSORIES & PACKING MATERIALS

\*\*\*\*\*

X-3940-412-1 CARRIER (N) ASSY, FILM  
 X-3941-134-1 CARRIER ASSY, P (AEP)  
 1-574-039-11 CORD, CONNECTION  
 3-752-973-11 MANUAL, INSTRUCTION (ENGLISH)  
 3-752-973-41 MANUAL, INSTRUCTION (AEP)  
 (DUTCH, SWEDISH, ITALIAN, PORTUGUESE)

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Ref. No.	Part No.	Description	Remark
	3-752-973-61	MANUAL, INSTRUCTION (E) (CHINESE, ARABIC)	
	3-752-973-71	MANUAL, INSTRUCTION (AEP) (FRENCH, GERMAN, SPANISH)	
*	3-941-787-01	CUSHION (UPPER)	
*	3-941-788-01	CUSHION (LOWER)	
*	3-941-789-21	INDIVIDUAL CARTON	
	3-941-887-01	CARRIER (POS1), FILM	
	3-942-328-11	COVER, DUST	

\*\*\*\*\*

#### HARDWARE LIST

\*\*\*\*\*

#1	7-685-534-19	SCREW +BTP 2.6X8	TYPE2 N-S
#2	7-621-773-95	SCREW +B 2.6X6	
#3	7-621-770-87	SCREW +P 2.6X5	
#4	7-621-555-10	SCREW +K 2X3	
#5	7-621-255-15	SCREW +P 2X3	
#6	7-685-645-79	SCREW +BTP 3X6	TYPE2 N-S
#7	7-685-104-19	SCREW +P 2X6	TYPE2 NON-SLIT
#8	7-621-281-15	SCREW +P 2X2	
#9	7-621-255-75	SCREW +P 2X12	TYPE2 NON-SLIT
#10	7-621-555-30	SCREW +K 2X5	
#11	7-621-772-50	SCREW +B 2X10	
#12	7-621-775-08	SCREW +P 2.6X3	
#13	7-685-132-19	SCREW +P 2.6X5	TYPE2 NON-SLIT
#14	7-685-133-19	SCREW +P 2.6X6	TYPE2 SLIT
#15	7-685-134-19	SCREW +P 2.6X8	TYPE2 NON-SLIT

\*\*\*\*\*

## 7. ELECTRICAL ADJUSTMENT

When performing adjustment, refer to the parts arrangement diagram from page 160.

### 7-1. PREPARATIONS FOR ADJUSTMENT

#### 7-1-1. Servicing tools

- Oscilloscope
- Regulated power supply (2 units)
- Vectorscope
- Adjusting screw driver
- Color monitor
- Digital voltmeter

Ref.	No.	Part Name	Part No.
J-1	ND filter 0.3	J-6080-818-A	Focus adjustment (2 pcs)
	ND filter 1.0	J-6080-808-A	Focus adjustment (2 pcs) Auto focus confirmation
	ND filter 0.4	J-6080-806-A	Positive iris adjustment
	ND filter 0.1	J-6080-807-A	Positive iris adjustment Auto focus confirmation (2 pcs)
J-2	Color bar chart	J-6082-126-A	
	Negative color bar chart	J-6082-127-A	
J-3	Siemens star chart	J-6082-130-A	Focus adjustment, auto focus adjustment
J-4	AF microprocessor data reading tool	J-6082-025-A	
J-5	Adjustment remote controller (RM-95 partly improved)	J-6082-053-A	
J-6	White balance chart (gray)	J-6082-129-A	
	Negative white balance chart (orange)	J-6082-128-A	
J-7	Inmega cycle chart	J-6082-125-A	
J-8	CPA connector jig	J-6082-109-A	Check point array on the VC-85 board

\*1 PTB-500 (J-6029-140-A) is also available.




Fig. 7-1.



### 7-1-2. Preparation

**Note:** Refer to "2. REMOVAL" for the details of the removal of the cabinet or various boards.

- 1) Connect the adjusting equipments as shown in Fig. 5-2.




Fig. 7-2.

### 7-1-3. Precautions

#### 1. Setting of switches

Performing adjustment by setting the switches in the following positions unless otherwise specified.

1. Perform adjustment by setting the adjustment data of the adjustment address 75 (AWB MODE) to 00 unless otherwise specified. Be sure to return the data to F0 after adjustment.
2. "IRIS (CLOSE/OPEN)" control (RV104 on the VC-85 board) .....center position
3. "COLOUR" control (RV102 on the VC-85 board) .....center click position
4. "NEGA/POSI" selection (S114 on the VC-85 board) positive
5. "IRIS (PUSH MANUAL)" button (S102 on the VC-85 board) ..... "AUTO" (LED off)
6. "WHT BAL (PUSH HOLD)" button (S103 on the VC-85 board) ..... "AUTO" (LED off)
7. "COLOUR BALANCE (ON/OFF)" button (S115 on the FA-1 board) ..... OFF (LED off)

#### 2. Adjustment order

As a rule, perform adjustments according to the described order.

#### 3. Subject

- 1) Color bar chart (standard picture frame)  
When performing adjustment using the color bar chart, adjust the picture frame as in the Fig. 7-3. (standard picture frame)
- 2) White pattern (standard picture frame)  
Remove the color bar chart and adjust with the zoom button so that the white pattern has the same size and position as the color bar chart (standard picture frame).
- 3) Siemens star chart  
Adjust the chart position so that the centers of the siemens star and monitor screen overlap each other on the monitor display.




Fig. 7-3.

- 4) Negative color bar chart (standard picture frame)  
Adjust the picture frame in the same manner as (positive) color bar chart.

Actual colors displayed on the negative color bar chart and colors displayed on the monitor TV are shown in the figure below.




Fig. 7-4.

- 5) White balance chart (gray) and negative white balance chart (orange) (Standard picture frame)

Move the picture frame to the TELE side until it stops. Set the border line between white/gray and white/orange to the center.




Fig. 7-5.

- 6) Inmega cycle chart

Set the monitor TV in to under scan condition and adjust the picture frame as in the figure below.




Fig. 7-6.

#### 7-1-4. Adjustment remote controller

The camera block employs EVR (electronic volume) as an adjustment element in place of conventional semi-fixed resistor. The EVR is controlled by EVR/AWB microprocessor (IC802 on VC-85 board). This microprocessor reads out the data written in the non-volatile memory within the microprocessor and sends it to EVR. The EVR makes the data (8-bit per each adjustment point) D/A conversion to generate the adjusting voltage.

It is necessary to change the adjustment data written in the non-volatile memory to adjust the camera block. For this purpose, adjustment remote controller is used.

The adjustment remote controller performs bi-directional communication with the camera block microprocessor using the remote controller signal line (LANC). The adjustment address and adjustment data up/down command are sent from the adjustment remote controller to the camera block microprocessor. The adjustment address and adjustment data are sent from the camera block microprocessor to the adjustment remote controller.

#### 1. Use of adjustment remote controller

- 1) Connect the adjustment remote controller to the remote terminal (J202 on VC-85 board). (Set the HOLD switch of the adjustment remote controller to the HOLD position:service position.)
- 2) Turn ON the power of the main unit.
- 3) Connect with the jumper wire between TP106 or the Pin (B6) (CAM ADJ) of the check point array and GND (TP105).

(This connection stops ordinary remote control operation for EVR/AWB microprocessor and starts exclusive adjustment communication.)

**Note:** Be sure to make this connection after turning the power ON. If connection is correct, the display below is shown on the LCD of the adjustment remote controller. (Adjustment data depends on unit.)




Fig. 7-7.

- 4) Designate the desired adjustment address using the adjustment remote controller.  
Adjustment address is increased by pressing FF (▶▶) button.  
Adjustment address is decreased by pressing REW (◀◀) button.  
The adjustment address is shown in hexadecimal. There are 117 addresses from 01 to 75. The adjustment addresses correspond to EVR output terminals (IC703, IC706 and IC902 on VC-85 board). Refer to the table 7-3 for the adjustment contents of each address.

- 5) Perform adjustment by increasing or decreasing the adjustment data.

Adjustment data is increased by pressing PLAY (▶) button.  
Adjustment data is decreased by pressing STOP (■) button.

- The adjustment address is shown in hexadecimal. There are 256 values from 00 to FF.

Hexadecimal	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
Display on LCD	0	1	2	3	4	5	6	7	8	9	A	b	c	d	e	F
Decimal equivalent	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

Table 7-1.

- The adjustment data corresponds to the output voltage of EVR (IC703, IC706 and IC902 on the VC-85 board) and shown below.

Adjustment data ( ) shows decimal equivalent	EVR output voltage
FF (=255)	Maximum value (approx. 5 Vdc)
F0 (=240)	
E0 (=224)	
D0 (=208)	
C0 (=192)	
B0 (=176)	
A0 (=160)	
90 (=144)	
80 (=128)	Center value (approx. 2.5 Vdc)
70 (=112)	
60 (=96)	
50 (=80)	
40 (=64)	
30 (=48)	
20 (=32)	
10 (=16)	
00 (=0)	Minimum value (approx. 0 Vdc)

Table 7-2.

- 6) To store the adjustment data in the non-volatile memory within EVR/AWB microprocessor (IC802 on VC-85 board), change the adjustment address by FF (▶▶) button or REW (◀◀) button.  
(If this procedure is not performed, a new adjustment data is not stored in the non-volatile memory.)



## 2. Precautions on use of adjustment remote controller

The correct adjustment data may be erased by mis-operation of the adjustment remote controller. To prevent this, it is recommended to record all the adjustment data and to record a new adjustment data after each step is completed.

**Note:** Data already described in the recording for adjustment data memo column is fixed data.

Adjustment address	Adjusting voltage output terminal	Adjustment item	Remarks	Adjustment data memo column
01	Pin ⑮ of IC703	DELTA R	White balance adjustment	
02	Pin ⑰ of IC703	DELTA B		
03				00
04	Pin ③ of IC703	C2 GAIN	Chroma signal matrix adjustment (2)	
05	Pin ④ of IC703	NEGA R-Y GAIN	Negative color reproduction adjustment	
06	Pin ⑤ of IC703	NEGA B-Y GAIN		
07	Pin ⑥ of IC703	NEGA R-Y HUE		
08	Pin ⑦ of IC703	NEGA B-Y HUE		
09	Pin ⑧ of IC703	NEGA C $\gamma$		D0
0A	Pin ⑨ of IC703	C LEVEL	Chroma level adjustment	
0B	Pin ⑫ of IC703	NEGA R GAIN	Negative pre-white balance adjustment	
0C	Pin ⑬ of IC703	NEGA B GAIN		
0D	Pin ⑮ of IC706	NEGA PED		
0E	Pin ⑰ of IC706	C1 GAIN	Chroma signal matrix adjustment (1)	
0F	Pin ② of IC706	Y1 GAIN	Y signal matrix adjustment	
10	Pin ③ of IC706	WC	White clip adjustment	
11	Pin ④ of IC706	SET UP		
12	Pin ⑤ of IC706	SYNC LEVEL		
13	Pin ⑥ of IC706	YH LEVEL		
14	Pin ⑦ of IC706	APERTURE		
15	Pin ⑧ of IC706	POSI Y LEVEL		
16	Pin ⑨ of IC706	BURST LEVEL		
17	Pin ⑫ of IC706	HUE CONT	Burst phase adjustment	
18	Pin ⑬ of IC706	NEGA Y LEVEL		
19	Pin ⑰ of IC902	POSI IRIS		
1A	Pin ⑰ of IC902	POSI R GAIN	Positive pre-white balance adjustment	
1B	Pin ② of IC902	HALL OFFSET	Hall adjustment	
1C	Pin ③ of IC902	POSI B GAIN	Positive pre-white balance adjustment	
1D	Pin ④ of IC902	PG CONT		
1E	Pin ⑤ of IC902	V SUB		
1F	Pin ⑥ of IC902	NEGA IRIS		
20	Pin ⑦ of IC902	AGC		FF
21	Pin ⑧ of IC902	NEGA Y- $\gamma$		70
22	Pin ⑨ of IC902			00
23	Pin ⑫ of IC902			00
24	Pin ⑬ of IC902	MGC		00

Table 7-3. (1)

Adjustment address	Adjusting voltage output terminal	Adjustment item	Remarks		Adjustment data memo column
25		MODE	The following adjustment modes are selected by changing the adjustment data.		00
			Adjustment data	Adjustment mode	
			00	Release	
			01	Focus hunching	
			03	Zoom position	
			05	Hall, iris close	
			07	Hall, iris open	
			09	Iris A/D converted value	
			0B	AGC A/D converted value	
			FD	Auto focus filter fixed at FA.	
FF	Auto focus filter fixed at FH.				
26		LLA	Low illuminance display threshold		3F
27		MACRO	Macro position		00
28		IN/OUT DOOR	Indoor/outdoor discrimination		00
29		STEP A	Number of motor FG for peak searching		04
2A		BASE-H	Low contrast start threshold		18
2B		STILL-THR1	Still area threshold (1)		04
2C		SEARCH-THR	Top check area threshold		10
2D		HALL OUT	AWB indoor/outdoor discrimination threshold		14
2E		HALL IN			18
2F		TC-COUNTER			01
30		FH-W	FH evaluation value at all white	Auto focus adjustment	
31		FH-B	FH evaluation value at all black		
32		AGC-W	AGC A/D converted value at all white		
33		AGC-B	AGC A/D converted value at all black		
34		BACKRUSH	Backrush compensation amount		01
35		FG-SPEED	Focus speed setting		02
36		STILL-THR2	Still area threshold (2)		02
37		STILL-THR3	Still area threshold (3)		01
38		LC-THR	Threshold at low contrast		10
39		R32MSB	Preset data (The data in the column are automatically input when adjusting auto white balance.)		
3A		R32LSB			
3B		B32MSB			
3C		B32LSB			
3D		G32MSB			
3E		G32LSB			
3F		START R	R CONT and B CONT data at auto white balance operation starting	Auto white balance fixed data	26
40		START B			51
41		TM DIVID	Border value of the tracking frame		44
42		BM DIVID	Border value of the tracking frame		28
43		TOP SLP R	R CONT coefficient of the upper step of the tracking frame		80
44		TOP SLP B	B CONT coefficient of the upper step of the tracking frame Auto white		20

Table 7-3. (2)

Adjustment address	Adjusting voltage output terminal	Adjustment item	Remarks		Adjustment data memo column
45		MDL SLP R	R CONT and B CONT coefficient of the middle step of the tracking frame	Auto white balance fixed data	40
46		MDL SLP B			40
47		BTM SLP R			20
48		BTM SLP B			40
49		KIKO R			80
4A		KIKO B			30
4B		TOP UP	Upper and lower limit frames of the upper step of the tracking frame		85
4C		TOP DWN			67
4D		MDL UP	Upper and lower limit frames of the upper, middle and lower steps of the tracking frame		70
4E		MDL DWN			6B
4F		BTM UP			52
50		BTM DWN			3C
51		KEIKO DWN			7F
52		R DWN LMT	R CONT data upper and lower limit of the tracking frame		23
53		R UP LMT			64
54		B UP LMT	B CONT data upper limit of the tracking frame		7A 55
55		IN BTOP			46
56		IN BMAX	INDOOR operation frame upper limit of the tracking frame INDOOR mode		46
57		OUT BMIN	B CONT data upper limit		3A
58		OUT BTM	OUTDOOR mode B CONT data lower limit		1C
59		B DWN LMT	OUTDOOR mode operation frame lower limit frame of the tracking frame		25 55 20
5A		R OUTDOOR	B CONT data lower limit of the tracking frame		26
5B		B OUTDOOR			34
5C		Ra	White balance preset data R CONT and B CONT data of the points a, b and c on the curve of blackbody radiation		65
5D		Rb			51
5E		Rc			3D
5F		Ba			13
60		Bb			2D
61		Bc			3B
62		R/B TOP	Incline data of the curve of blackbody radiation		35
63		R/B MDL			16
64		R/B DWN			11
65		B/R TOP			90
66		B/R MDL			08
67		B/R DWN			
68		KEIKO	Indoor AWB data		
69		LL LMT	Minimum tracking illuminance		

Table 7-3. (3)

Adjustment address	Adjusting voltage output terminal	Adjustment item	Remarks		Adjustment data memo column
6A		B HUE KEI	Variable linear matrix data	Auto white balance fixed data	18
6B		R GAIN OFF			30
6C		R GAIN KEI			20
6D		R HUE OFF			37
6E		R HUE KEI			1E
6F		DELAY TM	Tracking speed		10
70		FAST TM	Initial high speed tracking times		30
71		CAM DDS O	Fixed data		00
72		MODE			09
73		DSP MODE			00
74		CAM ALN			00
75		AWB MODE	The following auto white balance adjustment modes are selected by changing the adjustment data.		F0
			Adjustment data	Adjustment mode	
			00	Setting at adjustment	
			10 E0	Auto white balance adjustment mode	
			F0	3200K preset data read mode	
				Auto white balance tracking zone discrimination invalid, all area discrimination mode and setting at shipping	

Table 7-3. (4)



### 7-1-5. Check Point Array

Most of measurement points for camera block adjustment are placed on the check point array on the VC-85 board. Solder short lead wires to terminals necessary for adjusting and connect oscilloscope, etc. The terminal numbers and signal names are shown in the Table 7-4.

**Note:** The CPA connector jig (J-6082-109-A) allows you to connect an oscilloscope easily.

Terminal No.	Signal name	Terminal No.	Signal name
A1	G OUT	B1	WB ADJ
A2	PG CONT	B2	N.C
A3	N.C	B3	Y(LPF)OUT
A4	Y0	B4	V SUB
A5	Y1	B5	AW ADJ
A6	C0	B6	CAM ADJ
A7	C1	B7	MODE
A8	CAM Y	B8	ID
A9	YH	B9	N.C
A10	N.C	B10	GND
A11	N.C	B11	CCD OUT

※ N.C...no connection

Table 7-4.




Fig. 7-8.

### 7-1-6. AF Microprocessor Data Reading Tool

The AF microprocessor data reading tool converts the serial data (output data varies according to hall (iris) state, focus state, focus motor speed, zoom ring position, etc.) for adjustment output from the AF microprocessor (IC905 on VC-85 board) into a 2-digit hexadecimal code and displays it on the LED.

#### Connection

Connect as follows.




Fig. 7-9.

### 7-1-7. Data Processing

Some adjustment items require calculation from the data (hexadecimal) indicated on the reading tool for AF microprocessor adjustment remote controller to obtain the adjustment data. In this case, convert hexadecimal values into decimal and perform calculation, then convert the result into hexadecimal to make adjustment data. Hexadecimal to decimal conversion table is shown in the table 7-5.

Hexadecimal to decimal conversion table

Hexadecimal upper digit	Hexadecimal lower digit															
	0	1	2	3	4	5	6	7	8	9	A (H)	B (b)	C (c)	D (d)	E (E)	F (F)
0	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
2	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
3	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
4	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79
5	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95
6	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111
7	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127
8	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143
9	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159
A (H)	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175
① → B (b)	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191
C (c)	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
D (d)	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223
E (E)	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239
F (F)	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255

**Note:** ( ) is the indication on the tool or adjustment remote controller

**Example:** Indication on the tool or adjustment remote controller is BD ( b d ).

Upper digit is B ( b ) and lower digit is D ( d ) in hexadecimal, so "189" in decimal value is obtained from the intersection of ① and ② in the above table.

Table 7-5.

## 7-2. FOCUS ADJUSTMENT

Subject	Siemens star
Filter	ND filter 1.0 (2 pcs) and 0.3 (2 pcs)
Measurement Point	Monitor TV
Measuring Equipment	
Adjustment Element	Front lens ring

Adjusting method:

- 1) Connect a jumper wire between TP151 on the FA-1 board and GND (frame).
- 2) Attach ND filter 2.6 (1.0+1.0+0.3+0.3) to the lens.
- 3) Press the zoom W button (S111 on FA-1 board) to set WIDE end.
- 4) Press the focus push auto (S101 on FA-1 board) and release it when focus is matched.
- 5) Press the zoom T button (S112 on FA-1 board) to set TELE end.
- 6) Rotate the front lens ring and adjust the focus.
- 7) Repeat steps 3) to 6), fix the front lens ring so that focus is matched on both WIDE end and TELE end. (Fix with adhesive tape.)
- 8) Disconnect a jumper wire between TP151 on FA-1 board and GND (frame).




Fig. 7-10.

## 7-3. ELECTRICAL ADJUSTMENT

### 7-3-1. Power Supply Check

#### 1. Power source block check (power source block)

Measuring Equipment	Digital voltmeter
6V Check	
Measurement Point	Pin ① of CN3 and Pin ① of CN203 on VC-85 board
Specified Value	$6.0 \pm 0.5$ Vdc
12 V Check	
Measurement Point	Pin ① of CN2
Specified Value	$12.0 \pm 0.5$ Vdc

Checking method:

- 1) Each power supply voltage should meet the specified value.

#### 2. DC-DC converter check (VC-85 board)

Measuring Equipment	Digital voltmeter
CAM 5V Check	
Measurement Point	Pin ④ of CN701
Specified Value	$4.9 \pm 0.5$ Vdc
5V Check	
Measurement Point	Pin ③ of CN702
Specified Value	$4.9 \pm 0.5$ Vdc
15V Check	
Measurement Point	Pin ① of CN7022
Specified Value	$15.0 \pm 0.5$ Vdc
-9V Check	
Measurement Point	Pin ② of CN702
Specified Value	$-9.0 \pm 0.5$ Vdc

Checking method:

- 1) Each power voltage should meet the specified value.

### 7-3-2. DDS Microprocessor System Clock Adjustment (VC-85 Board)

Measurement Point	TP101 (Pin ⑬ of IC101)
Measuring Equipment	Frequency counter (Note)
Adjustment Element	RV101
Specified Value	$330 \pm 5$ kHz

**Note:** Use a probe of low capacity (10 PF or less) and high resistance (1 M $\Omega$  ).

Connection:

- 1) Connect with a jumper wire between TP102 (Pin ⑳ of IC101) and GND.

Adjusting method:

- 1) Adjust with RV101 for  $330 \pm 5$  kHz.

### 7-3-3. DDS Microprocessor Clock Check (VC-85 board)

Measurement Point	TP103 (Pin ④ of IC101)
Measuring Equipment	Frequency counter
Specified Value	$8.192 \pm 0.001$ kHz

Connection:

- 1) Connect with a jumper wire between TP102 (Pin ⑳ of IC101) and GND.

Checking method:

- 1) Oscillation frequency should meet the specified value.

### 7-3-4. PLL Adjustment (GE-10 Board)

Object	Optional
Measurement Point	CL664 (See Fig. 7-11) or Pin ⑳ of IC621
Measuring Equipment	Digital voltmeter
Adjustment Element	CT621
Specified Value	$2.5 \pm 0.2$ Vdc

Adjustment method:

- 1) Adjust to  $2.5 \pm 0.2$  Vdc with CT621.




Fig. 7-11.



### 7-3-5. EVR Initial Settings

Set the adjustment data of the adjustment address 75 to 00. With other adjustment addresses, set the adjustment data to the initial value only when EVR/AWB microprocessor (IC802 on VC-85 board) was replaced.

Be sure to return the adjustment data of the adjustment address 75 to F0 after adjustment is completed.

Adjusting method:

- 1) Set the adjustment data of each adjustment address to the initial value by the adjustment remote controller.
- 2) Change the adjustment address to store the last adjustment data in the memory.

Adjustment address	Adjustment data initial value	Adjustment address	Adjustment data initial value	Adjustment address	Adjustment data initial value
01 (DELTA R)	50	26 (LLA)	3F	51 (KEIKO DWN)	7F
02 (DELTA B)	50	27 (MACRO)	00	52 (R DWN LMT)	23
03	00	28 (IN/OUT DOOR)	00	53 (R TOP LMT)	64
04 (C2 GAIN)	C0	29 (STEP A)	04	54 (B UP LMT)	7A
05 (NEGA R-Y GAIN)	E0	2A (BASE-H)	18	55 (IN B TOP)	55
06 (NEGA B-Y GAIN)	CA	2B (STILL-THR1)	04	56 (IN B MAX)	46
07 (NEGA R-Y HUE)	C3	2C (SEARCH-THR)	10	57 (OUT B MAX)	46
08 (NEGA B-Y HUE)	CB	2D (HALL OUT)	14	58 (OUT B DWN)	3A
09 (NEGA C- $\gamma$ )	D0	2E (HALL IN)	18	59 (B DWN LMT)	1C
0A (C LEVEL)	B6	2F (TC-COUNTER)	01	5A (R OUTDOOR)	25
0B (NEGA R GAIN)	83	30 (FH-W)	00	5B (B OUTDOOR)	55
0C (NEGA B GAIN)	7F	31 (FH-B)	00	5C (Ra)	20
0D (NEGA PED)	89	32 (AGC-W)	00	5D (Rb)	26
0E (C1 GAIN)	C0	33 (AGC-B)	00	5E (Rc)	34
0F (Y1 GAIN)	C0	34 (BACKRUSH)	01	5F (Ba)	65
10 (WC)	A8	35 (FG-SPEED)	02	60 (Bb)	51
11 (SET UP)	90	36 (STILL-THR2)	02	61 (Bc)	3D
12 (SYNC LEVEL)	90	37 (STILL-THR3)	01	62 (R/B TOP)	13
13 (YH LEVEL)	D0	38 (LC-THR)	10	63 (R/B MDL)	2D
14 (APERTURE)	90	3F (START R)	26	64 (R/B DWN)	3B
15 (POSI Y LEVEL)	95	40 (START B)	51	65 (B/R TOP)	35
16 (BURST LEVEL)	A0	41 (TM DIVID)	44	66 (B/R MDL)	16
17 (HUE CONT)	AE	42 (BM DIVID)	28	67 (B/R DWN)	11
18 (NEGA Y LEVEL)	C3	43 (TOP SLP R)	80	68 (KEIKO)	90
19 (POSI IRIS)	80	44 (TOP SLP B)	20	69 (LL LMT)	08
1A (POSI R GAIN)	80	45 (MDL SLP R)	40	6A (B HUE KEI)	18
1B (HALL OFFSET)	2E	46 (MDL SLP B)	40	6B (R GAIN OFF)	30
1C (POSI B GAIN)	7E	47 (BTM SLP R)	20	6C (R GAIN KEI)	20
1D (PG CONT)	A0	48 (BTM SLP B)	40	6D (R HUE OFF)	37
1E (V SUB)	B0	49 (KEIKO R)	80	6E (R HUE KEI)	1E
1F (NEGA IRIS)	80	4A (KEIKO B)	30	6F (DELAY TM)	10
20 (AGC)	FF	4B (TOP UP)	85	70 (FAST TM)	30
21 (NEGA Y- $\gamma$ )	70	4C (TOP DOWN)	67	71 (CAM DDS 0)	00
22	00	4D (MDL UP)	70	72 (MODE)	09
23	00	4E (MDL DWN)	6B	73 (DSP MODE)	00
24 (MGC)	00	4F (BTM UP)	52	74 (CAM ALN)	00
25 (ADJ MODE)	00	50 (BTM DWN)	3C	75 (AWB MODE)	00

Table 7-6.

### 7-3-6. PG CONT and Vsub Adjustment

#### 1. PG CONT adjustment (VC-85 board)

Subject	Not required
Measurement Point	Pin (A2) of check point array (PG CONT)
Measuring Equipment	Digital voltmeter
Adjustment Address	1D (PG CONT)
Specified Value	(Images voltage) $\pm 0.1$ Vdc

Adjusting method:

- 1) Change the adjustment data of the adjustment address 1D by the adjustment remote controller and set PG CONT voltage to (imager voltage)  $\pm 0.1$  Vdc.
- 2) Change the adjustment address to store the last adjustment data in the memory.

#### 2. Vsub adjustment (VC-85 board)


Subject	Not required
Measurement Point	Pin (B4) of check point array (V SUB)
Measuring Equipment	Digital voltmeter
Adjustment Address	1E (V SUB)
Specified Value	(Imager voltage) $\pm 0.1$ Vdc

Adjusting method:

- 1) Change the adjustment data of adjustment address 1E by the adjustment remote controller and set VSUB voltage to (imager voltage)  $\pm 0.1$  Vdc.
- 2) Change the adjustment address to store the last adjustment data in the memory.

Example:  
If 3P is indicated;  
PG CONT voltage specified value  
=  $2.0 \pm 0.1$  Vdc  
Vsub voltage specified value  
=  $13.5 \pm 0.1$  Vdc

CD-52 board shield case



VsUB voltage code

Code	Voltage (Vdc)
E	9.0
F	9.5
G	10.0
H	10.5
J	11.0
K	11.5
L	12.0
M	12.5
N	13.0
P	13.5
Q	14.0
R	14.5
S	15.0
T	15.5
U	16.0
V	16.5
W	17.0
X	17.5
Y	18.0
Z	18.5

PG CONT voltage code

Code	Voltage (Vdc)
1	1.0
2	1.5
3	2.0
4	2.5
5	3.0
6	3.5
7	4.0

Fig. 7-12.

### 7-3-7. Hall Adjustment (VC-85 Board)

Subject	All black (Cover lens with black cap.)
Measurement Point	CN902
Measuring Equipment	AF microprocessor reading tool
Adjustment Element	RF851 (HALL GAIN)
Adjustment Address	1B (HALL OFFSET)
Specified Value	When iris closed: minimum value of 01 to 04 When iris opened: 3D or 3E

Adjusting method:

- 1) Set RV851 to the mechanical center.
- 2) Select the adjustment address 25 by the adjustment remote controller and set the adjustment data to 05. (Setting when iris closed)
- 3) Change the adjustment address to 1B.
- 4) Change the adjustment data so that the reading tool indication becomes the minimum value of 01 to 04. (Hall off set adjustment)
- 5) Change the adjustment address to 25 and set the adjustment data to 07. (Setting when iris open)
- 6) Adjust with RV851 so that the indication of the reading tool indication becomes 3D or 3E. (3D is displayed as 3 d .)
- 7) Repeat 2) to 6) until the specified values are met.
- 8) Select the adjustment address 25 and set the adjustment data to 00. (Adjustment mode is released.)
- 9) Change the adjustment address to store the adjustment in the memory.

### 7-3-8. Positive Iris Adjustment (VC-85 Board)

Subject	Color bar chart standard picture frame
Filter	ND filter 0.4 and 0.1
Measurement Point	Pin (B1) of check point array (CCD OUT)
Measuring Equipment	Oscilloscope
Adjustment Address	19 (POSI IRIS)
Specified Value	$300 \pm 10$ mV

Adjusting method:

- 1) Set the adjustment address to 19 with the adjustment remote controller.
- 2) Change the adjustment data by the adjustment remote controller with no ND filter attached, and set CCD OUT signal level to  $300 \pm 10$  mV.  
(Change data from lower level to higher level and adjust it to the specified value.)
- 3) Attach the ND filter 0.5 (0.4+0.1) to the front of the lens and make sure that signal levels change smooth.
- 4) Remove the ND filter and make sure that signal level is  $300 \pm 20$  mV.
- 5) If the specification is not met, repeat 2) to 4).
- 6) Change the adjustment address to store the adjustment in the memory.




Fig. 7-13.

### 7-3-9. GC Confirmation (VC-85 board)

Subject	Color bar chart standard picture frame
Measurement Point	Pin (B3) of check point array (Y (LPF) OUT)
Measuring Equipment	Oscilloscope
Adjustment Address	$225 \pm 25$ mVp-p

Checking method:

- 1) Confirm that Y signal level is  $225 \pm 25$  mVp-p.




Fig. 7-14.

### 7-3-10. Y Signal Matrix Adjustment (VC-85 Board)

Subject	Color bar standard picture frame
Measurement Point	1: Pin (A4) (Y0) of check point array 2: Pin (A5) (Y1) of check point array
Measuring Equipment	Oscilloscope
Adjustment Address	0F (Y1 GAIN)
Specified Value	Y1 signal level=Y0 signal level

**Note:** Connect the probe to the measurement point via 10 K $\Omega$  resistor.

Adjusting method:

- 1) Connect the oscilloscope to Pin (A4) of check point array and measure Y0 signal level.
- 2) Connect the oscilloscope to Pin (A5) of check point array.
- 3) Set the adjustment address to 0F by the adjustment remote controller.
- 4) Change the adjustment data and match Y1 signal level with Y0 signal level measured in 1).
- 5) Change the adjustment address to store the adjustment data in the memory.




Fig. 7-15.

### 7-3-11. Chroma Signal Matrix Adjustment (1) (VC-85 Board)

Subject	Color bar standard picture frame
Measurement Point	1: Pin (A6) (C0) of check point array 2: Pin (A7) (C1) of check point array
Measuring Equipment	Oscilloscope
Adjustment Address	0E (C1 GAIN)
Specified Value	C1 signal level=C0 signal level

Adjusting method:

- 1) Connect the oscilloscope to Pin (A6) of check point array and measure C0 signal level. (The larger level of CR or CB should be C0 signal level.)
- 2) Signal connect the oscilloscope to Pin (A7) of check point array.
- 3) Set the adjustment address to 0E by the adjustment remote controller.
- 4) Change the adjustment data and match C1 signal level with C0 signal level measured in 1).
- 5) Change the adjustment address to store the adjustment data in the memory.



Fig. 7-16. C0, C1 signal level



### 7-3-12. Chroma Signal Matrix Adjustment (2) (VC-85 Board)

Subject	Color bar standard picture frame
Measurement Point	CH1 (X): Q712 emitter (B-Y) CH2 (Y): Connecting point (R-Y) between R765 and R822
Measuring Equipment	Oscilloscope (X-Y mode)
Adjustment Address	04 (C2 GAIN)
Specified Value	Separate luminance points should become one.

**Note:** Adjustment can be done in the same manner as using vectorscope.

(Vectorscope connecting terminal: video output terminal)




Fig. 7-18.

Measurement point




Fig. 7-17.

Adjusting method:

- 1) Set the adjustment address to 04 by the adjustment remote controller.
- 2) Change the adjustment data so that two separate color luminance points become one respectively.
- 3) Change the adjustment address to store the adjustment data in the memory.

**Note:** Although the white balance is not matched when the adjustment address 75 data is 00, the adjustment can be made without any trouble.

### 7-3-13. YH Level Adjustment (VC-85 Board)

Subject	Color bar chart standard picture frame
Measurement Point	Pin (A9) (YH) of check point array
Measuring Equipment	Oscilloscope
Adjustment Address	13 (YH GAIN)
Specified Value	$1000 \pm 40$ mVp-p

Adjusting method:

- 1) Set the adjustment address to 13 by the adjustment remote controller.
- 2) Change the adjustment data by the adjustment remote controller and set YH signal level to  $1000 \pm 40$  mVp-p.
- 3) Change the adjustment address to store the adjustment data in the memory.




Fig. 7-19.

### 7-3-14. Sync Level Adjustment (PJ-43 Board)

Subject	All black (Attach the black cap to the lens.)
Measurement Point	J002 (video output) or Pin ⑤ (VIDEO OUT) of CN208 on VC-85 board
Measuring Equipment	Oscilloscope
Adjustment Address	12 (sync level)
Specified Value	$300 \pm 5$ mVp-p

**Note:** Terminate J002 at  $75\Omega$ .

Adjusting method:

- 1) Set the adjustment address to 12 by the adjustment remote controller.
- 2) Change the adjustment data by the adjustment remote controller and set sync level to  $300 \pm 5$  mVp-p.
- 3) Change the adjustment address to store the adjustment data in the memory.




Fig. 7-20.

### 7-3-15. Setup Adjustment (PJ-43 Board)

Subject	All black (Attach the black cap to the lens.)
Measurement Point	J002 (video output) or Pin ⑤ (VIDEO OUT) of CN208 on VC-85 board
Measuring Equipment	Oscilloscope
Adjustment Address	11 (SET UP)
Specified Value	$25 \pm 10 \text{ mV}$

**Note:** Terminate J007 at  $75\Omega$ .

Adjusting method:

- 1) Turn "COLOUR" control (RV102 on VC-85 board) fully counterclockwise. (The procedure to reduce noises)
- 2) Set the adjustment address to 11 by the adjustment remote controller.
- 3) Change the adjustment data by the adjustment remote controller and set the set up level to  $25 \pm 10 \text{ mVp-p}$ .
- 4) Change the adjustment address to store the adjustment data in the memory.
- 5) Return "COLOUR" control to the center click position.




Fig. 7-21.

### 7-3-16. White Clip Adjustment (PJ-43 Board)

Subject	Color bar chart standard picture
Measurement Point	J002 (video output) or Pin ⑤ (VIDEO OUT) of CN208 on VC-85 board
Measuring Equipment	Oscilloscope
Adjustment Address	15 (POSI Y LEVEL)
Specified Value	$820 \pm 20 \text{ mV}$

**Note:** Terminate J007 at  $75\Omega$ .

Adjusting method:

- 1) Turn "COLOUR" control (RV102 on VC-85 board) fully counterclockwise.
- 2) Set the adjustment address to 15 and record the adjustment data.
- 3) Set the adjustment data to 40 by the adjustment remote controller.
- 4) Set the adjustment address to 10 by the adjustment remote controller.
- 5) Change the adjustment data by the adjustment remote controller and set the white clip level to  $820 \pm 20 \text{ mVp-p}$ .
- 6) Set the adjustment address to 15 and enter the adjustment data recorded in 2).
- 7) Change the adjustment address to store the adjustment data in the memory.
- 8) Return "COLOUR" control to the center click position.




Fig. 7-22.

### 7-3-17. Y Level adjustment (PJ-43 Board)

Subject	Color bar chart standard picture
Measurement Point	J002 (video output) or Pin ⑤ (VIDEO OUT) of CN208 on VC-85 board
Measuring Equipment	Oscilloscope
Adjustment Address	15 (POSI Y LEVEL)
Specified Value	$700 \pm 10 \text{ mV}$

**Note:** Terminate J002 at  $75\Omega$ .

Adjusting method:

- 1) Turn COLOUR control (RV102 on VC-85 board) fully counterclockwise (○).
- 2) Set the adjustment address to 15 by the adjustment remote controller.
- 3) Change the adjustment data by the adjustment remote controller and set Y signal level to  $700 \pm 10 \text{ mV}$ .
- 4) Change the adjustment address to store the adjustment data in the memory.
- 5) Return COLOUR control to the center click position.




Fig. 7-23.

### 7-3-18. Aperture Adjustment (VC-85 Board)

Subject	Inmega cycle chart
Measurement Point	Pin ⑧ (CAM Y) of check point array
Measuring Equipment	Oscilloscope
Adjustment Address	0A (C LEVEL)
Specified Value	$420 \pm 20 \text{ mV}$

Adjusting method:

- 1) Turn COLOUR control (RV102 on VC-85 board) fully counterclockwise (○).
- 2) Set the adjustment address to 14 by the adjustment remote controller.
- 3) Match the focus so that amplitude near 3 MHz becomes maximum.
- 4) Change the adjustment data so that the difference between 0.5 MHz level (peak not included) and 3 MHz peak level become  $70 \pm 10 \text{ mV}$ .
- 5) Change the adjustment address to store the adjustment data in the memory.
- 6) Return COLOUR control to the center click position.




Fig. 7-24.



### 7-3-19. Chroma Level Adjustment (VC-85 Board)

Subject	Color bar chart standard frame
Measurement Point	Pin (A1) (G OUT) of check point array
Measuring Equipment	Oscilloscope
Adjustment Address	0A (C LEVEL)
Specified Value	$320 \pm 20$ mV

Connection:

- 1) Connect with a jumper wire between Pin (B7) (MODE) of check point array and GND.

Adjusting method:

- 1) Set the adjustment address to 0A by the adjustment remote controller.
- 2) Change the adjustment data with the adjustment remote controller and set G OUT signal level to  $320 \pm 20$  mV.
- 3) Change the adjustment address to store the adjustment data in the memory.




Fig. 7-25.

### 7-3-20. Burst Phase Adjustment (PJ-43 Board) (Method Using Vectorscope)

Subject	All black (cover lens with black cap)
Measurement Point	CNJ002 (VIDEO OUT)
Measuring Equipment	Vectorscope
Adjustment Address	17 (HUE CONT)
Specified Value	$135^\circ \pm 1^\circ$

Adjusting method:

- 1) Set adjustment address to 17 with the adjustment remote controller.
- 2) Change adjustment data so as to set the burst luminance point in the  $135^\circ \pm 1^\circ$  position.
- 3) Change the adjustment address to store the adjustment data in the memory.
- 4) Perform Burst Level Adjustment.




Fig. 7-26.

### 7-3-21. Burst Phase Adjustment (PJ-43 Board) (Method Using Oscilloscope)

Subject	All black (cover lens with black cap)
Measurement Point	CNJ002 (VIDEO OUT) or Pin ⑤ of CN208 on VC-85 board
Measuring Equipment	Oscilloscope (Trigger slope: +)
Adjustment Address	17 (HUE CONT)
Specified Value	Burst phase should become a single line.

Adjusting method:

- 1) Set adjustment address to 17 with the adjustment remote controller.
- 2) Change the adjustment data so as to turn the burst waveform into a single line.
- 3) Change the adjustment address to store the adjustment data in the memory.
- 4) Perform Burst Level Adjustment.

Trigger point




Fig. 7-27.

### 7-3-22. Burst Level Adjustment (PJ-43 Board)

Subject	All black (Attach the black cap to the lens.)
Measurement Point	CNJ002 (video output) or Pin ⑤ (VIDEO OUT) of CN208 on VC-85 board
Measuring Equipment	Oscilloscope
Adjustment Address	16 (BURST LEVEL)
Specified Value	$300 \pm 5 \text{ mVp-p}$

**Note:** Terminate J002 at  $75\Omega$ .

Adjusting method:

- 1) Set the adjustment address to 16 by the adjustment remote controller.
- 2) Change the adjustment data by the adjustment remote controller and set the burst level to  $300 \pm 5 \text{ Vmp-p}$ .
- 3) Change the adjustment address to store the adjustment data in the memory.




Fig. 7-28.

### 7-3-23. Negative Iris Adjustment (VC-85 Board)

Subject	Negative color bar chart standard picture frame
Measurement Point	Pin ⑪ (CCD OUT) of check point array
Measuring Equipment	Oscilloscope
Adjustment Address	1F (NEGA IRIS)
Specified Value	$300 \pm 10 \text{ mV}$

Switch setting

Negative/positive selection.....negative

Adjusting method:

- 1) Set the adjustment address to 1F by the adjustment remote controller.
- 2) Change the adjustment data by the adjustment remote controller and set CCD OUT signal level to  $300 \pm 10 \text{ mV}$ . (Change the data from small to large level to meet the specification.)
- 3) Change the adjustment address to store the adjustment data in the memory.




Fig. 7-29.

### 7-3-24. Negative Y Level Adjustment (PJ-43 Board)

Subject	Negative color bar standard picture frame
Measurement Point	J002 (video output) or Pin ⑤ (VIDEO OUT) of CN208 on VC-85 board
Measuring Equipment	Oscilloscope
Adjustment Address	18 (NEGA Y LEVEL) 0D (NEGA PED)
Specified Value	White level: $660 \pm 10 \text{ mV}$ Black level: $50 \pm 10 \text{ mV}$

**Note:** Terminate J002 at  $75\Omega$ .

Switch setting:

Negative/positive selection.....negative

Adjusting method:

- 1) Turn "COLOUR" control (RV102 on VC-85 board) fully counterclockwise.
- 2) Set the adjustment address to 0D by the adjustment remote controller.
- 3) Change the adjustment data by the adjustment remote controller and set black level to  $50 \pm 10 \text{ mV}$ .
- 4) Set the adjustment address to 18.
- 5) Change the adjustment address and set the white level to  $660 \pm 10 \text{ mV}$ .
- 6) Repeat 2) to 5) until both specified values are met.
- 7) Change the adjustment address to store the adjustment data in the memory.
- 8) Return "COLOUR" control to the center click position.




Fig. 7-30.

**7-3-25. Negative Color Reproduction Adjustment  
(PJ-43 Board)**

Subject	(Method Using Vectorscope) Negative color bar chart standard picture frame
Measurement Point	J002 (video output)
Measuring Equipment	Vectorscope
Adjustment Address	0B (NEGA R GAIN) 0C (NEGA B GAIN) 05 (NEGA R-Y GAIN) 06 (NEGA B-Y GAIN) 07 (NEGA R-Y HUE) 08 (NEGA B-Y HUE)
Specified Value	All color luminance points are within color reproduction frame.

Switch setting  
Negative/positive selection.....negative

- Adjusting method:
- 1) Confirm that the adjustment data of adjustment address 75 (AWB MODE) is 00. And set the adjustment address to 01, then 02.
  - 2) Adjust the phase and gain of the vectorscope to set the burst luminance points to the designated position on the color reproduction frame (negative).
  - 3) Change the data of adjustment address 0B and 0C by the adjustment remote controller, and match black luminance point with the origin.
  - 4) Change each adjustment data of the adjustment address 05 to 08 and set all color luminance points within color reproduction frame.
  - 5) Change the adjustment address to store the adjustment data in the memory.




Fig. 7-31.



### 7-3-26. Negative Color Reproduction Adjustment (Method Using Oscilloscope)

#### 1. GAIN adjustment (PJ-43 board)

Subject	Negative color bar chart standard picture frame
Measurement Point	J002 (video output) or Pin ⑤ (video out) of CN208 on VC-85 board
Measuring Equipment	Oscilloscope
Adjustment Address	0B(NEGA R GAIN) 0C(NEGA B GAIN) 05(NEGA R-Y GAIN) 06(NEGA B-Y GAIN)
Specified Value	1. Chroma signal level of "black" is minimum. 2. Chroma signal level of "red" is $517 \pm 32$ mVp-p. 3. Chroma signal level of "yellow" is $422 \pm 24$ mVp-p.

**Note:** Terminate J002 at  $75\Omega$ .

Switch setting

Negative/positive selection.....negative

Adjusting method:

- White balance adjustment

- 1) Confirm that the adjustment data of adjustment address 75 (AWB MODE) is 00. And set the adjustment address to 01, then 02.
- 2) Change the data of adjustment address 0B and 0C by the adjustment remote controller and make chroma signal level of "Black" is minimum.

- Gain adjustment

- 3) Set adjustment address to 06 by the adjustment remote controller and set adjustment data to "CA".
- 4) Set adjustment address to 07 and set adjustment data to "C3".
- 5) Set adjustment address to 08 and set adjustment data to "CB".
- 6) Set adjustment address to 05 and change adjustment data so that chroma signal level of "red" becomes  $517 \pm 32$  mVp-p.
- 7) Set adjustment address to 06 and change adjustment data so that chroma signal level of "Yellow" becomes  $422 \pm 24$  mVp-p.
- 8) Repeat 5) to 6).
- 9) Change the adjustment address to store the adjustment data in the memory.
- 10) Perform "Hue adjustment".




Fig. 7-32.

## 2. Hue adjustment (VC-85 board)

Subject	Negative color bar chart standard picture frame
Measurement Point	CH1 (X): Q712 (B-Y) CH2 (Y): connecting point (R-Y) between R765 and R822 (See Fig. 7-17.)
Measuring Equipment	Oscilloscope (X-Y mode)
Adjustment Address	07 (NEGA R-Y HUE) 08 (NEGA B-Y HUE)
Specified Value	All color luminance points are within color reproduction frame.

Switch setting


Negative/positive selection.....negative

Adjusting method:

- 1) Move the black luminance point on the oscilloscope to the origin point of the color reproduction frame.
- 2) Change the adjustment data at adjustment addresses 07 and 08 with the adjustment remote controller to bring the various color luminance points into the color reproduction frame.

**Note:** The luminance points are inverted up/down and right/left against positive color reproduction frame.

- 3) Check the hue reproduced on the monitor TV and fine adjust the adjustment data at adjustment addresses 07 and 08 if necessary.
- 4) Set the oscilloscope to normal mode and connect it to J002 (video output) on the PJ-43 board, then make sure that the specified value of "1. Gain adjustment" is met. If not, change the data of the adjustment addresses 05 and 06.
- 5) Change the adjustment address to store the adjustment data in the memory.



Negative color reproduction frame for oscilloscope

Fig. 7-33.

## 7-3-27. Negative Pre-white Balance Adjustment (VC-85 Board)

Subject	Negative white balance chart (orange) standard picture frame
Measurement Point and Measuring Equipment	When vectorscope used: J002 on PJ-43 board (video output) or Pin ⑤ (VIDEO OUT) of CN208 When Oscilloscope (X-Y mode) used: CH1 (X): Q712 emitter (B-Y) CH2 (Y): connecting point (R-Y) between R765 and R822 (See Fig. 7-17)
Adjustment Address	0B (NEGA R GAIN) 0B (NEGA R GAIN)
Specified Value	When vectorscope used: The white luminance point should be within origin centered circle of $\phi$ 1 mm. When oscilloscope used: White luminance point and black luminance point should be matched.

Switch setting

Negative/positive selection.....negative

Adjusting method:

- 1) Make sure that the adjustment data of adjustment address 75 (AWB MODE) is 00. And set the adjustment address to 01, then 02.
- 2) Change the data of adjustment address 0B and 0C, and match white luminance point with the origin. (When the oscilloscope is used, match white luminance point with the origin. At this time, make sure that the white pattern has no color on the monitor TV.)
- 3) Change the adjustment address to store the adjustment data in the memory.




Fig. 7-34.

### 7-3-28. Auto White Balance Adjustment

**Note:** Be sure to perform this adjustment after completing preset adjustment.

#### 1. Preset adjustment (VC-85 board)

Subject	Negative white balance pattern (orange)
---------	---

- Note:** 1) Perform preset adjustment after applying power for more than 30 sec.  
2) Be sure to OFF/ON the power supply before performing preset adjustment again.

Switch setting

Negative/positive selection.....negative

Preparation:

Confirm that EVR ADJ mode is normal. TP106 (CAM ADJ) and (Pin B6) of check point array are open.)

- 1) Prepare to connect with 1 k $\Omega$  resistor between Pin B5 (AW ADJ) on the check point array and Pin ① of IC207 (REV 5V).

Adjusting method:

- 1) After OFF/ON the power, connect with the jumper wire between TP106 (or Pin B6) (CAM ADJ) on the check point array) and GND, then wait for more than 30 seconds.
- 2) Select the adjustment address 75 (AW ADJ) and set adjustment data to E0. (3200k preset data read mode)
- 3) Change the adjustment address to store the adjustment data in the memory. Wait five seconds or more.
- 4) Disconnect the jumper wire between TP106 (CAM ADJ) and GND.
- 5) Connect with a 1 k $\Omega$  resistor between Pin B5 (AWB ADJ) of check point array and Pin ① (REG 5V) of IC207.
- 6) Connect with the jumper wire between TP106 (CAM ADJ) and GND.
- 7) Confirm that the display data (address 01) of the adjustment remote controller has changed.
- 8) Disconnect the jumper wire connected to TP106 (CAM ADJ) after allowing one second or more to elapse.
- 9) Disconnect the 1 k $\Omega$  resistor connected to Pin B5 (AWB ADJ) of check point array.
- 10) Connect with the jumper wire between TP106 (CAM ADJ) and GND.
- 11) Perform the following "Auto White Balance Adjustment".

## 2. Auto White Balance Adjustment (VC-85 board)

Subject	White balance chart (gray) standard picture frame
Measurement Point	<p>When vectorscope used: J002 on PJ-43 board (video output) or Pin ⑤ (VIDEO OUT) of CN208 on VC-85 board</p> <p>When Oscilloscope (X-Y mode) used: CH1 (X):Q712 emitter (B-Y) CH2 (Y):connecting point (R-Y) between R765 and R822 (See Fig. 7-17)</p>
Adjustment Address	01 (DELTA R) 02 (DELTA B)
Specified Value	<p>When vectorscope used: White luminance point and the origin should be matched.</p> <p>When oscilloscope used: White luminance point and black luminance point should be matched.</p>




Fig. 7-35.

Switch setting

Negative/positive selection.....negative

Adjusting method:

- 1) Connect with the jumper wire between Pin (B1) (WB ADJ) of check point array and GND.
- 2) Select the adjustment address 75 and set adjustment data to 10. (auto white balance adjustment mode)
- 3) Confirm that the white balance chart (gray) is attached.
- 4) Change the data of 01 and 02 of the adjustment address and match white luminance point with the origin. (When using oscilloscope, match with black luminance point.)
- 5) Select the adjustment address 75 and set adjustment data to F0. (auto white balance tracking zone invalid:all area discrimination mode)
- 6) Change the data of 01 and 02 of the adjustment address and match the white luminance point with the origin. (When using oscilloscope, match with black luminance point.)
- 7) Disconnect the jumper wire connected to TP106 (CAM ADJ) and GND.
- 8) Disconnect the jumper wire connected to Pin (B1) of check point array and GND.
- 9) Connect with the jumper wire between TP106 (CAM ADJ) and GND.
- 10) Set negative/positive selection switch to positive side.
- 11) Perform "Positive pre-white balance adjustment".



### 7-3-29. Positive Pre-white Balance Adjustment (VC-85 Board)

Subject	White pattern fully TELE <sup>Note 1</sup>
Measurement Point	<p>When vectorscope used. J002 (video output) on PJ-43 board or Pin ⑤ (VIDEO OUT) of CN208 on VC-85 board</p> <p>When oscilloscope used: CH1 (X):Q712 emitter (B-Y) CH2 (Y):connecting point (R-Y) between R765 and R822 (See Fig. 7-17.)</p>
Adjustment Address	<p>1A (POSI R GAIN) 1C (POSI B GAIN)</p>
Specified Value	<p>When vectorscope used. The white luminance point is within the origin centered circle of <math>\phi</math> 1 mm.</p> <p>When oscilloscope used. White luminance point and black luminance point should be matched.</p>

**Note:** Remove the chart and shoot the white diffusing surface of light source in fully TELE end. At this time, check that no dust or stain is attached on the white diffusing surface.

Adjusting method:

- 1) Confirm that negative/positive selection switch is set to positive side.
- 2) Set the adjustment address to 75 (AWB MODE) and confirm that adjustment data is F0.
- 3) Set the adjustment address to 01.
- 4) Set the adjustment address to 02.
- 5) Set the adjustment address to 1A.
- 6) Change the data of 1A and 1C of the adjustment address and match white luminance point with the origin. (When using oscilloscope, match with black luminance point.)
- 7) Change the adjustment address to store the adjustment data in the memory.




Fig. 7-36.

7-3-30. Positive Color Reproduction Adjustment  
(Method using vectorscope)

Subject	Color bar chart standard picture frame
Measurement Point	J002 on PJ-43 board (video output)
Measuring Instrument	Vectorscope
Adjustment Element	RV509 (POSI R-Y GAIN) RV510 (POSI B-Y GAIN) RV511 (POSI R-Y HUE) RV512 (POSI B-Y HUE)
Specified Value	All color luminance points should be within positive color reproduction frame.

**Note:** "Burst level adjustment" should already had be done.

Adjusting method:

- 1) Confirm that the adjustment data of adjustment address 75 is F0. And set the adjustment address to 01, then 02.
- 2) Disconnect the jumper wire between TP106 (CAM ADJ) and GND.
- 3) Adjust the phase and gain of the vectorscope to set the burst luminance points to the designated position on the color reproduction frame (positive).
- 4) Turn RV509 to 512 and make all color luminance points within positive color reproduction frame.




Fig. 7-37.




Fig. 7-38. Moving direction of adjustment element and luminance point.

### 7-3-31. Positive Color Reproduction Adjustment (Method using oscilloscope)

Subject	Color bar chart standard picture frame
Measurement Point	J00 (video output) or Pin ⑤ (VIDEO OUT) of CN208 on VC-85 board
Measuring Instrument	Oscilloscope
Adjustment Address	RV509 (POSI R-Y GAIN) RV510 (POSI B-Y GAIN)
Specified Value	"Red" level: $645 \pm 32$ mVp-p "Yellow" level: $422 \pm 24$ mVp-p

**Note:** Terminate J002 at  $75\Omega$ .

Adjusting method:

- 1) Make sure that the adjustment data of adjustment address 75 (AWB MODE) is 00.
- 2) Disconnect the jumper wire between TP106 (CAM ADJ) and GND.
- 3) Set RV510 and 512 to the mechanical center.
- 4) Set "Red" level to  $645 \pm 32$  mVp-p with RV509.
- 5) Set "Yellow" level to  $422 \pm 24$  mVp-p with RV510.
- 6) Repeat 3) and 4) until the both specified values are met.
- 7) Perform "Hue adjustment".





Fig. 7-39.

### 2. Hue adjustment (VC-85 board)

Subject	Color bar chart standard picture
Measurement Point	CH1 (X):Q712 emitter (B-Y) CH2 (Y):connecting point (R-Y) between R765 and R822 (See Fig. 7-17)
Measuring Instrument	Oscilloscope (X-Y mode)
Adjustment Address	RV511 (POSI R-Y HUE) RV512 (POSI B-Y HUE)
Specified Value	Each luminance point should be within the (positive) color reproduction frame.

Adjusting method:

- 1) Confirm that the jumper wire between TP106 (CAM ADJ) and GND is disconnected.
- 2) Match "Black" luminance point with the origin of color reproduction frame (positive).
- 3) Turn RV511 and 512 and set each luminance point within the color reduction frame.
- 4) Confirm that hue reproduced on the monitor TV and fine adjust RV511 and 512 if necessary.
- 5) Set the oscilloscope in normal mode and connect to J002 (video output, terminated at  $75\Omega$ ), then confirm that the specified value of "1. Gain adjustment" is met. If not, adjust RV509 and RV510.



Color reproduction frame for oscilloscope (positive)

Fig. 7-40.

7-3-32. Auto Focus Adjustment (VC-85 board)

1. Adjustment in all black pattern

Subject	All black (Attach a black cap to the lens.)
Measurement Point	CN902
Measuring Instrument	Reading tool for AF microprocessor data
Adjustment Address	31 (FHB), 33 (AGC B)

Adjusting method:

- 1) Set the adjustment address 25 by the adjustment remote controller and set adjustment data to FF.  
(Set the auto focus filter to FH side.)
- 2) Read the display data (FH B) of AF microprocessor data reading tool and enter adjustment address 31. (FH B should be 00 to 05.)
- 3) Set the adjustment address 25 by the adjustment remote controller and set adjustment data to FD.  
(Set the auto focus filter to FA side.)
- 4) Confirm the displayed data (FA B) of AF microprocessor data reading tool is 00 to 08.)
- 5) Set the adjustment address 25 and enter adjustment data 0B.  
(AGC A/D value display mode)
- 6) Read the display data (AGC B) of AF microprocessor data reading tool and enter adjustment address 33.
- 7) Perform "Adjustment in white pattern".

2. Adjustment in white pattern

Subject	White pattern fully TELE end <small>Note 1</small>
Measurement Point	CN902
Measuring Instrument	AF micro processor reading tool
Adjustment Address	30 (FWH), 32 (AGC W)

**Note:** Remove the chart and shoot the white diffusing surface of light source in fully TELE end. At this time, check that no dust or stain is attached on the white diffusing surface.

Adjusting method:

- 1) Set the adjustment address 25 by the adjustment remote controller and enter adjustment data FF.
- 2) Read the displayed data (FH W) of AF microprocessor data reading tool and enter adjustment address 30. (FH W should be 00 to 04.)
- 3) Set the adjustment address 25 by the adjustment remote controller and enter adjustment data FD.
- 4) Confirm that the displayed data (FA W) of AF microprocessor data reading tool is 00 to 06.)
- 5) Set the adjustment address 25 and enter adjustment data is 0B.
- 6) Read the displayed data (AGC W) of AF microprocessor data reading tool and enter adjustment address 32.
- 7) Set the adjustment address 25 and enter adjustment data 00.
- 8) Change the adjustment address to store the adjustment data in the memory.

7-3-33. Auto Focus Confirmation (VC-85 Board)


Subject	Siemens star
Filter	ND filter 1.0 and 0.1 (2 pcs)
Measurement Point	CN902
Measuring Instrument	AF microprocessor reading tool

Adjusting method:


- 1) Mount the ND filter 1.2 (1.0+0.1+0.1) on the lens.
- 2) Press the zoom T button to set the zoom TELE end.
- 3) Adjust the chart position so that the center of siemens star matches with that of the monitor TV screen.
- 4) Press the focus N button to set the focus near end.
- 5) Keep pressing "AUTO" button for three seconds and hand off the button after confirming a sharp image.
- 6) Set the adjustment address 25 by the adjustment remote controller and enter adjustment data FF.
- 7) Confirm that the displayed data (FH SM) of AF microprocessor data reading tool is 0F to 37.
- 8) Set the adjustment address 25 and enter adjustment data FD.
- 9) Confirm that the display data (FA SM) of AF microprocessor data reading tool is 4E to 80.
- 10) Set the adjustment address 25 and enter adjustment data 00.
- 11) Change the adjustment address to store the adjustment data in the memory.

7-4. ARRANGEMENT DIAGRAM FOR ADJUSTMENT PARTS

FA-1 BOARD (COMPONENT SIDE)




POWER BLOCK (CONDUCTOR SIDE)




7-4. ARRANGEMENT DIAGRAM FOR ADJUSTMENT PARTS


FA-1 BOARD (COMPONENT SIDE)




POWER BLOCK (CONDUCTOR SIDE)



VC-85 BOARD (COMPONENT SIDE)





VC-85 BOARD (CONDUCTOR SIDE)






BOARD (COMPONENT SIDE)






Color Reproducibility Adjustment (For Negative)  
For Vectorscope




Color Reproducibility Adjustment (For Negative)  
For Oscilloscope





Color Reproducibility Adjustment (For Positive)  
For Vectorscope



Color Reproducibility Adjustment (For Positive)  
For Oscilloscope



